COLOINTACO

Absolute Encoders

AMT58



Ether**CAT**

Instruction Manual

\$DATALOGIC

Datalogic S.r.l. Via S. Vitalino 13 40012 Calderara di Reno Bologna - Italy

© 2014 - 2017 Datalogic S.p.A. and/or its affiliates • ALL RIGHTS RESERVED. • Without limiting the rights under copyright, no part of this documentation may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means, or for any purpose, without the express written permission of Datalogic S.p.A. and/or its affiliates.

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

All other trademarks and brands are property of their respective owners. Datalogic reserves the right to make modifications and improvements without prior notification.

1 - Safety summary	1
Safety	1
Electrical safety	1
Mechanical safety	2
2 - Identification	3
3 - Mechanical installation	4
3.1 Solid shaft encoders	4
3.1.1 Customary installation	4
3.1.2 Installation using fixing clamps (code LKM-386)	4
3.1.3 Installation using a mounting bell (code ST-58-FLNG)	5
3.2 Hollow shaft encoders	6
3.2.1 AMT58-H15	6
4 - Electrical connections	7
4.1 M12 connectors	7
4.2 Ground connection	8
4.3 Diagnostic LEDs	8
5 - Quick reference (TwinCAT)	9
5.1 System configuration using TwinCAT software system from Beckhoff	9
5.1.1 Setting the Network Card	9
5.1.2 Add new I/O modules (Boxes)	11
5.2.1 Synchronous with SM3	
5.2.2 Synchronous with DC (SYNC0)	17
5.3 Process Data Objects	
5.4 COE Object Dictionary	
5.5 Online Data	20
5.6 EEProm upgrade	
5.7 Firmware upgrade	
6 - EtherCAT® interface	30
6 1 Basic Information on EtherCAT® Protocol	30
6 1 1 Data transfer	31
6 1 2 ISO/OSI I aver model	31
6 1 3 Topology	
6 1 4 Line Termination	33
6 1 5 Addressing	
6 1 6 Communication mode	
FreeRun	35
Synchronous with DC SYNC0	37
6 1 7 EtherCAT State Machine (ESM)	38
6 1 8 Slave configuration	
6 1 9 Timing and Synchronization	40
Svnc Manager	40
Buffered Mode (3-Buffer Mode)	40
Mailbox Mode (1-Buffer Mode)	40
6 2 CANopen Over EtherCAT (CoE)	41
	· ب
6.2.3 Process Data Objects (PDO)	<u>4</u> 3
6 2 5 Object dictionary	4 5
Standard objects	4 5

1000-00 Device type	45
1008-00 Manufacturer Device Name	45
1009-00 Hardware version	45
100A-00 Software version	46
1010-01 Store parameters	46
1011-01 Restore default parameters	46
1018 Identification object	47
01 Vendor number	47
02 Product number	47
03 Revision number	47
04 Serial number	47
1A00-01 PDO mapping parameter	47
1C00 Sync Manager Communication Type	47
01 SM MailBox Receive (SM0)	47
02 SM MailBox Send (SM1)	47
03 SM PDO output (SM2)	47
04 SM PDO input (SM3)	47
1C12-00 Sync Manager RxPDO Assigned	47
1C13-01 Sync Manager TxPDO Assigned	47
1C33 Sync Manager input parameter	47
01 Sync Type	48
02 Cycle time	48
03 Shift Time	48
04 Sync modes supported	48
05 Minimum cycle time	48
06 Calc and Copy time	48
Device profile objects	49
6000-00 Operating parameters	49
Code sequence	49
Scaling function	49
6001-00 Counts per revolution	49
6002-00 Total resolution	50
6003-00 Preset value	51
6004-00 Position value	53
6500-00 Operating status	53
Code sequence	53
Scaling function	53
6501-00 Hardware counts per revolution	54
6502-00 Hardware number of turns	54
6503-00 Errors	54
6504-00 Supported errors	54
6505-00 Warnings	54
6506-00 Supported warnings	54
6509-00 Offset value	54
6.2.6 SDO Abort codes	55
6.2.7 Emergency Error Codes	55
6.2.8 AL Status Error Codes	55
7 – Default parameters list	56

Subject Index

1	
1000-00 Device type	.45
1008-00 Manufacturer Device Name	.45
1009-00 Hardware version	.45
100A-00 Software version	.46
1010-01 Store parameters	.46
1011-01 Restore default parameters	.46
1018 Identification object	.47
1A00-01 PDO mapping parameter	.47
1000 Sync Manager Communication Ty	/pe .47
1C12-00 Sync Manager RxPDO Assign	ned
	.47
1C13-01 Sync Manager TXPDO Assign	1ea .47
1C33 Sync Manager input parameter	.47
6	
6000-00 Operating parameters	.49
6001-00 Counts per revolution	.49
6002-00 I otal resolution	.50
	.51
6004-00 Position value	.53
6500-00 Operating status	.53 ion
6501-00 Hardware counts per revolut	.1011 57
6502-00 Hardware number of turns	. 54 54
6503-00 Errors	. 54 54
6504-00 Supported errors	.54
6505-00 Warnings	.54
6506-00 Supported warnings	.54
6509-00 Offset value	.54

С

•	
Calc and Copy time	48
Code sequence4	9; 53
Cycle time	48
D	
Diagnostic data	55
H	
Hardware error	55
	~~~
INI I	38
IVI Minimum eveletinee	40
	48
	20
	38
Product number	
R	
Revision number	
S	
SAFE-OPERATIONAL	38
Scaling function4	9; 53
Serial number	47
Shift Time	48
SM MailBox Receive (SM0)	47
SM MailBox Send (SM1)	47
SM PDO input (SM3)	47
SM PDO output (SM2)	47
Sync modes supported	48
Sync Type	48
V	
Vendor number	47

# Typographic and iconographic conventions

In this guide, to make it easier to understand and read the text the following typographic and iconographic conventions are used:

- parameters and objects both of the device and the interface are coloured in ORANGE;
- alarms are coloured in RED;
- states are coloured in FUCSIA.

When scrolling through the text some icons can be found on the side of the page: they are expressly designed to highlight the parts of the text which are of great interest and significance for the user. Sometimes they are used to warn against dangers or potential sources of danger arising from the use of the device. You are advised to follow strictly the instructions given in this guide in order to guarantee the safety of the user and ensure the performance of the device. In this guide the following symbols are used:

	This icon, followed by the word WARNING, is meant to highlight the parts of the text where information of great significance for the user can be found: user must pay the greatest attention to them! Instructions must be followed strictly in order to guarantee the safety of the user and a correct use of the device. Failure to heed a warning or comply with instructions could lead to personal injury and/or damage to the unit or other equipment.
<b>()</b>	This icon, followed by the word NOTE, is meant to highlight the parts of the text where important notes needful for a correct and reliable use of the device can be found. User must pay attention to them! Failure to comply with instructions could cause the equipment to be set wrongly: hence a faulty and improper working of the device could be the consequence.
1	This icon is meant to highlight the parts of the text where suggestions useful for making it easier to set the device and optimize performance and reliability can be found. Sometimes this symbol is followed by the word EXAMPLE when instructions for setting parameters are accompanied by examples to clarify the explanation.

# **Preliminary information**

This guide is designed to describe the technical characteristics, installation and use of the EtherCAT encoders of the AMT58 series.

For any further information please refer to the product datasheet.

To make it easier to read the text, this guide is divided into two main sections.

In the first section general information concerning the safety, the mechanical installation and the electrical connection as well as tips for setting up and running properly and efficiently the unit are provided.

In the second section, entitled EtherCAT Interface, both general and specific information is given on the EtherCAT interface. In this section the interface features and the objects implemented in the unit are fully described.

## 1 - Safety summary

#### Safety

- Always adhere to the professional safety and accident prevention regulations applicable to your country during device installation and operation;
- installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected and stationary mechanical parts;
- device must be used only for the purpose appropriate to its design: use for purposes other than those for which it has been designed could result in serious personal and/or the environment damage;
- high current, voltage and moving mechanical parts can cause serious or fatal injury;
- warning ! Do not use in explosive or flammable areas;
- failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the equipment;
- Datalogic Automation s.r.l. assumes no liability for the customer's failure to comply with these requirements.

#### **Electrical safety**

- Turn off power supply before connecting the device;
- connect according to explanation in the section 4 "Electrical connections " in compliance with the 2014/30/EU norm on electromagnetic compatibility, following precautions must be taken:



- before handling and installing, discharge electrical charge from your body and tools which may come in touch with the device;
- power supply must be stabilized without noise, install EMC filters on device power supply if needed;
- always use shielded cables (twisted pair cables whenever possible);
- avoid cables runs longer than necessary;
- avoid running the signal cable near high voltage power cables;
- mount the device as far as possible from any capacitive or inductive noise source, shield the device from noise source if needed;
- to guarantee a correct working of the device, avoid using strong magnets on or near by the unit;
- minimize noise by connecting the shield and/or the connector housing and/or the frame to ground. Make sure that ground is not affected by noise. The connection point to ground can be situated both on the device side and on user's side. The best solution to minimize the interference must be carried out by the user.

1

#### Mechanical safety

- Install the device following strictly the information in the section 3 "Mechanical installation"
- mechanical installation has to be carried out with stationary mechanical parts;
- do not disassemble the encoder;
- do not tool the encoder or its shaft;
- delicate electronic equipment: handle with care; do not subject the device and the shaft to knocks or shocks;
- respect the environmental characteristics declared by manufacturer;
- unit with solid shaft: in order to guarantee maximum reliability over time of mechanical parts, we recommend a flexible coupling to be installed to connect the encoder and user's shaft; make sure the misalignment tolerances of the flexible coupling are respected;
- unit with hollow shaft: the encoder can be mounted directly on a shaft whose diameter has to respect the technical characteristics specified in the purchase order and clamped by means of the collar and, when requested, the anti-rotation pin.

## 2 - Identification

Device can be identified through the ordering code and the serial number printed on the label applied to its body. Information is listed in the delivery document too. Please always quote the ordering code and the serial number when reaching Datalogic Automation s.r.l. for purchasing spare parts or needing assistance. For any information on the technical characteristics of the product refer to the technical catalogue.

## 3 - Mechanical installation



#### WARNING

Installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected. Shaft and mechanical components must be in stop.

#### 3.1 Solid shaft encoders

- Mount the flexible coupling 1 on the encoder shaft;
- fix the encoder to the flange 2 (or to the mounting bell) by means of the screws 3;
- secure the flange 2 to the support (or the mounting bell to the motor);
- mount the flexible coupling 1 on the motor shaft;
- make sure the alignment tolerances of the flexible coupling 1 are respected.

#### 3.1.1 Customary installation



#### 3.1.2 Installation using fixing clamps (code LKM-386)



## **OJATALOGIC**

3.1.3 Installation using a flange (code ST-58-FLNG)



3.2 Hollow shaft encoders

#### 3.2.1 AMT58-H15

- Mount the encoder on the motor shaft using the reducing sleeve 8 (if supplied). Avoid forcing the encoder shaft;
- fasten the fixing plate 4 to the rear of the motor using two M3 cylindrical head screws 5;
- fix the collar 3 to the encoder shaft (apply threadlocker to screw 3).





## 4 - Electrical connections



WARNING

Power supply must be turned off before performing any electrical connection!

Do not remove the connection cap of the encoder. Damage may be caused to internal components.



#### 4.1 M12 connectors

The connection cap is fitted with three M12 connectors with pin-out in compliance with the EtherCAT® standard. Therefore you can use standard EtherCAT cables commercially available.

Input (IN) and output (OUT) connectors are not interchangeable! IN connector must be placed in the direction of the ETherCAT Master.

M12	BUS IN & BUS OUT	POWER
(frontal side)	$4 \bigcirc 0 2$	$4 \bigcirc 3 \\ 1 \bigcirc 2$
	D coding female	A coding male

Pin	Description	Description
1	Tx Data +	+10VDC +30VDC
2	Rx Data +	n.c.
3	Tx Data -	0 VDC
4	Rx Data -	n.c.

n.c.= not connected.

#### 4.2 Ground connection

Minimize noise by connecting the shield and/or the connector housing and/or the frame to ground. Make sure that ground is not affected by noise. The connection point to ground can be situated both on the device side and on user's side. The best solution to minimize the interference must be carried out by the user. You are advised to provide the ground connection as close as possible to the encoder. We suggest using the ground point provided in the cap (see Figure, use 1 TCEI M3 x 6 cylindrical head screw with 2 tooth lock washers).

#### 4.3 Diagnostic LEDs

Five LEDs located in the rear side of the connection cap are designed to show the operating or fault status of the EtherCAT® interface.

Link/ Activity	it shows the status of the physical link and the
(yellow)	activity in this link
OFF	condition: port closed, link: YES, activity: N.A.
FLICKERING	condition: port open, link: YES, activity: YES
ON	condition: port open, link: YES, activity: NO

RUN (green)	it shows the status of the EtherCAT State Machine (ESM)
OFF	encoder is in INIT status
BLINKING	encoder is in PRE-OPERATIONAL status
SINGLE FLASH	encoder is in SAFE-OPERATIONAL status
ON	encoder is in OPERATIONAL status

PWR (green)	it shows the power supply status
OFF	encoder is switched OFF
ON	encoder is switched ON

ERR (red)	it shows the error status
OFF	no error
FLICKERING	error on loading parameters from flash
	memory at start-up
FLICKERING	encoder parameters have not been saved
	correctly on flash memory
BLINKING	invalid configuration
SINGLE FLASH	local error (see ETG1000.6)
DOUBLE FLASH	watchdog timeout
ON	memory error and ESC controller not active

## 5 - Quick reference (TwinCAT)

5.1 System configuration using TwinCAT software system from Beckhoff

5.1.1 Setting the Network Card

Launch TwinCAT System Manager.

In the left pane of the main window extend the devices tree and select the I/O Devices item; right-click the I/O Devices item and then press the Append Device... command.

🛒 TwinCAT System Manager	
File Edit Actions View Options Help	
: D 🚅 📽 🖬 🍜 &, X 🖻 🖻 🔗 🗛 8   9	🗏 🖴 🗸 🏙 👧 🌺 🔧 🌾 🔕 🏘 🖹 Q 🞜 66 🤦 🐒 🏈 🖾 🤋
SYSTEM - Configuration     SYSTEM - Configuration     PLC - Configuration	зчісе Туре
🖻 📴 I/O - Configuration	
Append Device	
😭 Import Device	
📉 Scan Devices	
🔁 <u>P</u> aste Ctrl+V	
Paste with Links Alt+Ctrl+V	
Ready	Local (169.254.196.134.1.1) Config Mode

In the Insert Device window select the EtherCAT (Direct Mode) item and confirm pressing the OK button.

Insert De	vice	
Туре:	WO Beckhoff Lightbus Profibus DP Interbus-S Cia CANopen DeviceNet W SERCOS interface EtherCAT EtherCAT EtherCAT Ethernet Ethernet Ethernet Miscellaneous	Ok Cancel Target Type O PC only CX only O XX only O XX only All
Name:	Device 1	

If a network card has been already installed properly, the following window will appear showing the list of the installed devices.

Device Found At	
(nessuno) Connessione rete senza fili (802.11n Wireless LAN Card - Miniport dell'U Connessione alla rete locale (LAN) (Realtek RTL8168C(P)/8111C(P) PC	OK Cancel O <u>U</u> nused O <u>A</u> ll

Select the network card you want to use and then confirm the choice pressing the OK button.

If there are no network cards installed, you must install one before proceeding.

To do this, on the menu bar of the TwinCAT System Manager main window, select the Options menu and then press the Show Real Time Ethernet Compatible Devices... command.



## **COLATACO**

The Installation of TwinCAT RT – Ethernet Adapter window will appear. Now select Compatible Devices item and choose the network card you want to install; finally press the Install button to confirm your choice.

#### 5.1.2 Add new I/O modules (Boxes)

If devices are connected to the network and switched ON, right-click the Device 1 (EtherCAT) item in the left pane of the TwinCAT System Manager main window and press the Scan Boxes... command.

👼 TwinCAT System /	Manager						- 7 🛛
File Edit Actions View	Options Help						
🗅 🚅 📽 🔒 🎒		M 8 🔜	aa 🗸 💣 👧	🙆 🎨 🖄	् 🛞 🖗	E Q @ 66 🕵 🕫	🧶 🕚 💡
SYSTEM - Configuratio     PUC - Configuratio     J/O Configuratio     Devices     Devices     Device 1 (     Device 1)     Device     Devi	Append Box Append Box Collected Device Collected Con Colline Reload (Cor Colline Delete (Con	General Adapter Name: fig Mode only) ig Mode only)	EtherCAT Onlin Device 1 (EtherCA EtherCAT (Direct M	e CoE - Onli T) lode)	ne	Id: 1	
	😭 Export Device		Disabled			Create symbols 📃	
	😭 Import Box						×
	Scan Boxes		Box Name		Online	Address Type	In Si
	∦ Cu <u>t</u>	Ctrl+X					
	Ba Cobh	Ctrl+C					
	Paste	Ctrl+V					
	昆 Paste with Links	Alt+Ctrl+V					
	🔂 Change Id						
	× Disabled						
	Change To	•					
	Change NetId						
		J.					>
Ready						Local (169.254.196.134.1	1) Config Mode

At the end of the process some information will be listed in the right page as in Figure here below.

📕 vuoto_inglese.tsm - TwinCAT System	m Manager					
Eile Edit Actions View Options Help						
D 😅 📽 🖬 🌆 🖪   👗 🖻 🖻	a m a 💷	66 / # @ @ \$	× 🐼 🗣 🖹	QP	66 🗙 🕵	0 8
SYSTEM - Configuration     PLC - Configuration     PLC - Configuration	General Adapte	r EtherCAT Online CoE -	Online			^
I/O Devices	Name:	Device 1 (EtherCAT)		ld:	1	
Device 1 (EtherCAT)	Туре:	EtherCAT (Direct Mode)				
Device 1-Image-Info     Device 1-Image-Info     St Inputs     Dutputs     InfoData     Box 1 (AMT58-13x14-EC)	Comment				< >	
		Disabled	A.miter =	Creat	e symbols 🗌	~
	Number	Box Name	Online	Address	Туре	In
	■ 1	Box 1 (AMT58-13x14-EC)	0~0000000 (0)	1001	AMT58-13x14	-EC 4.(
	WcState	WeState	1			
	S InfoData	westate	1			
	\$T	State	0×0002 (2)			
	<b>\$</b> ₽1	AdsAddr	A9 FE C4 86 02			
<	<					>
Ready			Local (	(169.254.19	6.134.1.1) Co	nfig Mode

## **COLATACO**

If devices are not already connected to the network it is necessary to use the XML file supplied with the encoder: **AMT58-xxx-13x14-EC** (see at www.datalogic.com). At the same address you can also download the most recent files to update both the firmware and the EEProm of the encoder. For older versions of the files please contact Datalogic Automation s.r.l. After Sales Service Dept. For any information on the firmware upgrade procedure refer to the section "5.7 Upgrade firmware" on page 26. For any information on the EEProm upgrade procedure refer to the section "5.6 EEProm upgrade" on page 21).

#### WARNING



Before installing the XML file please check that it is compatible with the firmware version and the EEProm version of the device; the XML file version, the firmware version and the EEProm version must always comply. For example: if the firmware version is H1_S4 (Hardware version: 1; Software version: 4), it is mandatory that the EEProm version is S4, therefore you must then install the XML file version V4. For a description EEProm upgrade procedure please refer to the section "5.6 EEProm upgrade" on page 21. For a description of the firmware upgrade procedure please refer to the section "5.7 Firmware upgrade" on page 26.



#### WARNING

It is mandatory that in an EtherCAT network all devices are provided with the same version of the firmware, EEProm and XML file. So when you need to replace an old encoder installed in your network, then you must either upgrade all the encoders in the network to the last version compatible with the new encoder; or you must downgrade the new encoder to the older version compatible with the encoders already installed in the network.

If you want to know the firmware version of a device, press the Box (AMT58-ECAT) item in the left pane of the TwinCAT System Manager main window: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the CoE - Online page and refer to the indexes Hardware version and Software version.

🦻 TwinCAT System Manager									- 7 🛛
D 🖻 📽 🖬 🎒 🔃 X 🖻 🖻 🔒	M 8 🔳 📾 -	/ 谢 👧 🧕 🎨 🔨 🧕			66° 🔩 🕵	۲	?		
Gonfigurazione SYSTEM     Gonfigurazione NC     Gonfigurazione PLC	Generale EtherC.	AT DC Process Data Av	tio CoE - Onlin	ne   In li	inee   Show Offline Di				1
Configurazione eccentrico	Australia	All Objects	It olingie opda	ne i la	NIOW ONLINE DA				
E-B Dispositivi I/O	Avditzate					_			
🖻 🚍 Dispositivo 1 (EtherCAT)	Add to Star	tup Online Data	Module	OD (AGE	= Port): [0				
Dispositivo 1-Immagine di proces	Index	Nome	Elag	9	Valore			1	
Dispositivo 1-Immagine di proces	1000	Device type	BO		0x00010196	65942)			
E Si Licrite	1000	Device name	RO	-	PARTER-13x1	H-EC			
H. A InfoData	1009	Hardware version	RO		H01				
H	100A	Software version	RO		S04	)			
	1010:0	Store parameters	RO		>14				
Assegnazioni		Produces default parameters	DO		>1<				
332		Identity	RO		>4 <				
	± 1A00:0	TxPDO Mapping	HU DO		>1<				
	10120	Sync Manager Communication	Type HU		240				
	1012.0	TyPDO assign	RW		514				
	+ 1033-0	SM input parameter	BO		>64				
	+ 3000:0	Reserved	RO		>2<				
	6000	Operating Parameters	RW		0x0000 (0)				
	6001	Units per revolution	RW		0x00010000	(65536)			
	6002	Total Measuring Range	RW		0x40000000	(107374182	4)		
	6003	Preset	RW		0x00000000	0 (0)			
	6004	Position Value	RO F	2	0x00007E43	3 (32323)			
	6500	Operating Status	RO		0x0000 (0)				
	6501	Single Turn Resolution	RO		0x00010000	) (65536)			
	6502	Number of Revolutions	RO		0x00004000	(16384)			
	6503	Errors	RO		0×0000 (0)				
	Nome	Online	Tino	Gran.		Entra	User ID	Collegato a	
	Position Value	0x00000000 (0)	UDINT	4.0	39.0	Ingre	0	1	
	<b>♦</b> †WcState	1	BOOL	0.1	1522.1	Ingre	0		
	♦ State	0x0002 (2)	UINT	2.0	1548.0	Ingre	0		
	AdsAddr	A9 FE B0 C1 02 01	AMSADDRESS	8.0	1550.0	Ingre	0		
	A netId	A9 FE B0 C1 02 01	ARRAY [0	6.0	1550.0	Ingre	0		
	♦Î netīd[0]	0xA9 (169)	USINT	1.0	1550.0	Ingre	0		-
	♦ netId[1]	0xFE (254)	USINT	1.0	1551.0	Ingre	0		
4	♦Î netId[2]	0xB0 (176)	USINT	1.0	1552.0	Ingre	0		
	I OTnetid[3]	0vC1 (193)	USINT	1.0	1553.0	Incre	0		

Right-click the Device 1 (EtherCAT) item in the left pane of the TwinCAT System Manager main window and press the Append Box... command.



## **COLOUNTAGO**

In the Insert EtherCAT Device window that appears select Datalogic S.p.a and then EtherCAT Encoder items; now choose from the list the encoder you want to install:

• AMT58-ECAT

Press the OK button to confirm your choice.

Insert Et	ierCAT Device			
Nome:	Box 1 <u>M</u>	<u>t</u> ultiple:	1	ОК
<u>T</u> ipo:	Beckhoff Automation GmbH     System Couplers     EK1100 Ethernet Coupler Terminal (2A E-Bus)     CX1100-0004 Coupler Terminal (2A E-Bus)     Evaluation terminal terminal terminal (2A E-Bus)     Dives     Evaluation terminal termina			Annulla Indent O 0 1 Physics Tutti E-Bus

5.2 Setting the communication mode

#### 5.2.1 Synchronous with SM3

In the left pane of the TwinCAT System Manager main window press the Box (AMT58-ECAT) item: some tabbed pages for configuring and managing the device will appear in the right pane. Enter DC page. Select the Synchronous with SM3 (Inputs) option in the Operation Mode box.

📕 vuoto_inglese.tsm - TwinCAT System	n Manager	
Eile Edit Actions View Options Help		
D 🗳 📽 🖬 🍜 🖪 🗡 h 🖻 🕯	B # B 🗏 📾 🗸 🏄 👧 🧕 💱 🔨 🚱 🖹 🔍 🖓 60 🔍 🐒 1	0 8
SYSTEM - Configuration PLC - Configuration I/O - Configuration I/O - Configuration I/O - Configuration Device 1 (EtherCAT) Device 1-Image Device 1-Image Volume I (Dutputs InfoData In	General EtherCAT DC Process Data Startup CoE - Online Online Operation Mode: Advanced Settings	
< III (>	LJ	×
Ready	Local (169.254.196.134.1.1)	nfig Mode 🛄

For any further information on the Synchronous with SM3 operation mode please refer to the section "Synchronous with SM3" on page 36 and to the object **1C33 Sync Manager input parameter** on page 48.

5.2.2 Synchronous with DC (SYNC0)

In the left pane of the TwinCAT System Manager main window press the Box (AMT58-ECAT) item: some tabbed pages for configuring and managing the device will appear in the right pane. Enter DC page. Select the Synchronous with DC (SYNC0) option in the Operation Mode box.

Then press the Advanced Settings... button.

)istributed Clock	Distributed Clock			
	Operation Mode:	Sunchronous with D		
	Fnable	Sunc Unit Cucle (us):	2000	
	_ SYNC 0	oyno onik oyolo (poj.		
	Sync Unit Cycle x 1	Cycle Time (μs):	2000	
	O User Defined	Shift Time (µs):	0	
	Enable SYNC 0			
	SYNC 1			
	🔘 Sync Unit Cycle	🧹 Cycle Time (μs):	2000	
	SYNC 0 Cycle x 1	🗸 Shift Time (μs):	0	
	Enable SYNC 1			
	Reference Clock			
	Reference Clock Device:	Box 1 (AMT58-13x1	4-EC)	
	Assign to local µC			
	Cyclic Unit	Jnit 0	tch Unit 1	

The Advanced Settings window will appear. In the section tabbed SYNC 0 set the cycle time next to the Sync Unit Cycle box; sync time is calculated as multiple (or sub-multiple) of the value set in the Sync Unit Cycle ( $\mu$ s) item right above.

For any further information on the Synchronous with DC operation mode please refer to the section "Synchronous with DC SYNC0" on page 37 and to the object **1C33 Sync Manager input parameter** on page 48.

#### 5.3 Process Data Objects

In the left pane of the TwinCAT System Manager main window press the Box (AMT58-ECAT) item: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the Process Data page. In this page process data objects (PDO Mapping) are shown.

TwinCAT System Manager			_ 7
e Edit Actions View Options Help	a 🗛 a 🚇 📾 🗸 🐲 👧	<u>&amp; % &lt; + Eq.</u> ## <b>%</b> ¢	• 1
SYSTEM - Configuration  LC - Configuration  KP PROVA2 PLC  IO - Configuration	General EtherCAT DC Process Sync Manager:	Data Startup PDD List:	
Consistent of the second	Size         Type         Flags           0         192         MbxDut           1         192         MbxIn           2         0         Outputs           3         4         Inputs	Index Size Name 0x1A00 4.0 TxPD0 Mapping	Fla MF
InfoData     Box 1 (AMT58-13x14-EC)     Strate Contemporation     Strate Contemporation	PD0 Assignment (0x1C13):	PDD Content (0x1A00):	>
← GPI Poston value	₩0×1A00	Index         Size         Offs         Name           0x6004:00         4.0         0.0         Position Value           4.0         4.0         4.0	~ ~
	Download	Load PD0 info from device	
	PD0 Assignment PD0 Configuration	Sync Unit Assignment	
	Messannio		1

Process data objects can be displayed also by pressing the TxPDO Mapping item in the left pane of the TwinCAT System Manager main window; data is listed in the right panel.

🛒 TwinCAT System Manager						
Eile Edit Actions View Options Help						
D 📽 📽 🖬 🚑 D, 🗡 🖻 🖷 !	8 M 8 🔜 📾 🗸	/ 💣 👧 👧 🎨 🖻	😵 🔕 /	EQPE	🍢 🕬 🥔	3
E- 🚮 SYSTEM - Configuration	Name	Online	Туре	Size >Add	r In/Out	User
PLC - Configuration I/O - Configuration I/O - Configuration Device 1 (EtherCAT) Evice 1 - Image Device 1 - Image Evice 1 - Image Evi	♦ Position Value	0x0000000 (0)	UDINT	4.0 26.0	Input	0
< >	<					>
Ready			Lo	ocal (169.254.196.13	4.1.1) Config	Mode

## **COLATACO**

#### 5.4 COE Object Dictionary

In the left pane of the TwinCAT System Manager main window press the Box (AMT58-ECAT) item: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the CoE -Online page. In this page the objects dictionary is shown.

Edit Actions View Options Help								
) 🖆 🖬 🐻 🖪 🖌 🛍 🖻	a a a 💷	🙃 🗸 🎯 🙊 💩 🖏 🖄	< 💰 🍫 🛙		P 66 🔍	S ¹⁰		2
SYSTEM - Configuration PLC - Configuration I/O - Configuration I/O - Evvices I - Covices Devices 1 (EtherCAT)	General EtherCA Update L Advanced	T DC Process Data Sta ist Auto Update	rtup CoE - Onlin	e Online	9			
Device 1-Image	Index	Name	Flag	e	Value		~	
🖅 😫 Inputs	1000	Device tupe	M Pr	° 1	1 diac			
E al Outputs	1000	Device type	PO	,				
🕀 😫 InfoData	1009	Hardware version	BO					
B- Box 1 (AMT58-13v14-FC)	1003	Software version	BO					
ATTYPDO Mapping	F 10180	Identitu	MB	1				
At Position Value	H-1400-0	TyPD0 Mapping	BO					
	E 10000	Sunc Manager Communication	Tune M Bí	1				
E S InfoData	F 10120	BxPDD assign	BW	1				
	E 10130	TxPD0 assign	BW					
	F 1C330	SM input parameter	BO					
	6000	Operating Parameters	BW					
	6001	Units per revolution	BW					
	6002	Total Measuring Range	BW					
	6003	Preset	BW					
	6004	Position Value	RO F	<b>,</b>			~	
	<				and the second	>		
	Name	Online	Туре	Size	>Addr	In/Out	User.	
	♦ Position Value	0×00000000 (0)	UDINT	4.0	26.0	Input	0	
	♦ WcState	1	BOOL	0.1	1522.0	Input	0	
	<b>♦</b> † State	0x0002 (2)	UINT	2.0	1548.0	Input	0	
	AdsAddr	A9 FE C4 86 02 01	AMSADDRESS	8.0	1550.0	Input	0	
	A netId	A9 FE C4 86 02 01	ARRAY [0	6.0	1550.0	Input	0	
	At 17 1501	0.10(1(0)	1.10778.177		1550.0			

Objects can be read directly from the encoder; to do this click the Advanced... button: the Advanced Settings window will appear.

Dictionary	Dictionary
- Backup	<ul> <li>Online - via SDO Information</li> <li>All Objects Mappable Objects (RxPDO) Mappable Objects (TxPDO) Backup Objects Settings Objects</li> </ul>
	O Offline - from Device Description O Offline - via EDS File Browse

Select the Dictionary item in the left pane and then choose the Online - via SDO Information option in the Dictionary page; press OK button to confirm.

#### 5.5 Online Data

In the left pane of the TwinCAT System Manager main window press the Box (AMT58-ECAT) item: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the Online page to check the encoder status.

🥦 TwinCAT System Manager								×
Eile Edit Actions Yiew Options Help								
D 🖨 📽 🖬 🍜 🖪 🐇 🐚 🕄 Į	a 🗛 a 📃	💼 🗸 🏄 👧 👲 💱	× 🕲 🍫 🗉		8 66 🔦	Q ¹⁰	1	8
<ul> <li>SYSTEM - Configuration</li> <li>PLC - Configuration</li> <li>J/O - Configuration</li> <li>J/O Devices</li> <li>Device 1 (EtherCAT)</li> <li>Device 1 - Image</li> <li>Device 1 - Im</li></ul>	General Ether State Machin Init Pre-Op Op DLL Status- Port A: Port B: Port D:	CAT DC Process Data St Pe Bootstrap C Safe-Dp R Clear Error R Carrier / Open No Carrier / Closed No Carrier / Closed	aitup CoE - Onlin urrent State: equested State:	e Online PREOF PREOF	2			
1	Name	Online	Туре	Size	>Addr	In/Out	User.	^
	<ul> <li>♦↑ Position Value</li> <li>♦↑ WcState</li> <li>♦↑ State</li> <li>♦↑ AdsAddr</li> </ul>	0x00000000 (0) 1 0x0002 (2) A9 FE C4 86 02 01	UDINT BOOL UINT AMSADDRESS	4.0 0.1 2.0 8.0	26.0 1522.0 1548.0 1550.0	Input Input Input Input	0 0 0	*
<	<				1		>	
Ready			Loca	l (169.254.	196.134.1.	1) Config	g Mode	-

To display the encoder process data in real time, click the Safe-OP button if you want to display inputs only; click the OP button if you want to display both inputs and outputs.



#### WARNING

The structure of Data Objects (PDO and SDO) requires bytes to be sent from the Least Significant Byte (LSB) to the Most Significant Byte (MSB).

On the contrary in TwinCAT write and read data from MSB to LSB. Furthermore in TwinCAT also strings must be entered in the reverse order:

- read default values: Data byte = 64 61 6F 6Chex = "daol" in ASCII code (means "load" in reverse);
- save parameters: Data byte = 65 76 61 73hex = "evas" in ASCII code (means "save" in reverse).

## **COLATACO**

#### 5.6 EEProm upgrade



#### WARNING

The EEProm upgrade process has to be accomplished by skilled and competent personnel. If the upgrade is not performed according to the instructions provided or a wrong or incompatible EEProm program is installed then the unit may not be updated correctly, in some cases preventing the unit from working.



#### WARNING

The XML file version, the firmware version and the EEProm version must always comply. For example: if the firmware version is H1_S4 (Hardware version: 1; <u>Software version: 4</u>), it is mandatory that the EEProm version is <u>S4</u>, therefore you must then install the XML file version <u>V4</u>.



#### WARNING

It is mandatory that in an EtherCAT network all devices are provided with the same version of the firmware, EEProm and XML file. So when you need to replace an old encoder installed in your network, then you must either upgrade all the encoders in the network to the last version compatible with the new encoder; or you must downgrade the new encoder to the older version compatible with the encoders already installed in the network.

1. In the left pane of the TwinCAT System Manager main window press the Box (AMT58-ECAT) item of the encoder you need to update: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the EtherCAT page.

🥦 TwinCAT System Manager									
File Modifica Azioni Visualizza Opzioni Aiuto									
	M 8 🔜 📾 🗸	# @ @ & ** ×	C & E	Q 02 60	r • •	0	8		
B: B: Configurations (STEM) B: Configurations PLC B: Configurations (JO B: Configuratio	Generale EtherCAT Tipo: Product/Revision: Auto Inc Addr: EtherCAT Addr: IT Previous Port:	In lines	N	fvanced Settin	ga				
	Nome	Onine	Tipo	Gran	>Indiri	Entra	User ID	Collegato a	
*[	Vistate	0x0011(17)	UDAT	2.0	1548.0	ingre	0		
Server (porta) Timestamp	Messaggio								
(65535)         16/03/2012 11.59.05 812 ms           (65535)         16/03/2012 11.59.05 812 ms           (65535)         16/03/2012 11.59.05 546 ms           (65535)         16/03/2012 11.59.05 546 ms           (65535)         16/03/2012 11.59.05 546 ms	Box 1 (PFFFFFFFF RFF Box 1 (PFFFFFFFF RFF Box 1 (PFFFFFFFF RFF Box 1 (PFFFFFFFF RFF	FFFFFF (1001): state ch FFFFFF (1001): INIT to F FFFFFF (1001): state ch SECCE (1001): 'BUT to F	ange aborted (rec REOP' failed! Erro ange aborted (rec angent! follow! Erro	uested PREO or: 'check devi wested 'PREO	P', back to 'I ce state for P', back to 'I	INIT'). PREOP', A DIIT').	L Status V	0x0011' read and '0x000	l' expected. AL S
kprontato							Local	(169.254.196.134.1.1)	Config Mode

 Press the Advanced Settings... button; the Advanced Settings page will appear; in the directory tree on the left expand the ESC Access directory, then expand the E2PROM directory, finally select the HEX Editor item.



 Press the Read from File... button and select the .BIN file provided to upgrade the EEProm; please make sure you select the file of your own model you need to upgrade (for example: if you have to upgrade an <u>H- series multiturn</u> <u>encoder</u> then you must select the file <u>AMT58_EC_eeprom_Hx_Sy.bin</u>); finally press the Open button.





#### NOTE

In the .BIN file Hx is the hardware version of the encoder, while Sy is the software version.

4. Move back to the previous Advanced Settings page and press the Download button. Now wait until the EEProm writing process is carried out. The progress bar below in the page displays the progress of the operation. As soon as the process is completed press the OK button.

Configurazione SYSTEM	Generale BherCAT In linea
Configurazi Advanced Settings	X
B     General       B     General       B     General       B     File       B <th>Hex Editor           0000 05 0C 03 0C 00 04 00 00 00 04 00 00 00 00 00 00 00</th>	Hex Editor           0000 05 0C 03 0C 00 04 00 00 00 04 00 00 00 00 00 00 00
	Upload Write to File
(porta)	OK Annula
535) 16/03/2012 11.59.05 812 ms 535) 16/03/2012 11.59.05 812 ms	Box 1 (PFFFFFFF RFFFFFFF (1001): state change aborted (requested 'PREOP', back to 'INIT'). Box 1 (PFFFFFFF RFFFFFF (1001): 'INIT to PREOP' failed Error: 'check device state for PREOP', AL Status '0x0011' read and '0x0002' exp

5. Now turn power off, then on again.

 In the left pane of the TwinCAT System Manager main window delete all the Box (AMT58-ECAT) items in the list. Select each box and then press the DEL key in the PC keyboard. Press OK to confirm.



 In the left pane of the TwinCAT System Manager main window select and right-click the Device 1 (EtherCAT) item; press the Scan Boxes... command in the menu.

📑 TwinCAT System	m Manager									
File Modifica Azioni Visual	lizza Opzioni Aiuto									
	X BB BB	44 8 🔜 📾	1 1 9 9	S 🔨 🛞 🎢 🔒	Q 02 66 9	v 🔊 🧶 🛛 🖇				
Configurazione SYSTEM Configurazione PLC Configurazione I/O Configurazione I/O		Generale Adap	ter   EtherCAT   In line  Dispositivo 1 (EtherC	a   CoE - Online   AT)	ld:	1				1
E 🗯 Dispositivo 1 (Ethe	- Andundi hox	· -	CAT							
Dispositivo 1-1	Cancella <u>d</u> ispositi	vo				*				
B-QL Uscite B-QL Uscite InfoData Assegnazioni	<ul> <li>Ripristino in linea</li> <li>Online Reload (Co Online Delete (Co</li> </ul>	onfig Mode only) onfig Mode only)				±				
	😭 Esporta dispositiv	/0	sabled		Crea	a simboli 🗖				
	Properta box									
	📉 Scan Boxes									
	<ul> <li>✗ Iagliare</li> <li>♀ Copia</li> <li>♀ Insenso</li> <li>♀ Insenso con colle</li> </ul>	Ctrl- Ctrl- Ctrl- gamento Alt+Ctrl-	+X +C +V							
	1 Modifica ID									
	× Disabled									
	Cambia in		•							
	Change NetId	<u>.</u>								
		Numero	Nome box	Online	Indirizzo	Тіро	Grande	Grande	E-Bus (mA)	Collega
•		4	- Y	19		*	· · · · · ·		]	•
Server (porta) Timestam	qr	Messaggio								*
(65535) 16/03/20	12 13.25.55 734 ms	'Box 1 (AMT58-13:	x14-EC)' (1002): state	change to 'PREOP' finish	ed					
(65535) 16/03/20 (65535) 16/03/20	12 13.25.55 656 ms	Box 1 (AMT58-13)	x14-EC) (1002): abno	rmai state change (from i	PREOP to INIT ).	Try to go back to PRi	EOP'			
(65535) 16/03/20	112 11.59.05.812 ms	IDAN 1 (PEPEPEPE	NEEDEEEEE! (1001): SI	are change aported (requ	resied PREUP', b	ack to INIT ).	hable '0+0011' e	nad and !Ou	1000' evector	·
Approntato							Local (169.254	. 196. 134. 1.	1) Config	Mode

### **OIDOJATACO**

8. At the end of the scanning process all the devices available in the network are listed as shown in the Figure here below.

📕 TwinCAT System Manager						
File Modifica Azioni Visualizza Opzioni Aiuto						
0 📽 🖬 🖉 🗛 🗴 🖻 📾 🚮	a e 🔜 💼	1 1 1 2 2 2 2 2 3	S & EQ P	60 % 🕵 🛷 😰 😵		
Configuratione PLC     ConfigurationePLC     Configuratione PLC     Configuratione PL	Generale Ada Nome: Tipo: Commerco:	ter   EtherCAT   In linea   CoE  Dispositivo 1 (EtherCAT)  EtherCAT	(♥)   ♥   ♥   4 02	ido" (* 1	<u> </u>	
Server (porta) (65535) 16(03/2012 13.25.55 734 ms (65535) 16(03/2012 13.25.55 656 ms (65535) 16(03/2012 13.25.55 656 ms (65535) 16(03/2012 13.25.05 852 ms (65535) 16(03/2012 13.25.05 852 ms	Numero 1 Messaggio Box 1 (AMT58-13 Box 1 (AMT58-13 Box 1 (PEREEEE	Nome box Box 1 (AMT58-13 x14-EC) x14-EC)' (1002): state change x14-EC/' (1002): state change s14+EC/' (1002): state change s14+EC/' (1001): state s14+EC/' (1001): s14+EC/'	Online Int 10 to 'PREOP' finished te change (from 'PREOP' to ge aborted (requested 'Pr PEOP' fulled) Europa (shorts)	Strizzo Topo DI AMT58-13x14-EC VIIIT), Try to go back to PRE EEOP/ back to TNIT). Hecory, back to TNIT).	Grande Grande. 4.0 :00 ²	
Approntato				ſ	Local (169.254.196.134.	1.1) Config Mode

#### 5.7 Firmware upgrade



#### WARNING

Firmware upgrade process has to be accomplished by skilled and competent personnel. If the upgrade is not performed according to the instructions provided or a wrong or incompatible firmware program is installed then the unit may not be updated correctly, in some cases preventing the unit from working.



#### WARNING

The XML file version, the firmware version and the EEProm version must always comply. For example: if the firmware version is H1_S4 (Hardware version: 1; Software version: 4), it is mandatory that the EEProm version is S4, therefore you must then install the XML file version V4.



#### WARNING

It is mandatory that in an EtherCAT network all devices are provided with the same version of the firmware, EEProm and XML file. So when you need to replace an old encoder installed in your network, then you must either upgrade all the encoders in the network to the last version compatible with the new encoder; or you must downgrade the new encoder to the older version compatible with the encoders already installed in the network.

Firmware is a software program which controls the functions and operation of a device; the firmware program, sometimes referred to as "user program", is stored in the flash memory integrated inside the unit. Datalogic encoders are designed so that the firmware can be easily updated by the user himself. This allows Datalogic Automation s.r.l. to make new improved firmware programs available during the lifetime of the product.

Typical reasons for the release of new firmware programs are the necessity to make corrections, improve and even add new functionalities to the device.

The firmware upgrading program consists of a single file having .EFW extension. It is downloadable from the web or released by Datalogic Automation s.r.l.

WARNING

You must upgrade the EEProm before upgrading the firmware.



## **COLATACO**

1. In the left pane of the TwinCAT System Manager main window press the Box (AMT58-ECAT) item of the encoder you need to update: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the Online page.

📕 TwinCAT System Manager										×
File Modifica Azioni Visualizza Opzioni Aiuto										
D 📽 📽 🖬   🍜 🖪   X 🖻 🖻 🎒	M Ə 🔜 📾 🗸 🏼	r 👧 🧕 🎨 🔨	🔕 🗞 🖹 C	L 02 6	6 🔦 💇	🧶 😨	8			
Configuratione F/STEM     Configuratione P/C     Configuratione P/C     Depositive 1 (EtherCAT)     P Depositive 1 (EtherCAT)     P Oppositive 1 (Ethe	Generale EtherCAT D State Machine Int Pre-Op Op DLL Status Port A: Carrier Port B: Carrier Port D: Nio Car File Access over Ethe Download	C Process Data Bootstrap Safe-Op Cear Error /Open /Open /Open ter / Oosed ter / Closed CAT Uploed	Avvio CoE - Oni Current State: Requested State:	ne in Ine	a   P					
	Nome	Online	Tipo	Gran	>Indiri	Entra	User ID	Collegato a		
	Position Value	0x00000000 (0)	UDINT	4.0	39.0	Ingre	0	n	10-	
	V WcState	1	BOOL	0.1	1522.1	Ingre	0			-
Server (porta) Timestamp	Messaggio									*
(65535) 16/03/2012 13.25.55 734 ms	'Box 1 (AMT58-13x14-EC)	(1002): state change	to 'PREOP' finished	1						
(65535) 16/03/2012 13.25.55 656 ms	Box 1 (AMT58-13x14-EC)	(1002): abnormal sta	te change (from 'PP	EOP' to 'IN	IT'). Try to g	go back to	PREOP'			
(65535) 16/03/2012 11.59.05 812 ms	BOX 1 (PFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	FFF (1001): state char	nge aborted (reque	sted PREO	P, back to 1	INIT).				-
4 16.02/0013 11 ED.0E.013 mm	Way & MELECEEE DECCC	HER FIGULE THET IN D	nurtin testadi. Erran	televele della		onentr A	Contraction (1)	NUO' has been 'n NUO	T superiod	•
Approntato							Loca	169,254,196,134,1,1	) Config Mo	de

2. Press the Bootstrap button in the State Machine box; in the BOOT state the encoder is ready to accept the firmware upgrade download process (the BOOT message appears next to the Current State item in the same box).

📴 TwinCAT System Manager										×
D 📽 📽 🖶 🎯 🖪   X 🖻 📾 🔒	h ð 🔜 📾 🗸	# @ @ & * *	🛞 🍫 🖹	Q 02 60	· • 5 ¹⁰	۵	8			
Configuratione SYSTEM     Configuratione SYSTEM     Configuratione SUC     Configurat	Generale BherCAT State Machine Int Pre-Op Op DLL Status Port A: Car Port B: Car Port D: Tile Port D: Tile Download	DC Process Data	Avvio CoE - C Current State: Requested State	Inine In Ineu						
<u>د</u>	Nome Position Value VcState	Online 0x00000000 (0) 1	Tipo UDINT BOOL	Gran 4.0 0.1	>Indiri 39.0 1522.1	Entra Ingre Ingre	User ID 0 0	Collegato a		4
Server (porta)         Timestamp                •             •	Messaggio 'Box 1 (AMT58-13x14- 'Box 1 (AMT58-13x14- 'Box 1 (PFFFFFFF RFF 'Box 1 (PEFEFFFFF RFF 'Box 1 (DEEEEEEE DEE	EC.)' (1002): state chang EC.)' (1002): abnormal st FFFFF' (1001): state cha	e to 'PREOP' finis ate change (from nge aborted (requ NEON' failed) Erro	hed 'PREOP' to 'II Jested 'PREOP er 'deorfe deorf	VIT'). Try to 2°, back to 'I	go back to NIT').	PREOP'	with the set and 'DuDi	103' avected a	- - -

3. Now press the Download... button in the File Access Over EtherCAT box; in the Open window that appears select the

.EFW file provided to upgrade the firmware; please make sure you select the file of your own model you need to upgrade (for example: if you have to upgrade an <u>H- series multiturn</u> <u>encoder</u> then you must select the file **ECATFW_AMT58_Hx_Sy.efw**; finally press the Open button.

Apri						? ×
Cerca in:	FirmWare		•	000	···· <del>·</del>	
Pecent	ECATFW_4	19758_13x14_H1_S4.efw				
Desktop						
Documenti						
Risorse del computer						
Risorse di rete	Nome file:	ECATFW_AMT58_13	x14_H1_S4.	əfw	•	Apri
	Tipo file:	EtherCAT Firmware Fi	es (*.efw)			Annulla



NOTE

In the .EFW file Hx is the hardware version of the encoder, while Sy is the software version.

4. In the Edit FoE Name page that appears on the screen enter the password 0x0000000 next to the Password (hex) item below in the page and then press the OK button to confirm. Now wait until the firmware file saving process is carried out. The progress bar below in the page displays the progress of the operation.

Edit FoE Name		
String:	ECATFW_AMT58_13x14_H1_S4	ОК
Esad.	45 43 41 54 46 57 5F 41 4D 54 35 38 5F 31 33	Annulla
Lunghezza:	24	
Password (hex):	00000000	

## **COLATACO**

5. To check whether the firmware upgrade procedure has been completed successfully enter the Online page in the TwinCAT System Manager main window and press the Pre-Op button in the State Machine box; if everything is ok, the encoder enters the PREOPERATIONAL state (the PREOP message appears next to the Current State item in the same box).

📴 TwinCAT System Manager										
File Modifica Azioni Visualizza Opzioni Aiuto										
D 📽 📽 🔛   🖂 🖪   X 🖻 🖻 🚮	# 8 🔜 📾 🗸 🕯	🖉 🙆 🧶 🐏 🔨	🛞 🚱 🖹 (	2 02 60	r 💁 🕵	🧶 😨	?			
Configuratione SYSTEM     Configuratione PLC     Configuratione PLC     Depositive 1 (D     Depositive 1 - Immagine d processo     Depositive 1 - Immagine d processo     Depositive 1 - Immagine d processo     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D     D	Generale BherCAT State Machine Int Pre-Op Op DLL Status Port A: Came Port B: Came Port B: Came Port D: No Ce Port D: No Ce Port D: No Ce	DC Process Data Bootstrap Safe-Op Cear Error 7/Open refer / Open refer	Avvic CoE-Or Current State: Requested State:	Ine In Ine	<ul> <li></li></ul>					
	Nome	Online	Tipo	Gran	>Indiri	Entra	User ID	Collegato a		
and the second	Of Position Value	0x00000000 (0)	UDINT	4.0	39.0	Ingre	0			-
	<b>♥</b> TWcState	1	BOOL	0.1	1522.1	Ingre	0			•
Server (porta) Timestamp	Messaggio	1/ (1007): state change	to 'DDEOD' finishe	4						-
(65535) 16/03/2012 13.25.55 656 ms	Box 1 (AMT58-13X14-EC	(1002): state change (1002): abnormal sta	te change (from 'P	REOP' to 'IN	T). Try to (	to back to 1	PREOP			-
(65535) 16/03/2012 11.59.05 812 ms	Box 1 (PFFFFFFFF RFFFF	FFFF' (1001): state cha	nge aborted (requ	ested 'PREO	P', back to 'I	NIT').				1
(45575) 16/07/2012 11 50 05 912 mm	'Des + /necesses neces	CECE' /10011. 'TAITT to D	nEON' failed! Error	telsente elevis		nn=00' 4	6+++ 10	v00111 cood and 10v	1007' ovported	AL 6
Approntato					_		Local (	169.254.196.134.1.	1) Config M	Mode

## 6 - EtherCAT® interface

#### 6.1 Basic Information on EtherCAT® Protocol

EtherCAT protocol is designed to use the standard Ethernet dataframes for issuing data; in addition, and as regards the hardware, it is not necessary to install dedicated Masters for establishing and managing the EtherCAT communication because standard Ethernet network cards can be used. This results in an advantage in terms of lower costs and simplicity of use because Ethernet network cards are used in standard personal computers and are easily commercially available.

An EtherCAT bus can be viewed as a single and large Ethernet device that receives and sends Ethernet telegrams; it can be considered an Ethernet subnet supported by an Ethernet dataframes structure.

However this "subnet" must be fitted with one only EtherCAT Master controller and several EtherCAT Slaves, but no Ethernet controller with downstream microprocessor must be present.

* add 1-32 padding bytes if Ethernet frame is shorter than

Here follows an Ethernet frame structure with EtherCAT:



Inside the Ethernet frames data are transmitted among Master and Slaves using PDO (process data objects) protocol. Each PDO message has inside one or more addresses for issuing data to Slaves; data + address/es (and additional elements such as a validation checksum) joined together forms an EtherCAT telegram (Datagram).An EtherCAT frame can contain several telegrams and often a complete control cycle requires more than one frame.

#### 6.1.1 Data transfer

Usually, in a data bus system, Master controller sends online a data request and then waits for data to be processed and sent back from each Slave node; this does not comply with a real-time system because Master receives data from Slaves in different moments and the whole system cannot be synchronized.

In EtherCAT the real-time characteristic of the system is quite improved because data are processed "on-the-fly", using one single frame to acquire all data from all Slaves.

In fact the frame sent by the Master is read by each Slave node data is addressed to while the telegram passes through the device; similarly, input data is inserted while the telegram passes through. Then the telegram is forwarded to the next device. Telegrams are only delayed by a few nanoseconds.

The last Slave issues back the complete frame to the Master with all the requested data (again passing through all the Slaves).



This efficient data flow is guaranteed by the 100BASE-TX full-duplex structure of EtherCAT bus which is fitted with two separated lines for transmitting and receiving data.

Moreover the protocols exchange takes place inside the hardware and it is thus independent from CPU and software processing.

#### 6.1.2 ISO/OSI Layer model



* "empty" means that the layer behaviour exists, but is not shown explicitly.

6.1.3 Topology

Several topologies of connection are supported by EtherCAT networks: line, tree, daisy-chain, star, ...). Furthermore EtherCAT networks can be configured in almost any topology in the same structure. The maximum length of the cable between two Slaves is 100 m; standard EtherCAT cables commercially available can be used.

The choice of the topology depends on the structural characteristics of the plant and it is made in order to reduce the complexity and time for cabling.

Inside an EtherCAT network up to 65535 devices can be connected. Some topology examples are shown in the Figures below:

LINE topology:



TREE topology:



DAISY CHAIN with drop lines topology:



#### 6.1.4 Line Termination

EtherCAT network needs no line termination because the line is terminated automatically; in fact every Slave is able to detect the presence of downstream Slaves.

An EtherCAT Slave is able to detect the presence of the signal in the outgoing line (Port 0) or in the return line (Port 1).

If the Slave is not able to detect the signal in its return line then it closes the communication ring by short-circuiting the TX signal of its outgoing line with the RX signal of its return line; in this way a telegram received through the outgoing line is processed and sent back through the TX of the return line.

The Slave sends a "carrier signal" or a telegram on TX of the outgoing line continuously and, once the next Slave is connected again, a signal on RX of the return line is detected again; so the short circuit is removed and the telegrams are sent on TX of the outgoing line.



#### 6.1.5 Addressing

It is not necessary to assign a physical address to the device (for instance using a dip-switch) because the addressing of the Slave is automatic at power on during the initial scanning of hardware configuration.

8 Bit	8 Bit	32	Bit	11 Bit	2	1	1	1	16 Bit
Cmd	ldx	Add	ress	Len	R	С	R	Μ	IRQ
		16 Bit	16 Bit						
APxx		Position	Offset	+ Auto	Ind	ore	me	ent	Addressing
	1	1		(Position addressing)					
FPxx		Address	Offset	+ Fixe	d P	hy	sic	al A	Addressing
				(Node	ado	Ires	sing	g)	
Lxx		Logical	Address	✓ Logical Addressing					

The field for addressing is 32 bits long; there are three kinds of addressing:

- Auto Increment Addressing = Position Addressing: 16 bits indicates the physical position of the Slave inside the network while 16 bits are scheduled for local memory addressing; when the Slave receives the frame then it increments the position address and the Slave receiving address 0 is the addressed device;
- Fixed Addressing = 16 bits indicates the physical address of the Slave inside the network while 16 bits are scheduled for addressing the local memory;
- Logical Address = the Slave is not provided with its own individual address, but it can read and write data in a section of the total memory space available (4 Gigabytes).

#### 6.1.6 Communication mode

Datalogic encoders with EtherCAT interface support the following operating modes:

- FreeRun: asynchronous mode;
- SM3 event: synchronous mode;
- DC: distributed clock synchronization mode (synchronous mode).

For a system that requires high performances in real time (closedloop applications) we suggest using DC mode; if real time requirements are not so mandatory SM3 or Freerun modes can be used instead.

A reference parameter is the "Jitter": it represents the temporal fluctuation of the instant data sampling; in other words data sampled by the micro-controller is available in ECAT DPRAM memory after a certain time and the measure of the variability over time is the "jitter".

#### FreeRun

Asynchronous mode; encoder position is sampled directly from EtherCAT frame sent by the Master; position update is performed by an internal timer of the controller every 100 microseconds.



This operating mode has a high sampling jitter (up to 100 microseconds) and can be chosen only when cycle times are quite longer than the jitter if we want to ensure a sufficient real-time system performance.



Description	Min	Тур	Max	
Jitter	0		100	µsec
Cycle Time	1000		64000	µsec

Synchronous with SM3

In this mode data is sampled and then copied into Sync Manager buffer as soon as previous data was read from the Master (SM event); in this way new sampled data is synchronous with Master readings.



New data will be read by the Master at next cycle (following SM3 event), so if cycle time is too long, data could be relatively old for a real-time system.

The main advantage is that data is updated exactly when Master is reading (synchronous mode).

Description	Min	Тур	Max	
Jitter	0		7,2	µsec
Cycle Time	62,5		64000	µsec

Synchronous with DC SYNC0

In this operating mode data is sampled and then copied into Sync Manager buffer simultaneously at SYNC0 event generated by the ESC capture/compare unit.

Time required for accomplishing these operations is set in object **1C33 Sync Manager input parameter**; in particular object **03 Shift Time** (1C33hex, sub3) and object **06 Calc and Copy time** (1C33hex, sub6).



In this operating mode "Jitter" is a fundamental parameter in the sampling of two consecutive data. The main advantage of this mode is that there is a direct relation between the sampling instant and the absolute time of the system; in this way, if we know the shift times of the Slaves, we can have an exact image of the system at a given moment (with a tolerance equal to jitter).

Description	Min	Тур	Max	
Jitter	0	100	200	µsec
Cycle Time	62,5		64000	µsec

#### 6.1.7 EtherCAT State Machine (ESM)



EtherCAT Slave is a state machine; communication and operating characteristics depend on the current state of the device:

 INIT: it is the default state after power on; in this state there is not direct communication between Master and Slave on the Application Layer; some configuration registers are initialized and the Sync Managers are configured;PRE-OPERATIONAL: in this state mailbox is active; both Master and Slave can use the mailbox and its protocols for exchanging specific initialization parameters of the application. Exchange of Process Data (PDO) is forbidden;SAFE-OPERATIONAL: in this state Master and Slave can issue only input process data, while output process data are still in SAFE-OPERATIONAL state;OPERATIONAL: in this state Master and Slave are enabled to send both input process data and output process data. 6.1.8 Slave configuration

The configuration of the Slave communication characteristics (Sync Manager configuration, addresses, synchronization modes, PDO mapping, ...) can be made both using the XML file (EtherCat Slave Information - ESI) or loading data directly from EEPROM (Slave Information Interface SII).

EEPROM content (SII):

Byte										
16	EtherCAT Slave Controller Configuration Area									
22	Vendorld	ProductCode	RevisionNo	SerialNo						
32	Hardware Delays	•	Bootstrap Ma	ailbox Config						
48	Mailbox Syne	c Man Config								
		Rese	erved							
128	Additional Information (Subdivided in Categories)									
		Categor	y Strings							
		Category	Generals							
		Category FMMU								
		Category Sy	/ncManager							
		Category Tx- / RxF	PDO for each PDO							

6.1.9 Timing and Synchronization

The main feature of EtherCAT is its almost ideal representation of a real-time system.

Hence the Master has to synchronize all the Slaves at the same time in order to build a system where all nodes have the same reference time; this goal can be achieved by using "distributed clocks".

Master downloads its clock into one of the salves (customarily the first Slave) which becomes the reference clock for all the Slaves in the network; so it has the task of synchronizing the other Slaves. Master controller periodically sends a special synchronization-telegram where the reference Slave writes its own "current time". This telegram is then sent to all the other Slaves that, in this way, provide for a new re-synchronization of their own clock in order to avoid possible drifts.

This synchronization of the reference time is very important in order to have a snapshot of the system and accordingly to take simultaneous actions in high sensitive applications such as the coordination in axis control operations.

Besides, EtherCAT Slave Controller (ESC) is fitted with a capture/compare unit that provides accurate synchronization signals (SYNC0 or interrupts): they are sent to the local micro-controller so that it is able to synchronize its own clock to Slaves clock.

#### Sync Manager

Sync Manager has the task of synchronizing data transfer between Master and Slave and prevents the same memory area from being written by different events.

There are two synchronization modes:

- 3-Buffer Mode;
- 1-Buffer Mode.

Synchronisation mode is initialized through the XML file or by loading data directly from EEPROM (SII).

#### Buffered Mode (3-Buffer Mode)

In this mode new data can be accessed at any time by both Master EtherCAT and ESC controllers; no timing restrictions are imposed.

Three buffers are necessary (three consecutive memory areas); one buffer is always available to ESC controller for writing and one buffer always contains updated data to be read by the Master.

Customarily this is used for process data communication.

#### Mailbox Mode (1-Buffer Mode)

In this mode a "handshake" between Master and Slave must be used; in fact one only memory buffer is available to both Master and Slave for writing and reading; the Master (or the Slave) is enabled to write only when the buffer is empty, that is when the Slave (or the Master) has finished reading the data buffer. And vice versa: the Master (or the Slave) is enabled to read only when the buffer is empty, that is when the Slave (or the Master) has finished writing the data buffer. 6.2 CANopen Over EtherCAT (CoE)

Datalogic encoders are Slave devices and support "CanOpen Over EtherCAT" (COE) mode for data transfer. In particular, they support the "Device profile for encoders", Class 2.

For any omitted specification on CANopen® protocoll, please refer to "CiA Draft Standard 301" and "CiA Draft Standard 406" documents available at the address www.can-cia.org.

For any omitted specification on EtherCAT® protocoll, please refer to "ETG.1000 EtherCAT Specification" document available at the address www.ethercat.org.

#### 6.2.1 XML file

EtherCAT® encoders are supplied with their own XML file **AMT58xxx-13x14-EC** (see at www.datalogic.com). At the same address you can also download the most recent files to update both the firmware and the EEProm of the encoder. For older versions of the files please contact Datalogic Automation s.r.l. After Sales Service Dept. For any information on the firmware upgrade procedure refer to the section "5.7 Firmware upgrade" on page 21. For any information on the EEProm upgrade procedure refer to the section "5.6 EEProm upgrade" on page 26). XML file has to be installed on EtherCAT® Master device.



#### WARNING

Before installing the XML file please check that it is compatible with the firmware version and the EEProm version of the device; the XML file version, the firmware version and the EEProm version must always comply. For example: if the firmware version is H1_S4 (Hardware version: 1; Software version: 4), it is mandatory that the EEProm version is S4, therefore you must then install the XML file version V4.



#### WARNING

It is mandatory that in an EtherCAT network all devices are provided with the same version of the firmware, EEProm and XML file. So when you need to replace an old encoder installed in your network, then you must either upgrade all the encoders in the network to the last version compatible with the new encoder; or you must downgrade the new encoder to the older version compatible with the encoders already installed in the network.

#### **AMT58x-EC EtherCAT®**

#### **CIDOJATAC**

If you want to know the firmware version of a device, press the Box (AMT58-ECAT): item in the left pane of the TwinCAT System Manager main window: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the CoE - Online page and refer to the indexes Hardware version and Software version.

🥦 TwinCAT System Manager									
File Modifica Azioni Visualizza Opzioni Aiuto									
D 📽 📽 🖬   🖨 🔃   X 🐚 🛍 🝰	M ð 🔳 💼	/ 谢 🙊 👧 🗞 🔨 🛞			66° 🍢 💇	۱ 🌭	8		
표·🐼 Configurazione SYSTEM			CoE Onlin	a luis	1				
Configurazione NC	Generale   Etheru	AT DC Process Data AV	10 COL - Or III	o I in in	<b>P</b> 1				1
Configurazione PLC	Annioma el		IT Carle Incore			-			
Configurazione eccentrico	Aggiorna er	Auto Opdate	I♥ Single Upda	te i Sr	now Omine Da	ta			
E-W Configurazione I/O	Avanzato	All Objects							
E-B Dispositivi I/O	A 111 01		Module (		Port): D	_			
Dispositivo 1 (EtherCAT)	Add to Star	Unine Data	Modulo	DD (HOL	r ony. Ju				
Dispositivo 1-Immagine di proces	Index	Nama	Dam		Valana			1	
Dispositivo 1-Immagine di proces	1000	Device here	Fiegs		0-0001010c	(05040)			<u></u>
🗈 😽 Ingressi	1000	Device name	BO	-	000010156	(00042) I-EC			
E- St Uscite	1009	Hardware version	BO		H01	- 10			
H InfoData	100A	Software version	BO		\$04	)			
+ e Box 1 (AMIT 58-13 x14-EC)	1010:0	Store parameters	RO		>15				
Assegnazioni		Treatment default parameters	00	-	>1<				
	±-1018:0	Identity	RO		>4 <				
	± 1A00:0	TxPDO Mapping	RO		>1<				
		Sync Manager Communication	Type RO		>4 <				
	+ 1C12:0	RxPDO assign	RW		>0<				
	±-1013:0	TxPDO assign	RW		>1<				
	± 10330	Sivi input parameter	HU		>6<				
	6000	Onegating Parameters	PW		> 2 C				
	6000	Upite per revolution	RW/		0x00000(0)	(65536)			
	6002	Total Measuring Bange	RW		0x40000000	(1073741824	0		
	6003	Preset	RW		0x00000000	(0)	·/		
	6004	Position Value	RO F	>	0x00007E43	(32323)			
	6500	Operating Status	RO		0x0000 (0)				
	6501	Single Turn Resolution	RO		0x00010000	(65536)			
	6502	Number of Revolutions	RO		0x00004000	(16384)			
	6503	From	RO		0x0000 (0)				
	Nome	Online	Tipo	Gran	>Indiri	Entra	User ID	Collegato a	<b>_</b>
	Position Value	0x00000000 (0)	UDINT	4.0	39.0	Ingre	0		
	<b>♦</b> †WcState	1	BOOL	0.1	1522.1	Ingre	0		
	<b>♦</b> † State	0x0002 (2)	UINT	2.0	1548.0	Ingre	0		
	AdsAddr	A9 FE B0 C1 02 01	AMSADDRESS	8.0	1550.0	Ingre	0		
	A netId	A9 FE B0 C1 02 01	ARRAY [0	6.0	1550.0	Ingre	0		
	∩ netId[0]	0xA9 (169)	USINT	1.0	1550.0	Ingre	0		
	• netId[1]	0xFE (254)	USINT	1.0	1551.0	Ingre	0		
- F	♥ netId[2]	UXBU (176)	USINI	1.0	1552.0	Ingre	0		-
Approntato	- Setherini M	100.1010431	- PAIRE		1943.0				

## **COLATACO**

6.2.2 Communication messages

EtherCAT Datagram of CoE mode has the following structure:

Mbx Header	Co	DE Cmd	Cmd specific data	
type = 3	Numb er	res	Тур е	
6 bytes	9 bits	3 bits	3 bits	0 1478 bytes

Mbx Heade	er	= 3	CoE mode
Number service res	= 0 ≠ 0	in case of in case of in case	of SDO messages of PDO messages, it defines the type of
Туре		reserved Emerger SDO red SDO res Transmi Receive Remote Remote SDO info 15 rese	d ncy message quest sponse itted PDO (TxPDO) ed PDO (RxPDO) transmission request of TxPDO transmission request of RxPDO formation erved
Cmd specif	fic dat		messages are the process data e.g.

Cmd specific data PDO messages: are the process data, e.g. position value

SDO messages: standard CANopen frame

Transmit (tx) or receive (rx) "Type" is viewed from Slave.

6.2.3 Process Data Objects (PDO)

PDO messages are used for transmitting or receiving process data in real time; data to be transmitted or received is defined in PDO Mapping and managed by Sync Manager PDO Mapping.

#### 6.2.4 Service Data Objects (SDO)

SDO messages are issued via Mailbox (low priority data); Segmented SDO Service and SDO Complete Access are not supported (transfer of low size data and one sub-index at a time).

#### "CoE Cmd type" = 2 or 3

Structure of "Cmd specific data":

Cmd specific data									
SDO control	Index	Sub index	Data	Data optional					
8 bits	16 bits	8 bits	32 bits	1 1470 bytes					

SDO control standard CANopen SDO Service

Index parameter index

Sub index parameter sub-index

Data parameter value

Data optional optionally, more then 4 bytes of data can be sent in one frame. Full mailbox size usable.

Index and sub-index values are described in the "Object dictionary".

## **OIDOJATACO**

#### 6.2.5 Object dictionary

In the following pages the objects implemented are listed and described as follows:

Index-subindex Object name [data types, attribute]

- Index and sub-index are expressed in hexadecimal notation.
- Attribute:

ro = read only access

rw = read and write access

Unsigned16 data type:

Process data bytes						
byte 4	byte 5					
LSByte	MSByte					

Unsigned32 data type:

Process data bytes								
byte 4 byte 5 byte 6 byte								
LSByte			MSByte					

#### Standard objects

1000-00 Device type

[Unsigned32, ro] Default =0001 0196h= single turn encoder, DS 406 0002 0196h= multi turn encoder, DS 406

#### 1008-00 Manufacturer Device Name

[String, ro] It shows the manufacturer device name, expressed in ASCII code. Default = 454D353878 = "AMT58" = multi turn encoder

1009-00 Hardware version

[String, ro] It shows the hardware version of the device.

#### 100A-00 Software version

[String, ro] It shows the software version of the device.

#### 1010-01 Store parameters

[Unsigned32, rw]

Use this object to save all parameters on the non-volatile memory. Write "save" in ASCII code in the data bytes:

[	Master Encoder										
Cmd specific data											
Cmd	Index Sub				Da	ata					
23	10	10	01	73	61	76	65				

	Encode	er Ma	ster (co	onfirma	tion)			
Cmd specific data								
Cmd	Index		Sub		Data			
60	10	10	01	00	00	00	00	

#### 1011-01 Restore default parameters

[Unsigned32, rw]

This object allows you to restore all parameters to default values. The default parameters are set at the factory by Datalogic Automation engineers to allow the operator to run the device for standard operation in a safe mode. A list of machine data and relevant default parameters preset by Datalogic Automation s.r.l. engineers is available on page 56.

Write "load" in ASCII code in the data bytes:

Master Encoder

Cmd specific data									
Cmd	Inc	lex	Sub	Data					
23	11	10	01	6C	6F	61	64		

	Encoder	Master	(confirmation)	)
--	---------	--------	----------------	---

Cmd specific data							
Cmd	Index		Sub	Data			
60	11	10	01	00	00	00	00



#### NOTE

To save the default values execute the "Store parameters" function (see object **1010-01 Store parameters**). When the power is turned off, parameters not saved are lost.

## **OIDOJATACO**

1018 Identification object

01 Vendor number [Unsigned32, ro] Default = 0000 012Eh 02 Product number [Unsigned32, ro] 03 Revision number [Unsigned32, ro] 04 Serial number [Unsigned32, ro]

#### 1A00-01 PDO mapping parameter

[Unsigned32, rw] This object contains the mapped position value of the encoder according to DS406 device profile. Default = 6004 0020h

#### 1C00 Sync Manager Communication Type

01 SM MailBox Receive (SM0) [Unsigned8, ro] Default = 1 02 SM MailBox Send (SM1) [Unsigned8, ro] Default = 2 03 SM PDO output (SM2) [Unsigned8, ro] Default = 3 04 SM PDO input (SM3) [Unsigned8, ro] Default = 4

#### 1C12-00 Sync Manager RxPDO Assigned

[Unsigned8, ro] This device does not support receive PDO messages. Default = 0

#### 1C13-01 Sync Manager TxPDO Assigned

[Unsigned32, ro] This device uses TxPDO messages to send the position value. Default = 0000 1A00hex 1C33 Sync Manager input parameter

Some sub-indexes of object 1C33hex are calculated dynamically and depend on both the encoder configuration (programmed resolution, counting direction, ...) and the synchronization mode (SM or DC).

01 Sync Type

[Unsigned16, rw]

Default = 1

0: FreeRun; see on page 34;

1: Synchronous with SM3 Event; see on page 36;

2: DC mode synchronous with SYNC0 event; see on page 37.

02 Cycle time

[Unsigned32, ro]

this parameter depends on the Sync Type selected:

if "FreeRun": interval between two position samplings (internal timer);

if "Synchronized with SM3": min. interval between two SM3 events;

if "Synchronized with DC Sync0": Sync0 cycle time.

03 Shift Time

[Unsigned32, ro]

Interval between the synchronization event and the moment of inputs latching from hardware. This parameter is calculated dynamically.

04 Sync modes supported

[Unsigned16, ro]

Default = 7

bit 0: FreeRun (supported)

bit 1: Synchronous with SM3 (supported)

bit 2: Synchronous with DC SYNC0 (supported)

05 Minimum cycle time

[Unsigned32, ro]

Max. duration of the encoder internal cycle time. This parameter is calculated dynamically and depends on the operating parameters and the position value.

06 Calc and Copy time

[Unsigned32, ro]

Time the internal micro-controller (DSP) needs to make calculations on latched optical reading of position and then copy updated data from local memory to ESC memory (Sync Manager) before they are available to EtherCAT. This parameter is calculated dynamically and depends on the operating parameters and the position value. Device profile objects

#### 6000-00 Operating parameters

[Unsigned16, rw]

Bit	Function	bit = 0	bit = 1	
0	Code sequence	CW (clockwise)	CCW (counter clockwise)	
1	not used			
2	Scaling function	disabled	enabled	
3 15	not used			

Default = 0000h

#### Code sequence

This is intended to set if the encoder counting increments either when the shaft is rotating clockwise (CW) or when the shaft is rotating counter-clockwise (CCW). CW and CCW rotations are viewed from shaft end. Setting 0 (bit 0 = 0) causes the encoder counting to increment when the shaft is rotating clockwise; setting 1 (bit 0 = 1) causes the encoder counting to increment when the shaft is rotating clockwise; setting 1 (bit 0 = 1) causes the encoder counting to increment when the shaft is rotating clockwise; setting 1 (bit 0 = 1) causes the encoder counting to increment when the shaft is rotating counter-clockwise.

#### Scaling function

This is meant to enable / disable the scaling parameters 6001-00 Counts per revolution and 6002-00 Total resolution. When the scaling function is disabled (bit 2 = 0), the encoder uses its own physical resolution (i.e. hardware counts per revolution and number of hardware revolutions, see the encoder identification label and the objects 6501-00 Hardware counts per revolution and 6502-00 Hardware number of turns); otherwise, when the scaling function is enabled (bit 2 = 1), the encoder uses the resolution set next to the parameters 6001-00 Counts per revolution and 6002-00 Total resolution complying with the following relation:

# 6001-00 Counts per revolution

Transmitte d position

6501-00 Hardware counts

- x Real position  $\leq$ 

6002-00 Total resolution

6001-00 Counts per revolution

[Unsigned32, rw]

This object sets the number of distinguishable steps per revolution. This value is considered only if the bit 2 **Scaling function** in the **6000-00 Operating parameters** item is set to "=1". To avoid counting errors, check that

6501-00 Hardware counts per revolution

6001-00 Counts per revolution

is an integer value.

Furthermore, after having set a new value next to the 6001-00 Counts for revolution parameter, make sure to meet also the following condition:

<

6002-00 Total resolution 6001-00 Counts per revolution Number of physical revolutions

You are allowed to set whatever integer value lower than or equal to the maximum number of physical steps per revolution (see the hardware counts per revolution in the encoder identification label and the object 6501-00Hardware counts per revolution).

Default =0000 2000h (8192)



WARNING

Every time you change the value in this object then you are required to set a new preset value (see 6003-00 Preset value)

#### 6002-00 Total resolution

[Unsigned32, rw]

This object sets a custom number of distinguishable steps over the total measuring range.

This value is considered only if the bit 2 **Scaling function** in the **6000-00 Operating parameters** item is set to "=1".

This values results from:

6001-00 Counts per revolution * number of desired revolutions.

You are allowed to set whatever integer value lower than or equal to the **overall hardware resolution** (see the encoder identification label).

The overall hardware resolution results from:

6501-00 Hardware counts per revolution * 6502-00 Hardware number of turns.

Default =0800 0000h (134217728)

## **CIDOJATAGO**



#### NOTE

To avoid counting errors we recommend values which are power of 2  $(2^n: 2, 4, ..., 2048, 4096, 8192,...)$  to be set next to the objects **6001-00 Counts per revolution** and **6002-00 Total resolution**.



#### WARNING

If you have set the preset, when you change the value next to 6001-00 Counts per revolution and/or 6002-00 Total resolution parameters, then you must check the value in the 6003-00 Preset value parameter and perform the preset operation.

#### 6003-00 Preset value

[Unsigned32, rw]

This object allows to set the encoder position to a Preset value. Preset function is meant to assign a certain value to a desired physical position of the encoder. The chosen physical position will get the value set next to this item and all the previous and following positions will get a value according to it. For instance, this can be useful for getting the zero point of the encoder and the zero point of the application to match.

Default = 0000 0000h

# Â

#### WARNING

Check the value in the 6003-00 Preset value parameter and perform the preset operation every time you change the value next to 6001-00 Counts per revolution and/or 6002-00 Total resolution parameters.



NOTE

- If the scaling function is disabled (bit 2 Scaling function in the parameter 6000-00 Operating parameters = 0), 6003-00 Preset value must be lower than or equal to the total hardware resolution (i.e. 6501-00 Hardware counts per revolution 6502-00 Hardware number of turns).
- If the scaling function is enabled (bit 2 Scaling function in the parameter 6000-00 Operating parameters = 1), 6003-00 Preset value must be lower than or equal to 6002-00 Total resolution.

Set Preset value 6003-00 Preset value (preset = 1000 = 3E8h)

MasterEncoderCmd specific dataCmdIndex23036000E8030000

	Encode	er Ma	ster (Se	et confi	rmation	ı)	
		С	md spe	ecific da	ata		

Cmd specific data							
Cmd	Inc	lex	Sub		Da	ata	
60	03	60	00	00	00	00	00

#### 6004-00 Position value

[Unsigned32, ro]

This object contains the position value of the encoder, transmitted value is calculated considering the scaling values, bit 2 **Scaling function** of the object 6000-00 **Operating parameters**.

#### 6500-00 Operating status

[Unsigned16, ro]

Bit	Function	bit = 0	bit = 1
		CW	CCW
0	Code sequence	Clockwis	Counter
		е	clockwise
1	not used		
2	Scaling function	Disabled	Enabled
3 15	not used		

#### Code sequence

It shows the currently set value that is entered through the bit 0 **Code sequence** in the parameter **6000-00 Operating parameters**. If the bit is "=0" the output encoder position value has been set to increment when the shaft rotates clockwise; if the bit is "=1" instead the output encoder position value has been set to increment when the shaft rotates counter-clockwise. For any further information on setting and using the counting direction function refer to **6000-00 Operating parameters** parameter on page 49.

#### Scaling function

It shows the currently set value that is entered through the bit 2 **Scaling function** in the parameter **6000-00 Operating parameters**. In other words, it is intended to show whether the scaling function is enabled or disabled. If the value is "=0" the scaling function is disabled; if the value is "=1" instead the scaling function is enabled. For any further information on setting and using the scaling function refer to the **6000-00 Operating parameters** parameter on page 49.

#### 6501-00 Hardware counts per revolution

[Unsigned32, ro]

This object defines the <u>physical</u> number of distinguishable steps each turn given by the hardware.

To set a custom singleturn resolution see object 6001-00 Counts per revolution.

#### 6502-00 Hardware number of turns

[Unsigned32, ro]

This object defines the <u>physical</u> number of distinguishable turns given by the hardware.

Total hardware resolution = 6501-00 Hardware counts per revolution * 6502-00 Hardware number of turns.

To set a custom number of turns see objects 6001-00 Counts per revolution and 6002-00 Total resolution.

#### 6503-00 Errors

[Unsigned16, ro] The corresponding bits of supported errors are set (see object 6504-00 Supported errors).

#### 6504-00 Supported errors

[Unsigned16, ro] Default = 0000h (No errors supported).

#### 6505-00 Warnings

[Unsigned16, ro] Bits of supported warnings are set (see object 6506-00 Supported warnings).

#### 6506-00 Supported warnings

[Unsigned16, ro] bit 12: wrong parameters loaded from flash memory at power on. Default = 1000h

#### 6509-00 Offset value

[Unsigned32, ro] This object contains the Offset value. This value is the difference between the physical position of the encoder and the position relating 6003-00 Preset value.



#### NOTE

To save new parameters execute the store parameters function (see object **1010-01 Store parameters**).

When the power is turned off, parameters not saved are lost.

#### 6.2.6 SDO Abort codes

SDO transfer could be unsuccessful; causes of error are listed and described in the SDO Abort Codes (see ETG1000.6 par. 5.6.2.7.2 table 40).

#### 6.2.7 Emergency Error Codes

Emergency Service is used by server for transmitting diagnostic messages to the client using MailBox; Error Codes are listed and described in the ETG1000.6 par. 5.6.4.2 table 50.

Error	Code	Error Register	Diagnostic Data				
Byte	Byte	Byte (2)	Byte	Byte	Byte	Byte	Byte
(0)	(1)		(3)	(4)	(5)	(6)	(7)

Error Code State Transition Errors of state machine: (for detailed description see ETG1000.6 par. 5.6.4.3) A000hex: transition error from PRE-OPERATIONAL to SAFE-OPERATIONAL A001hex: transition error from SAFE-OPERATIONAL to OPERATIONAL Encoder errors: 5000hex: Hardware error 5001hex: Diagnostic data (wrong parameters loaded from flash memory)

Error Register EtherCAT state machine current status (ESM)

Diagnostic Datainformation about possible error causes (see ETG1000.6 par. 5.6.4.3.2-5).

#### 6.2.8 AL Status Error Codes

If the state transition requested by the Master through the "AL Control Register" is unsuccessful, Slave sets to 1 the "Error Indicator Bit" in "AL Status Register" and writes the cause of the error in "AL Status Code Register".

Values and descriptions of "AL Status Code" are available in ETG1000.6 par.5.3.2 Table 11.

6.3 File Over EtherCAT (FoE)

Datalogic encoders are devices that allow the firmware update using the protocol "File over EtherCAT (FoE)".

For any specification on FoE protocoll, please refer to "ETG.1000 EtherCAT Specification" document available at the address www.ethercat.org.

# 7 – Default parameters list

Default values are expressed in hexadecimal notation.

Parameters list	Default values	
6000-00 Operating	0000	
parameters		
6001-00 Counts for revolution	0000 2000h (8192)	
6002-00 Total	0800 0000h	
resolution	(134217728)	
6003-00 Preset value	0000 0000	