

# Laser Pointer

## LASER POINTER



MODEL	DESCRIPTION	ORDER NUMBER
SG-LP	Laser pointer	95ASE5590
<b>COMPATIBILITY</b>		All SG Series Safety Light Curtains except SG4-H and SLIM

# Communication interface

## DONGLE



MODEL	DESCRIPTION	ORDER NUMBER
SG4-DONGLE	Ethernet adaptor	95ASE2080
<b>FUNCTIONS</b>		
1) Ethernet connection (TCP/IP) to Monitoring and Configuration Software SG4-E GUI. 2) Configuration cloning 3) Error logging 4) Configuration logging		
<b>COMPATIBILITY</b>		
SG4 EXTENDED		
<b>NOTE</b>		
To connect SG-DONGLE directly to a PC, order Ethernet cable CAB-ETH-M01		