

USER'S MANUAL



> IO-LINK MASTER Profinet IO and Modbus/TCP



ORIGINAL INSTRUCTIONS (ref. 2006/42/EC)

Datalogic S.r.l.
Via S. Vitalino 13
40012 Calderara di Reno
Italy

IO-LINK MASTER User's Manual
Ed.: 05/2019

© 2019 Datalogic S.p.A. and/or its affiliates ♦ ALL RIGHTS RESERVED. ♦ Without limiting the rights under copyright, no part of this documentation may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means, or for any purpose, without the express written permission of Datalogic S.p.A. and/or its affiliates.

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

All other trademarks and brands are property of their respective owners.

Datalogic shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from the use of this material.

821006340 Rev. A

CONTENTS

1	INTRODUCTION	6
2	HARDWARE INSTALLATION	7
2.1	CBX-IOL-8-PNIO Hardware Installation	7
2.1.1	Setting the Rotary Switch	7
2.1.2	Connecting to the network	9
2.1.3	Connecting the power	9
2.1.4	Mounting the CBX-IOL-8-PNIO	11
3	CONFIGURING THE IOLM WITH STEP 7	12
3.1	Overview	12
3.2	Installing the GSD File	12
3.3	Configuring the IOLM.....	13
3.3.1	STEP 7 V5.5	13
3.3.2	TIA Portal V13.....	13
3.4	IP Address Assignment	14
3.4.1	Assigning an IP Address via IO Controller (DCP)	14
3.4.1.1	STEP 7 V5.5	14
3.4.1.2	TIA Portal V13.....	15
3.4.2	Assigning an IP Address via DHCP.....	16
3.4.3	Assigning an IP Address Statically (LOCAL).....	17
3.4.3.1	STEP 7 V5.5	17
3.4.3.2	TIA Portal V13.....	19
3.4.3.3	Assign IP Address Statically Using the Web Page.....	21
3.5	Device Name Assignment	22
3.5.1	Assign the Device Name in STEP 7	22
3.5.1.1	STEP 7 V5.5	22
3.5.1.2	TIA Portal V13.....	23
3.5.2	Using the Web Interface to Assign the Device Name.....	24
3.6	Setting the IO Device Update Time	25
3.6.1	STEP 7 V5.5	25
3.6.2	TIA Portal V13.....	26
3.7	Configuring IO-Link Ports	27
3.7.1	IO-Link Port Modules	27
3.7.1.1	IO-Link Port Settings (IO-Link Port Module Parameters)	28
3.7.1.1.1	STEP 7 V5.5.....	29
3.7.1.1.2	TIA Portal V13	30
3.7.1.2	SIO Digital In/Out Module Parameters	31
3.7.1.2.1	STEP 7 V5.5.....	31
3.7.1.2.2	TIA Portal V13.....	32
3.7.2	Port Status Modules	33
3.7.2.1	IO-Link Status Module	33
3.7.2.2	Auxiliary Input Parameters.....	34
3.7.2.2.1	STEP 7 V5.5.....	34
3.7.2.2.2	TIA Portal V13	35
3.7.2.3	Digital I/O Module	35
3.7.2.3.1	STEP 7 V5.5.....	36
3.7.2.3.2	TIA Portal V13	37
3.7.3	Port Status Modules	38
4	CONNECTING DEVICES.....	41
4.1	Overview	41
4.2	CBX-IOL-8-PNIO IO-Link Ports	41
5	LOADING AND MANAGING IODD FILES	44

5.1	IO-Link Device Description Files Page	44
5.1.1	Preparing IODD Files to Upload	44
5.1.2	Uploading IODD Zip Files	45
5.1.3	Uploading xml Files or Supporting Files	47
5.1.4	Viewing and Saving IODD Files	48
5.1.5	Deleting IODD Files	49
5.2	IO-Link Device Configuration Summary Page	50
6	CONFIGURING IO-LINK DEVICES	51
6.1	Port Pages Overview	51
6.2	Editing Parameters – IO-Link Device – Port Table	55
6.3	Resetting IO-Link Device Parameters to Factory Default	56
6.4	Editing Parameters – IO-Link Device ISDU Interface – Port	57
6.4.1	Overview	57
6.4.2	How to Use the Interface	58
7	UTILIZING IOLM FEATURES	59
7.1	Setting User Accounts and Passwords	59
7.2	Data Storage	61
7.2.1	Uploading Data Storage to the IOLM	61
7.2.2	Downloading Data Storage to the IO-Link Device	61
7.2.3	Automatic Device Configuration	62
7.2.4	Automatic Device Configuration Backup	64
7.3	Device Validation	65
7.4	Data Validation	67
7.5	IOLM Configuration Files	68
7.5.1	Saving Configuration Files	68
7.5.2	Loading Configuration Files	69
7.6	Configuring Miscellaneous Settings	70
7.6.1	Using the Menu Bar Hover Shows Submenu Option	71
7.6.2	Enable PDO Write From Attached Devices Port Page	72
7.6.3	IO-Link Test Event Generator	73
7.7	Clearing Settings	75
8	USING THE DIAGNOSTIC PAGES	76
8.1	IO-Link Port Diagnostics	76
8.2	Modbus/TCP Diagnostics	79
8.3	PROFINET IO Diagnostic Page	81
8.4	OPC UA Diagnostics Page	84
9	PROFINET IO REFERENCE INFORMATION	85
9.1	Sample IO-Link Master Gateway Configuration	85
9.2	Read PDI Data as Record Data	87
9.3	Using the SFB52 RDREC	88
9.4	Read and Write ISDU with the FB IOL_CALL	89
9.4.1	Using the IO-Link Library in the TIA Portal	90
9.5	Diagnostic Alarm	94
9.5.1	IO-Link Event Mapping Overview	94
9.5.2	IO-Link EventCode Mapping	94
10	MODBUS/TCP INTERFACE	97
10.1	Modbus Function Codes	97
10.2	Modbus Address Definitions	98
10.2.1	Port Models	99
10.3	Multiple Port Process Data (PDI/PDO) Access via Modbus/TCP	100
11	FUNCTIONALITY DESCRIPTIONS	103
11.1	Process Data Block Descriptions	103
11.1.1	Input Process Data Block Description	103
11.1.1.1	Input Process Data Block-8 Bit Data Format	104

11.1.1.2	Input Process Data Block-16 Bit Data Format	104
11.1.1.3	Input Process Data Block-32 Bit Data Format	104
11.1.2	Output Process Data Block Description	105
11.1.2.1	Output Process Data Block-8 Bit (SINT) Data Format.....	105
11.1.2.2	Output Process Data Block-16 Bit (INT) Data Format	106
11.1.2.3	Output Process Data Block-32 Bit (DINT) Data Format.....	107
11.2	Event Handling.....	108
11.2.1	Clear Event After Hold Time Process	108
11.2.2	Clear Event in PDO Block Process.....	109
11.2.3	Clear Event Code in PDO Block and Clear Event After Hold Time Process- PDO Block First.....	109
11.2.4	Clear Event Code in PDO Block and Clear Event After Hold Time Process- Hold Time Expires	110
11.3	ISDU Handling	111
11.3.1	ISDU Request/Response Structure	111
11.3.1.1	Single ISDU Command Requests.....	111
11.3.1.2	Multiple ISDU Command Structure	112
11.3.2	ISDU Request Message Format From PLC to IOLM	114
11.3.2.1	Standard ISDU Request Command Format.....	114
11.3.2.2	Integer (16-Bit Word) ISDU Request Command Format	115
11.3.3	ISDU Response Message Format	116
11.3.3.1	Standard ISDU Response Command Format.....	116
11.3.3.2	Integer (16-Bit Word) ISDU Response Command Format.....	117
11.3.4	ISDU Blocking and Non-Blocking Methods	118
11.3.4.1	Single Command Blocking	118
11.3.4.2	Multiple Command Blocking.....	119
11.3.4.3	Single Command Non-Blocking	119
11.3.4.4	Multiple Command Non-Blocking.....	120
12	TROUBLESHOOTING AND TECHNICAL SUPPORT	121
12.1	Troubleshooting	121
12.2	IOLM LEDs	122
12.2.1	CBX-IOL-8-PNIO-LEDs	122
12.3	Contacting Technical Support.....	123
12.4	Using Log Files	123
12.4.1	View a Log File	124
12.4.2	Export a Log File.....	124
12.4.3	Clear a Log File.....	125

1 INTRODUCTION

This document provides installation, configuration, and embedded web interface information for the Datalogic IO-Link Master (IOLM), including detailed information on PROFINET IO and Modbus/TCP.

The web interface provides a platform for the user to easily configure, review diagnostic pages, and access advanced features, e.g.:

- Upload the latest IOLM images or applications
- Set up user accounts with different user levels and passwords
- Load IODD files and configure IO-Link device parameters
- Implement manual or automatic data storage (upload or download)
- Implement device and/or data validation

2 HARDWARE INSTALLATION

2.1 CBX-IOL-8-PNIO HARDWARE INSTALLATION

This section provides detailed information on the hardware installation of the CBX-IOL-8-PNIO.

2.1.1 Setting the Rotary Switch

You can use the rotary switches under the configuration window on the IOLM to set the lower 3-digits (8 bits) of the static IP address.



Note: Optionally, you can leave the rotary switch set to the default and use the web interface to set the network address.

If the rotary switches are set to a non-default position, the upper 9-digits (24 bits) of the IP address are then taken from the static network address. The switches only take effect during startup, but the current position is always shown on Help | SUPPORT page.

Using the rotary switches to set the IP address may be useful in the following situations:

- A permanent method to assign IP addresses while setting machines for a special application where a PC or laptop is not available.
- A temporary method to assign IP addresses to several IOLMs so that they do not have duplicate addresses. This makes IP address setting through software easier. After using the web page to change the IP address, reset the rotary switches back to 000.
- An emergency method to return the IOLM back to factory defaults, so that software can be used to program the appropriate IP address, and then return the switches back to 000.



Note: If you set the network address using the rotary switches, the Rotary Switch setting overrides the network settings in the web interface when the IOLM is initially powered on or after cycling power.

Switch Setting	Node Address
000 (Default setting)	Use the network configuration stored in the flash. The default network configuration values are: <ul style="list-style-type: none"> • IP address = 192.168.1.250 • Subnet mask = 255.255.255.0 • IP gateway = 0.0.0.0
001-254	This is the last three digits in the IP address. This uses the first three numbers from the configured static address, which defaults to 192.168.1.xxx. Note: If software is used to change the IP address to another range before setting the rotary switches, the IOLM uses that IP address range. For example, if the IOLM is set to 10.0.0.250 and the first rotary switch is set to 2, the IP address would be 10.0.0.200.
255-887	Reserved.
888	Reset to factory defaults. If the IOLM is set to 888 and the IP address is changed using other methods, the IP address is returned to the default IP address if the IOLM

	is rebooted or power cycled.
889-997	Use the network configuration values stored in the flash (reserved).
998	Setting the rotary switches to 998 configures the IOLM to use DHCP addressing.
999	Use the default IP address. If the IOLM is set to 999 and the IP address is changed using other methods, the IP address is returned to the default IP address if the IOLM is rebooted or power cycled.

Follow these steps to change the default rotary switch settings:

1. Gently open the window using a small flathead screwdriver.
2. Gently swing open the switch window from the top to the bottom, allowing it to pivot on the hinge on the bottom of the window.
3. Turn each dial to the appropriate position using a small flathead screwdriver.



Figure 1 - Rotary switches

The default setting is 000 as shown above.

The arrow points to the switch location. 0 is located at the 9:00 position. Turn the dial clockwise to the appropriate setting.


4. Close the window and make sure that it snaps shut tightly.



Failure to close the configuration window properly may compromise IP67 integrity.

2.1.2 Connecting to the network

The IOLM provides two Fast Ethernet (10/100BASE-TX) M12, 4-pin female D-coded connectors.



You can use this procedure to connect the IOLM to the network.

1. Securely connect one end of a shielded twisted-pair (Cat 5 or higher) M12 Ethernet cable to either Ethernet port.
2. Connect the other end of the cable to the network.
3. Optionally, use the other Ethernet port to daisy-chain to another Ethernet device.
4. If you did not connect both Ethernet ports, make sure that the unused port is covered with a connector cap to keep dust and liquids from getting in the connector.




Note: Ethernet ports must have an approved cable or protective cover attached to the connector to guarantee IP67 integrity.

2.1.3 Connecting the power

The CBX-IOL-8-PNIO provides M12 (5-poles) L-coded input and output power connectors. Use a 24VDC power supply capable of the total output current required.



Note: Power connectors must have an approved cable or protective cover attached to the port for IP67 compliance.



Pin	Power Input (Male)	Power Output or Actuator Power (Female)	Description
1	US+	US+ or +V	IO-Link Master's system electronics and IO-Link devices
2	UA-	UA- or 0V	Actuator supply
3	US-	US- or 0V	IO-Link Master's system electronics and IO-Link devices
4	UA+	UA+ or +V	Actuator supply
5	FE		




Note: The IOLM requires a UL listed power supply with an output rating of 24VDC.

Power Supply	Values
Power Supply In - Maximum V_S and V_A	16A (Maximum)
IO-Link Connector Port 1 C/Q (Pin 4) L+/L- Sensor Supply (Pins 1 and 3)	200 mA (Maximum) 1.6A (Maximum)
IO-Link Connector Port 3 C/Q (Pin 4) L+/L- Sensor Supply (Pins 1 and 3)	200 mA (Maximum) 1A (Maximum)
IO-Link Connectors Ports 2 and 4 - 8 C/Q (Pin 4) L+/L- Sensor Supply (Pins 1 and 3)	200 mA (Maximum) 500 mA (Maximum)/up to 1A Output Budget
IOLM Power	100mA @ 24VDC (V_S)
Power Supply Out V_S V_A	16A † (Maximum) 16A †† (Maximum)
† V_S output available is determined by subtracting the following from the available input current. <ul style="list-style-type: none"> - IO-Link Master module electronics current. - Total L+/L- current for all IO-Link ports. - Total C/Q current for all IO-Link ports. 	
†† V_A output available is the same as the available V_A input current.	

You can use the following procedure to connect the IOLM to a power supply.



Note: Power should be disconnected from the power supply before connecting it to the IOLM. Otherwise, your screwdriver blade can inadvertently short your power supply terminal connections to the grounded enclosure.

1. Securely attach the power cable between the male power connector (**PWR In**) and the power supply.
2. Either attach a power cable between the female power connector and another device to which you want to provide power or securely attach a connector cap to prevent dust or liquids from getting into the connector.
3. Apply the power and verify that the following LEDs are lit indicating that you are ready to attach your IO-Link or digital I/O devices.
 - a. The **US** LED lights.
 - b. The **ETH1/ETH2** LED lights on the connected port.
 - c. The **MOD** and **NET** LEDs are lit.
 - d. The IO-Link LEDs  flash (if no IO-Link device is attached) or are lit if an IO-Link device is attached.



Note: It takes approximately 25 seconds after power up for the IO-Link Master to be ready for operation.

e. The **MOD** LED is solid green, the IO-Link Master is ready for operation. Go to the next installation step:


- Program the IP address using the web interface. Refer to chap. 3 for configuring network information.
- If you are using the rotary switches to set the IP address, then you are ready to attach devices. Refer to chap. 4.

If the LEDs do not meet the above conditions, you can refer to par. 12.2.1 (CBX-IOL-8-PNIO LEDs).

2.1.4 Mounting the CBX-IOL-8-PNIO

Use the following procedure to mount the IOLM. You can mount the IOLM on a mounting panel or a machine.

1. Verify that the mounting surface is level (flat) to prevent mechanical stress to the IOLM.
2. Attach the IOLM to the surface with two 6mm screws and washers, torque down to 8Nm.



3 CONFIGURING THE IOLM WITH STEP 7

3.1 OVERVIEW

PROFINET IO configuration procedures vary between software versions but the following configuration steps are required in all cases. Refer to your STEP 7 documentation if you require step-by-step procedures.

1. Download, unzip, and upload the GSD file for the IO-Link Master (IOLM).
2. Insert the IOLM in the PROFINET IO system.
3. Configure the IP address for the IOLM.
4. Assign the PROFINET Device Name.
5. Set the IO Device Update Time.
6. Configure the IO-Link ports.
 - a. Configure IO-Link port modules.
 - b. Configure port status modules.
 - c. If desired, configure data storage, automatic or manual - upload or download.
 - d. If desired, configure device validation and data validation.
7. Use chap. 9 (PROFINET IO Reference Information) to complete configuration after attaching the IO-Link devices.

3.2 INSTALLING THE GSD FILE

Use the following procedure to install the GSD file for PROFINET IO using STEP 7 V5.5.

1. Unzip **GSDML-V2.xx-Datalogic-IOLink-yyyyymmdd.zip** to a working directory.
2. Use the appropriate steps:

STEP 7 V5.5:

- a. Open **SIMATIC STEP 7 | HW Config**.
- b. Use **Menu Options | Install GSD Files** to install the GSD file.

TIA Portal V13:

- a. Open the TIA Portal and switch to the **Project** view.
- b. Use **Menu Options | manage general station description files (GSD)** to install the GSD file.



Note: If an older version of the GSD file was installed before, you may need to remove the IOLM object from an existing project and reinsert it after the new GSDML file is installed.

3.3 CONFIGURING THE IOLM

Use the appropriate procedure for your environment:

- STEP 7 V5.5
- TIA Portal V13

3.3.1 STEP 7 V5.5

Select the IOLM from the *Hardware Catalog* window and insert it into a PROFINET-IO-System in the HW Config (DR-8-PNIO) as shown in **Figure 2**.





Figure 2 - Inserting an IOLM DR-8-PNIO into a PROFINET IO System

3.3.2 TIA Portal V13

Select the IOLM from the *Hardware Catalog* window (Other field devices | PROFINET IO | Gateway | Datalogic | DR-8-PNIO) and drag it into the **Device configuration | Network** view. Then connect the IOLM to the IO controller.



3.4 IP ADDRESS ASSIGNMENT

Datalogic IOLM gateways support three methods for IP address assignment according to *GSDML Specification*.

- **DCP** - The IOLM supports IP address assignment via Discovery and basic Configuration Protocol (DCP).
- **DHCP** - The IOLM supports the Dynamic Host Configuration Protocol for IP address assignment.
- **LOCAL** - The IOLM supports a device specific method for IP address assignment.

3.4.1 Assigning an IP Address via IO Controller (DCP)

An IO controller can assign an IP address to the Datalogic IOLM gateway via DCP. The IO controller and the Datalogic IOLM gateway have to be on the same subnet. The IOLM default IP address is: 192.168.1.250 and the subnet mask is 255.255.255.0.

Use the appropriate procedure for your environment.

- STEP 7 V5.5
- TIA Portal V13

3.4.1.1 STEP 7 V5.5

Use the following procedure to assign an IP address via DCP.

1. Double-click the **X1 PNIO-IO** interface of the IO control to open the *Properties* window.
2. On the **General** tab, click the **Properties** button, which opens the *Ethernet interface Properties* window.
3. Uncheck the **Use different method to obtain IP address** option.
4. Manually enter the IP address and subnet mask for the IO controller.
In this example the IO controller was assigned an IP address of 10.0.0.31 and a subnet mask of 255.0.0.0.
5. Double-click the IOLM, check **Assign IP address via IO controller** as shown in Figure 3.
6. On the **General** tab, click the **Ethernet** button, which opens the *Ethernet interface properties* window, where you can specify what IP address the IO controller should assign to the IOLM.

Steps 2 through 4 are necessary in STEP 7 V5.5 so that both the IO controller and the IOLM are on the same subnet. Otherwise, the Assign IP address via IO controller function may not work correctly.

In this example, IP address 10.0.0.100 is assigned to the IOLM via the IO controller.





Figure 3 - IOLM Properties

3.4.1.2 TIA Portal V13

Use the following procedure to assign an IP address via DCP.

1. Double-click the IOLM in the **Device configuration | Network** view.
2. On the **Properties | General tag**, select **Ethernet addresses**.
 - a. Make sure that the **User IP protocol** option is checked and the **Set IP address in the project** is selected.
 - b. Enter the desired IP address for the IOLM. In this example the IP address 10.0.0.100 is assigned to the IOLM via the IO controller.



3.4.2 Assigning an IP Address via DHCP

The Datalogic IOLM gateway supports DHCP for IP address assignment. DHCP is disabled by default. Use the following steps to enable DHCP.



Note: The IOLM default IP address is: 192.168.1.250 and the subnet mask is 255.255.255.0. You may need to change your laptop or PC IP address range to access the IOLM web interface to change the IP address without changing your settings.

1. Open a web browser and enter the IOLM IP address.
2. Click **Configuration | Network**.
3. Click **EDIT** button.

The screenshot shows the 'Network Settings' page with the 'EDIT' button in the top right corner highlighted with a red box and labeled '1.'. A 'Caution' dialog box is displayed in the center, with the text 'Changes to IP address configuration may interfere with PLC communications.' and the 'CONTINUE' button highlighted with a red box and labeled '2.'.

Figure 4 - Web Network Configuration Page

4. Change **IP Type** from **static** to **dhcp**.

The screenshot shows the 'Network Settings' page with the 'IP Type' dropdown menu set to 'dhcp'. The 'SAVE' button in the top right corner is highlighted with a red box.

5. Click the **SAVE** button.

Once DHCP is enabled, the IOLM attempts to obtain an IP address from a DHCP server. If a new IP address is assigned by a DHCP server, then the IOLM switches to the new IP address immediately. This may interfere with communications between the device and the IO controller.

The **Obtain IP address from a DHCP server** option in the *Edit Ethernet Node* window in STEP 7 (Figure 4) is not supported. DHCP can only be enabled or disabled via the web interface.



Note: An IO controller can overwrite DHCP IP assignment by assigning IP address via DCP.

The next configuration step is to assign the device name. Refer to par. 3.5.

3.4.3 Assigning an IP Address Statically (LOCAL)

IP addresses can also be assigned statically using one of the following methods:

- The LOCAL method as defined in the GSDML Specification
- Embedded web interface


Use the appropriate procedure for your environment:

- STEP 7 V5.5
- TIA Porta V13

3.4.3.1 STEP 7 V5.5

Use the following procedure if you want to use the LOCAL method using STEP 7.

1. In the STEP 7 *HW Config* window, double-click the IOLM object to open up the *Properties* window.



2. Uncheck the **Assign IP address via IO controller** option and click **OK**.

3. Download and run the project.


The IO controller will not attempt to assign IP address to the IOLM. You must assign a static IP address to the IOLM manually.

4. Select the IOLM in **HW Config**, open the *Edit Ethernet Node* window (Figure 5) by using menu **PLC | Ethernet | Edit Ethernet Node** option.

5. Once opened, click the **Browse** button, which opens the *Browse Network* window.

The IOLM should be displayed as an Datalogic IO-Link Master with a default IP address of 192.168.1.250.

6. Select the IOLM and click the **OK** button to return to the *Edit Ethernet Node* window.
7. Enter the desired IP configurations.
In **Figure 5**, the IOLM was configured to use a static IP address 10.0.0.100, subnet mask 255.0.0.0 and no router.
8. Click the Assign IP Configuration button, the IP configuration is assigned to the IOLM.



The screenshot shows the 'Edit Ethernet Node' window with the following configuration details:

- Ethernet node:** MAC address: 00-C0-4E-57-00-00
- Set IP configuration:**
 - Use IP parameters (selected)
 - IP address: 10.0.0.100
 - Subnet mask: 255.0.0.0
 - Gateway: Do not use router (selected)
- Obtain IP address from a DHCP server:** (Not selected)
- Identified by:** Client ID (selected)
- Assign IP Configuration:** (Button)
- Assign device name:** Device name: cbx8iolpnic
- Reset to factory settings:** (Reset button)
- Close** and **Help** buttons at the bottom.


Figure 5 - Configure IP Address and Device Name

The next configuration step is to assign the device name. Refer to par. 3.5.


3.4.3.2 TIA Portal V13

Use the following procedure if you want to set the LOCAL method using TIA Portal.

1. Double-click the IOLM in the **Device configuration | Network** view.
2. On the **Properties | General tag**, select **Ethernet addresses**.
3. Make sure that the **User IP protocol** option is checked and the **IP address is set directly at the device** is selected.
4. Download and run the project. The IO controller will not attempt to assign IP address to the IOLM. You must assign a static IP address to the IOLM manually.



5. In the TIA Portal Project view, navigate to **Project tree | Online access**, double-click the **Ethernet adapter that is used as PROFINET IO network in your system**, then double-click **Update accessible devices**.



6. Once the accessible devices list is updated, find the IOLM by using the default IP address 192.168.1.250 or the previous IP address that the IOLM was assigned by IO controller.

7. Double-click the Accessible device [192.168.1.250], then double-click the **Online & diagnostics** to open up the Online access view.
8. Click the **Functions | Assign IP address**, enter the desired IP configurations. In the following figure, the IOLM was configured to use a static IP address 10.0.0.100, subnet mask 255.0.0.0 and no router.
9. Click the Assign IP address button, the IP configuration is assigned to the IOLM.



Online access > D-Link DGE-530T Gigabit Ethernet Adapter > iolm8 [10.0.0.100] > iolm8 [10.0.0.100]

▼ Diagnostics
General
Diagnostic status
▶ PROFINET interface
▼ Functions
Assign IP address
Assign name
Reset to factory settings

Assign IP address

Assign IP address to the device

 Devices connected to an enterprise network or directly to the internet must be appropriately protected against unauthorized access, e.g. by use of firewalls and network segmentation. For more information about industrial security, please visit <http://www.siemens.com/industrialsecurity>

MAC address: 00 - C0 - 4E - 57 - 00 - 00

IP address: 10 . 0 . 0 . 100

Subnet mask: 255 . 0 . 0 . 0

Use router

Router address: 10 . 0 . 0 . 1

The next configuration step is to assign the device name. Refer to par. 3.5.

3.4.3.3 Assign IP Address Statically Using the Web Page

You can use the following procedure to configure a static IP address. The IOLM web interface switches to the new IP address immediately.



Note: The IOLM default IP address is: 192.168.1.250 and the subnet mask is 255.255.255.0. You may need to change your laptop or PC IP address range to access the IOLM web interface to change the IP address without changing your settings.

1. Open a web browser and enter the IOLM IP address.
2. Click **Configuration | Network**.
3. Click the **EDIT** button.

The screenshot shows the IOLM web interface with the following elements:

- Navigation bar: IO-LINK, PROFINET IO, MODBUS/TCP, OPC UA, NETWORK (selected), MISC, LOAD/SAVE, CLEAR SETTINGS.
- Page title: Network Settings
- Section: NETWORK CONFIGURATION with an **EDIT** button (labeled 1.).
- Table:

Status	
Current IP Address	192.168.11.185
Current Netmask	255.255.0.0
Current Gateway	
Current DNS	
Configuration	
Host Name	
IP Type	
Static IP Address (xxx.xxx.xxx.xxx)	
Static Subnet Mask (xxx.xxx.xxx.xxx)	
Static Gateway Address (xxx.xxx.xxx.xxx)	
DNS 1 (xxx.xxx.xxx.xxx)	
DNS 2 (xxx.xxx.xxx.xxx)	
IP Address Conflict Detection	enable
NTP Server IP/Hostname	
Syslog Server IP/Hostname	
Syslog Server Port (0 - 65535)	514
SSH Server Enable	enable
- Caution dialog box:

Caution

Changes to IP address configuration may interfere with PLC communications.

Buttons: **CONTINUE** (labeled 2.), CANCEL

4. If necessary, change the **IP Type** to **static**.
5. Enter an IP address, subnet mask, and gateway address.
6. If applicable, enter the DNS1 and DNS2 addresses.
7. Click the **SAVE** button.

The next configuration step is to assign the device name. Refer to par. 3.5.

3.5 DEVICE NAME ASSIGNMENT

Use one of the following methods to configure the Device Name.

- STEP 7
- Web interface

3.5.1 Assign the Device Name in STEP 7


Use the appropriate procedure for your environment:

- STEP 7 V5.5
- TIA Portal V13

3.5.1.1 STEP 7 V5.5

Use the following procedure to configure the Device Name using STEP 7.

1. Select the IOLM, open the *Edit Ethernet Node* window using the **PLC | Ethernet | Edit Ethernet Node** menu.
2. Click the **Browse** button to open the *Browse Network* window.
The unit should be displayed as an IO-Link Master with an empty device name.
3. Select the unit and click the **OK** button to return to the *Edit Ethernet Node* window.




4. Set the device name. PROFINET IO Device Names are not case-sensitive.

If there is a cyclic communication between the device and an IO controller, the cyclic communication must be stopped before changing the device name.

3.5.1.2 TIA Portal V13

1. Use the same procedure in par. 3.4.3.2 to access the **Online access** view.
2. Click **Functions | Assign name**, enter the device name and click the **Assign name** button. PROFINET IO Device Names are not case-sensitive. In this example, the device name was set to `iolmnr8`.



3.5.2 Using the Web Interface to Assign the Device Name

You can use the **Configuration | Profinet IO Settings** page to assign the device name for PROFINET IO with the IO-Link Master.




Note: Changes to device name using the web interface take effect immediately. It may interfere with the communication between the device and IO controller.

1. If necessary, open the IOLM web interface with your web browser using the IP address.
2. Click **Configuration | PROFINET IO Settings**.
3. Click the **EDIT** button.
4. Enter the **PROFINET IO Device Name**.

The **PROFINET IO Device Name** is the same as the name later used to configure PROFINET IO for the IOLM. The **PROFINET IO Device Name** is not case-sensitive.

5. If necessary, change the **IOL_CALL Function Block Timeout** (1-20) value to reflect your environment.



6. Click **SAVE**.

Parameter	Description
PROFINET IO Device Name (Default: empty)	<p>The device name must be specified according to DNS conventions.</p> <ul style="list-style-type: none"> • Restricted to a total of 240 characters (letters, digits, dash or period) • Parts of the name within the device name; in other words, a string between two periods, must not exceed a maximum of 63 characters. • No special characters such as umlauts (ä, ö etc.), brackets, underscore, slash, blank etc. The dash is the only permitted special character. • The device name must not begin or end with the "-" character. • The device name must not begin with numbers. • The device name must not have the structure n.n.n.n (n = 0...999). • The device name must not begin with the character string "port-xyz-" (x, y, z = 0...9).
IOL_CALL Function Block Timeout (1-20) (Default: 20)	The timeout value in seconds for IOL_CALL function block.

3.6 SETTING THE IO DEVICE UPDATE TIME


Use the appropriate procedure for your environment:

- STEP 7 V.5.5
- TIA Portal V13


3.6.1 STEP 7 V5.5

Use the following procedure to set the IO Device Update Time.

1. Double-click the **Ethernet(1): PROFINET-IO-System (100)**.



2. In the *Properties - PROFINET IO-System* window, select the **Update Time** tab, as shown in the image below.




3. Set the desired update time. The fastest IO device update time is 8ms.

3.6.2 TIA Portal V13

Use the following procedure to set the IO Device Update Time.

1. Double-click the IOLM in the **Device configuration | Network** view.
2. On the Properties | General tag, select PROFINET interface [X1] | Advanced options | Real time settings.
3. Select the **Can be set** option and set the update time to the desired value from the list. The fastest IO device update time is 8ms.



3.7 CONFIGURING IO-LINK PORTS

The IO-Link Master gateway has two categories of IO modules:

- IO-Link port modules (refer to par. 3.7.1)
- Port status modules (refer to par. 3.7.3)

IO modules are used to configure IO-Link ports and exchange PDI and PDO data with various IO-Link devices and digital I/O devices.

3.7.1 IO-Link Port Modules

An IO-Link port can be configured as one of the following:

- IO-Link Mode
- SIO Digital In Mode
- SIO Digital Out Mode.

IO-Link Port modules are used to configure the mode of an IO-Link port.

All the IO-Link modules start with the IO-Link (that is: IO-Link In, IO-Link Out and IO-Link In/Out) configure the corresponding IO-Link port as IO-Link Mode. An SIO Digital In module configures the IO-Link port as SIO Digital In Mode. Similarly, an SIO Digital Out module configures the port as SIO Digital Out Mode.

- An **IO-Link module** can be input only, output only or both. In addition, there are different modules with various IO data sizes (1 to 32 bytes). For example, the IO-Link In/Out 4 bytes module is for an IO-Link device that supports up to 4-byte PDI data and 4-byte PDO data. If you do not find an exact matching IO size, select the next size (larger). For instance, use IO-Link in 16-bytes module for an IO-Link device that has 10-byte PDI data. The unused PDI data is filled with zeros.
- For **SIO Digital In module**, the PDI data is fixed at 1-byte. A high voltage on the IO-Link port C/Q Pin results in a 0x01 PDI data; a low voltage on the C/Q Pin results in a 0x00 PDI data.
- For **SIO Digital Out module**, the PDO data is fixed at 1-byte. A zero output value from an SIO Digital Out module sets the IO-Link port C/Q pin to low voltage. Any non-zero output value sets the C/Q pin to high voltage.

<i>IO-Link Port Module Input Data Format</i>	
Byte Offset	Description
0	PDI Data Block byte 0
1	PDI Data Block byte 1
...	...
31	PDI Data Block byte 31

<i>IO-Link Port Module Output Data Format</i>	
Byte Offset	Description
0	PDO Data Block byte 0
1	PDO Data Block byte 1
...	...
31	PDO Data Block bytes 31

3.7.1.1 IO-Link Port Settings (IO-Link Port Module Parameters)

Additional IO-Link port settings can be configured by using module parameters. Use the appropriate procedure for your environment:

- STEP 7 V5.5
- TIA Portal V13

IO-Link Port Module Parameters	
IO-Link Port Config	
Minimum Cycle Time (Default: 4) Valid range: 4-538ms	The minimum or fastest cycle time at which the IO-Link device may operate. You can leave the Minimum Cycle Time set to the default value and the IO-Link Master negotiates with the IO-Link device for its minimum cycle time. The <i>IO-Link Diagnostics</i> page displays the Actual Cycle Time , which is the negotiated cycle time.
Data Storage Config	
Automatic Data Storage Upload Enable <i>Default: Off</i>	<p>When this option is initially set to On, the IOLM saves the data storage (if the data storage is empty) from the IO-Link device to that port. Some IO-Link devices update the data storage contents if you use the Teach buttons on the IO-Link device, but that is determined by the IO-Link device manufacturer.</p> <p>Automatic upload occurs when the Automatic Upload Enable option is set to On and one of these conditions exists:</p> <ul style="list-style-type: none"> • There is no upload data stored on the gateway. • The IO-Link device executes a request_ at upload function (generally because you have changed the configuration via Teach buttons). <p>Do not enable both Automatic Upload and Automatic Download at the same time, the results are not reliable among IO-Link device manufacturers.</p> <p>When a port contains data storage for an IO-Link device and if you attach a device whose Vendor and Device ID do not match, the IO-Link LED on the IOLM flashes red to indicate a wrong device is attached. In addition, the <i>IO-Link Diagnostics</i> page displays DV: Wrong Sensor in the IOLink State field.</p> <p>You should not enable Automatic Upload until after you have configured the IO-Link device attached to the port unless you want to capture the default settings. Refer to par. 7.2(Data Storage) for more information.</p>
Automatic Data Storage Download Enable <i>Default: Off</i>	<p>The data stored on the IOLM port is downloaded to the IO-Link device if:</p> <ol style="list-style-type: none"> 1. This option is selected. 2. The data stored on the IOLM port contains the same Vendor ID and ProductID as the IO-Link device connected to the port. 3. The data stored on the IOLM port is different than that of the IO-Link device. 4. The IO-Link device requests an upload and the Automatic Upload Enable option is set to Off. <p>If you change configuration parameters on the IO-Link device and want the parameters to remain loaded on the IO-Link device, you must disable the Automatic Download option because otherwise the IOLM will reload the data storage on the port down to the IO-Link device.</p> <p>Do not enable both Automatic Upload and Automatic Download at the same time, the results are not reliable among IO-Link device manufacturers.</p>
Validation Config	
Device Validation Mode (Default: None)	<p>Device Validation Mode provides these options:</p> <ul style="list-style-type: none"> • None - this disables Device Validation Mode. • Compatible - permits a compatible IO-Link device (same Vendor ID and Device ID) to function on the corresponding port. • Identical - only permits an IO-Link device to function on the corresponding port as defined in the following fields. <ul style="list-style-type: none"> - Vendor ID - Device ID - Serial Number
Vendor Id (0-65535)	This is required if you select a Device Validation Mode other than None .
Device Id (0-16777215)	This is required if you select a Device Validation Mode other than None .


Serial Num	This is required if you select Identical for the Device Validation Mode .
Data Validation Mode (Default: None)	There are three Data Validation Modes : <ul style="list-style-type: none"> • None - no data validation is performed on the port. • Loose - the slave device's PDI/PDO lengths must be less than or equal to the user-configured values. Strict - the slave device's PDI/PDO lengths must be the same as the user-configured values.
PDI Length (0-32)	This is input length of the PDI data field. This is required if you select a Data Validation Mode other than None.
PDO Length (0-32)	This is input length of the PDO data field. This is required if you select a Data Validation Mode other than None.

3.7.1.1.1 STEP 7 V5.5

Use the following information to configure IO-Link port module parameters.

1. Double-click an IO-Link Port module.
2. Select the **Parameters** table.

Available parameters are shown in this figure. The table above describes how to use the parameters.



Parameter	Value
Parameters	
IO-Link Port Config	
Minimum Cycle Time	4
Data Storage Config	
Automatic Upload Enable	Off
Automatic Download Enable	Off
Validation Config	
Device Validation Mode	None
Vendor Id	0
Device Id	0
Serial Num	
Data Validation Mode	None
PDI Length	0
PDO Length	0

3.7.1.1.2 TIA Portal V13

Use the following information to configure IO-Link port module parameters.

1. Open the **Device** view.
2. Click an IO-Link Port module.
3. On the **Properties | General tag**, select **Module parameters**. Available parameters are shown in the following figure. The table above describes how to use the parameters.

IO-Link In - 2 bytes_1 [Module] Properties Info Diagnostics

General IO tags System constants Texts

General
Inputs
Module parameters
I/O addresses
Hardware identifier

Module parameters

IO-Link Port Config

Minimum Cycle Time: 4

Data Storage Config

Automatic Upload Enable: Off
Automatic Download Enable: Off

Validation Config

Device Validation Mode: None
Vendor Id: 0
Device Id: 0
Serial Num:
Data Validation Mode: None
PDI Length: 0
PDO Length: 0

3.7.1.2 SIO Digital In/Out Module Parameters

Use the appropriate procedure to configure SIO digital in/out module parameters:


- STEP 7 V5.5
- TIA Portal V13

SIO Digital Input and Output Module Parameters	
SIO Digital Input	
Invert IO (Default: False)	If enabled, this inverts the I/O value. <ul style="list-style-type: none"> • False (Disabled - Do not invert IO) • True (Enabled - Invert IO) Note: This does not affect the Auxiliary Input.
Input Settling Time (0 - 10000ms) Default= 0ms	If non-zero and Mode is set to Digital-Input , the required time that the input status must remain constant before an input status change is reported.
Input Hold Time (0 - 10000ms) (Default: 0ms)	This is how long the IOLM keeps the input at its present value. For example, if the IOLM detects the input to go to high, and the hold time is X milliseconds, then the IOLM reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.
SIO Digital Output	
Invert IO (Default: False)	If enabled, this inverts the I/O value. <ul style="list-style-type: none"> • False (Disabled - Do not invert IO) • True (Enabled - Invert IO) Note: This does not affect the Auxiliary Input.
Default Digital Output (Default: Off)	Defines the default digital output value that is used at startup and when there is no active PDO controller. <ul style="list-style-type: none"> • Off (low voltage) • On (high voltage)


3.7.1.2.1 STEP 7 V5.5

Use the following procedure to configure SIO digital in/out module parameters.

1. Double-click an SIO Digital In or SIO Digital Output module.
2. Select the **Parameters** table.



SIO Input Module Parameters




SIO Output Module Parameters


3.7.1.2.2 TIA Portal V13

Use the following procedure to configure SIO digital in/out module parameters.

1. Open the **IOLM Device** view. Click an SIO Digital In or SIO Digital Output module.
2. On the **Properties | General tag**, select **Module parameters**.



SIO Input Module Parameters



SIO Output Module Parameters

3.7.2 Port Status Modules

There are two **Port Status** modules:

1. IO-Link Status Module
2. Digital I/O Module

3.7.2.1 IO-Link Status Module

IO-Link Status module is a 4-byte input only module that provides status information of all IO-Link ports. The following table shows the data format of IO-Link Status module.

Byte Offset	Status Byte Description
0	IO-Link Active
1	IO-Link PDI Valid
2	IO-Link Auxiliary Input
3	IO-Link Error

Each IO-Link port is mapped into one bit of each byte in the IO-Link Status module as shown in this table. For IO-Link Active status byte (offset 0), a bit one means the corresponding IO-Link port is active. An IO-Link port is considered as active when it is configured correctly and has a working IO-Link device attached.

A bit one in IO-Link PDI Valid status byte (offset 1) means the PDI data from the corresponding IO-Link port is valid. PDI Valid is only applicable to IO-Link port modules that have input data.

3. If there are any errors detected when communicating with the IO-Link device, the corresponding bit in the IO-Link Error status byte (offset 2) will be set to 1.
4. If a high voltage is detected on the auxiliary input of an IO-Link port, the corresponding bit in the IO- Link Auxiliary Input status byte (offset 3) will be set to 1.

See the following table for the description of each byte of the **IO-Link Status** module.

Status Byte	Status Bit Description
IO-Link Active	<ul style="list-style-type: none"> • 0: IO-Link port is not active, no IO-Link device is detected. • 1: IO-Link port is active, an IO-Link device is detected and operational.
IO-Link PDI Valid	<ul style="list-style-type: none"> • 0: IO-Link port PDI data is not valid. • 1: IO-Link port PDI data is valid.
IO-Link Auxiliary Input	<ul style="list-style-type: none"> • 0: Low voltage detected on the auxiliary pin of an IO-Link port. • 1: High voltage detected on the auxiliary pin of an IO-Link port.
IO-Link Error	<ul style="list-style-type: none"> • 0: No error detected • 1: An error detected. The further information about the error is available in PROFINET IO channel diagnostics.

3.7.2.2 Auxiliary Input Parameters

Use the appropriate procedure for your environment:


- STEP 7 V5.5
- TIA Portal V13

Port N Auxiliary Input Parameters	
Enable (Default: False)	<p>If enabled, the auxiliary input of Port n will be used.</p> <ul style="list-style-type: none"> • True (Enabled – Enable auxiliary input) • False (Disable – Do not use auxiliary input)
Invert Input (Default: False)	<p>If enabled, this inverts the auxiliary input of port n.</p> <ul style="list-style-type: none"> • False (Disabled - Do not auxiliary input) • True (Enabled – Invert auxiliary input)
Input Settling Time (ms) (Default: 0)	The auxiliary input settling time that remains constant before that input is considered/accepted
Input Hold Time (ms) (Default: 0)	This is how long the IO-Link Master keeps the input at its present value. For example, if the IO-Link Master detects the input to go to high, and the hold time is X milliseconds, then the IO-Link Master reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.

3.7.2.2.1 STEP 7 V5.5

Use this procedure to set the auxiliary input parameters:


1. Double-click the IO-Link Status module.
2. Select the **Parameters** table



3.7.2.2.2 TIA Portal V13

Use this procedure to set the auxiliary input parameters:

1. Open the **IOLM Device** view.
2. Click the **IO-Link Status** module.
3. On the **Properties | General tag**, select **Module parameters**.



3.7.2.3 Digital I/O Module

Digital I/O module has 1-byte input and 1-byte output. There are four digital I/O ports: DIO 1-4.

DIO 2 and DIO 4 can be configured as outputs. Use the following table to map DIO pins into bits of Digital IO module.

For input, a bit one means that high voltage is detected on that DIO pin. A zero means low voltage is detected on the DIO pin. Bits 4-7 are not in use and always return as zeros.

Digital I/O Module Bit Map								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
DIO Input	0	0	0	0	DIO 4	DIO 3	DIO 2	DIO 1
DIO Output	-	-	-	-	DIO 4	-	DIO 2	-

To use DIO 2 and DIO 4 as outputs, first they need to be configured as digital output.

Digital I/O Module Parameters	
Mode (Default: Digital Input)	<ul style="list-style-type: none"> • Off - Disable the digital I/O • Digital Input - monitors the digital input status on the DIO terminal screw connection • Digital Output - sets the digital output to either the default setting or value received from a controller. <p>Note: The Digital Output option is only available on D2 and D4.</p>
Invert I/O (Default: False)	<p>If enabled, this inverts the I/O value. If Mode is set to Digital Input, this inverts the input status. If Mode is set to Digital Output, this inverts the output.</p> <ul style="list-style-type: none"> • False (Disabled - Do not invert IO) • True (Enabled - Invert IO)

Default Digital Output (Default: Off)	Defines the default digital output value at startup before a controller can set the digital output, or when communication to all controller(s) has been lost. <ul style="list-style-type: none"> Off (low voltage) On (high voltage) Note: Only available on D2 and D4.
Input Settling Time 0-10000ms (Default: 0ms)	If non-zero and Mode is set to Digital Input , the required time that the input status must remain constant before an input status change is reported.
Input Hold Time 0-10000ms (Default 0ms)	This is how long the IOLM keeps the input at its present value. For example, if the IOLM detects the input to go to high, and the hold time is X milliseconds, then the IOLM reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.

Use the appropriate procedure for your environment:

- STEP 7 V5.5
- TIA Portal V13

3.7.2.3.1 STEP 7 V5.5


Use the following procedure to configure digital output.

- Double-click the Digital I/O module to open up the Parameters window, as shown in the following figure.
- Change the parameter **Mode** of DIO 2 and DIO 4 to **Digital Output**.

Once configured, writing a one to Bit 1 and Bit 3 of the Digital I/O module output sets DIO 2 and DIO 4 pins to high. Clearing Bit 1 and Bit 3 to zero sets DIO 2 and DIO 4 pins to low.




Note: Only Bit 1 and Bit 3 of the Digital I/O module output are in use. Changing the value of other bits has no effects.



3.7.2.3.2 TIA Portal V13

Use the following procedure to configure digital output.

1. Open the IOLM **Device** view.
2. Click the Digital I/O module.
3. On the **Properties | General tag**, select **Module parameters**.



3.7.3 Port Status Modules

IO-Link port settings (for example, port mode, minimum cycle time, data storage, validation, and device validation) should be configured through STEP 7 by adding correct modules and setting modules' parameters. Optionally, the same settings can be changed through the web interface.



Note: Any changes made through the web interface are overwritten when an application relation is established between a gateway and an IO controller.

This page provides special features such as Data Storage, Device Validation, and Data Validation.



Note: Do not configure Data Storage until the IO-Link device is configured.

You can use this procedure to configure IO-Link settings for each IO-Link port.

If an IO-Link device is attached to the port, no configuration is required for operation. If a digital input or output device is attached, it is necessary to change the Port Mode.

1. If necessary, open the IO-Link Master web interface with your web browser using the IP address.
2. **Click** Configuration | IO-Link Settings.
3. Click the **EDIT** button for the port or ports that you want to configure.
*Note: You can click each **EDIT** button and open all ports to quickly configure port parameters.*
4. Make appropriate selections for the device that you connected to that port.

Make sure you select the **DigitalIn** option for a digital input device and the **DigitalOut** option for a digital output device for the **Port Mode**.

The IOLM negotiates the Minimum Cycle Time so it is not necessary to set a cycle time unless you need a specific cycle time.

You can use the help system if you require definitions or values for the options or refer to the following table.



Note: Do not configure Data Storage until the IO-Link device is configured.



Note: Do not enable **Automatic Download** and then attempt device configuration as Automatic Download changes the settings back to what is stored on the IOLM.

5. Click the **SAVE** button for each port.
6. Return to the **IO-Link Diagnostics** page to verify that your changes have taken affect.

The screenshot shows the 'IO-Link Settings' web interface for 'PORT 1'. The interface includes a navigation menu at the top with options like 'IO-LINK', 'PROFINET ID', 'MODBUS/TCP', 'OPC UA', 'NETWORK', 'MISC', 'LOAD/SAVE', and 'CLEAR SETTINGS'. The main content area is titled 'IO-Link Settings @' and contains a form for 'IO-LINK PORT CONFIG'. The form has several sections: 'PORT 1' (with 'CANCEL' and 'SAVE' buttons), 'Data Storage Config', and 'Validation Config'. The 'Data Storage Config' section includes 'Storage Contents' (empty), 'Automatic Upload Enable' (OFF), and 'Automatic Download Enable' (OFF). The 'Validation Config' section includes 'Device Validation Mode' (None), 'Vendor Id' (0), 'Device Id' (0), 'Serial Num', 'Data Validation Mode' (None), and 'PDI Length' (0 byte). A red box highlights the 'SAVE' button, and a red text annotation says 'Collapse and expand to customize your view'.

The **Configuration | IO-Link Settings** page supports the following options.

IO-LINK Settings Page	
Port Name	User defined port or device description. <ul style="list-style-type: none"> Standard ASCII characters Max length = 80 characters
Port Mode <i>Default: IO-Link</i>	Selected IO-Link port mode. Valid settings are: <ul style="list-style-type: none"> Reset - Select to disable a port or to reset/restart an IO-Link port. IO-Link - Select to connect and operate an IO-Link device on the port. Digital In - Select if a DI device is attached to the port. Digital Out - Select if a DO device is attached to the port.
Invert SIO <i>Default: False</i>	If enabled and the Port Mode is Digital In or Digital Out , this option inverts the SIO value. <ul style="list-style-type: none"> False (Disabled - Do not invert SIO) True (Enabled - Invert SIO) <p>Note: This option does not affect the Auxiliary Input.</p>
Invert Auxiliary Input	If this option is enabled, the Auxiliary bit is inverted.
Default Digital Output <i>Default: Off</i>	If the port mode is Digital Out , defines the default digital output value that is used at startup and when there is no active PDO controller. <ul style="list-style-type: none"> Off (low voltage) - 0 On (high voltage) - 24V
Minimum Cycle Time <i>Default: 4</i>	The minimum, or fastest, cycle time at which the IO-Link device may operate. The valid range is 4-538 ms. You can leave the Minimum Cycle Time set to the default value and the IO-Link Master negotiates with the IO-Link device for its minimum cycle time. The IO-Link Diagnostics page displays the Actual Cycle Time , which is the negotiated cycle time.
Auxiliary Input Settling Time (0 - 10000)	The auxiliary input settling time that remains constant before that input is considered/accepted
Auxiliary Input Hold Time (0 - 10000)	This is how long the IO-Link Master keeps the input at its present value. For example, if the IO-Link Master detects the input to go to high, and the hold time is X milliseconds, then the IO-Link Master reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.
SIO Input Settling Time (0 - 10000)	The SIO input settling time that remains constant before that input is considered/ accepted.
SIO Input Hold Time (0 - 10000)	This is how long the IO-Link Master keeps the input at its present value. For example, if the IO-Link Master detects the input to go to high, and the hold time is X milliseconds, then the IO-Link Master reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.
Data Storage Config	
Storage Contents	Indicates that the data storage for the port is empty or displays the Vendor ID and Product ID of the data stored on that port.
Automatic Data Storage Upload Enable <i>Default: Off</i>	When this option is initially set to On , the IOLM saves the data storage parameters (if the data storage is empty) from the IO-Link device to the IOLM. Automatic upload occurs when the Automatic Upload Enable option is set to On and one of these conditions exists: <ul style="list-style-type: none"> There is no upload data stored on the gateway and the IO-Link device is connected to the port. The IO-Link device has the DS_upload bit on (generally because you have changed the configuration via Teach buttons or web page). When a port contains data storage for an IO-Link device and if you attach a device whose Vendor and Device ID do not match, the IO-Link LED on the IOLM flashes red to indicate a wrong device is attached. In addition, the <i>IO-Link Diagnostics</i> page displays DS: Wrong Sensor in the IOLink State field. Note: Not all device parameters are sent to data storage, this is determined by the IO-Link device manufacturer.
Automatic Data Storage Download Enable <i>Default: Off</i>	The data storage parameters on the IOLM are downloaded to the connected IO-Link device if: <ol style="list-style-type: none"> The Automatic Download option is enabled. The data stored on the IOLM port contains the same Vendor ID and Product ID as the IO-Link device connected to the port. Data storage parameters are also downloaded to the IO-Link device if configuration changes are made on the device causing the DS upload bit to turn on and automatic upload is not enabled. The IO-Link device requests an upload and the Automatic Upload Enable option is set to

	<p>Off.</p> <p>If you change configuration parameters on the IO-Link device and want the parameters to remain loaded on the IO-Link device, you must disable the Automatic Download option because otherwise the IOLM will reload the data storage on the port down to the IO-Link device.</p>
Data Storage Manual Ops	<p>The Manual Data Storage Ops option provides the following functionality, if data storage is supported by the IO-Link device.</p> <ul style="list-style-type: none"> • CLEAR - this clears any stored data for an IO-Link device on this port. • UPLOAD - this uploads and stores the IO-Link device configuration on the IOLM. <p>DOWNLOAD - this downloads the stored IO-Link device configuration from the IOLM to the IO-Link device attached to this port if the Vendor ID and Device ID match.</p>
Validation Config	
Device Validation Mode (Default: None)	<p>Device Validation Mode provides these options:</p> <ul style="list-style-type: none"> • None - this disables Device Validation Mode. • Compatible - permits a compatible IO-Link device (same Vendor ID and Device ID) to function on the corresponding port. • Identical - only permits an IO-Link device to function on the corresponding port as defined in the following fields. <ul style="list-style-type: none"> - Vendor ID - Device ID - Serial Number <p><i>Note: Connecting an IO-Link device that is different than the configured with Data Validation enabled will generate a DV: wrong sensor error.</i></p>
Vendor Id (0-65535)	<p>This is required if you select a Device Validation Mode other than <i>None</i>.</p> <p>The Vendor ID can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the Vendor ID in this field.</p>
Device Id (0-16777215)	<p>This is required if you select a Device Validation Mode other than <i>None</i>.</p> <p>The Device ID can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the Device ID in this field.</p>
Serial Num	<p>This is required if you select Identical for the Device Validation Mode.</p> <p>The Serial Number can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the serial number in this field.</p>
Data Validation Mode (Default: None)	<p>There are three Data Validation Modes:</p> <ul style="list-style-type: none"> • None - no data validation is performed on the port. • Loose - the slave device's PDI/PDO lengths must be less than or equal to the user-configured values. <p>Strict - the slave device's PDI/PDO lengths must be the same as the user-configured values.</p>
PDI Length (0-32)	<p>This is input length of the PDI data field.</p> <p>This is required if you select a Data Validation Mode other than <i>None</i>.</p> <p>The PDI Length can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the PDI length in this field.</p>
PDO Length (0-32)	<p>This is input length of the PDO data field.</p> <p>This is required if you select a Data Validation Mode other than <i>None</i>.</p> <p>The PDO Length can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the PDO length in this field</p>
GET ATTACHED (Button)	<p>After opening a port for editing, you can click the GET ATTACHED button to automatically populate the following fields with data from the IO-Link device:</p> <ul style="list-style-type: none"> • Vendor Id • Device Id • Serial Num • PDI Length <p>PDO Length</p>

4 CONNECTING DEVICES

4.1 OVERVIEW

The **C/Q** pin for the IO-Link ports in SIO mode for all models:

- **DI** – sinking input
The **DI** pin on the IO-Link ports for all models is a sinking input.
- **DO** – PNP/NPN (push/pull) output

The following table provides definitions of the terminology used above.


Term	Definition
PNP output	This is an output that can source current: the (+) side of the device is connected to the output and the (-) side of the device is connected to (-) of the supply. The device is powered when the output LED is on.
NPN output	This is an output that sinks current: the (-) of the device is connected to the output and the (+) side of the device is connected to (+) side of the supply. The device is powered when the output LED is off.
Sinking input	This sinks current into the IO-Link Master so a positive voltage will cause the input to turn on. Note: Using NPN with inputs is not correct as NPN describes an output situation. However, some vendors describe their inputs as accepting a certain type of sensor output, so in this case a sinking input will accept a PNP output sensor.

4.2 CBX-IOL-8-PNIO IO-LINK PORTS

The CBX-IOL-8-PNIO provides eight IO-Link ports with M12, 5-pin female/A coded connectors. Each port has robust over-current protection and short circuit protection on its L+/L- power output and C/Q IO-Link signal. The pin-out for each IO-Link port is per the IO-Link standard and is provided in the following table:

This table provides signal information for the IO-Link connectors.

Pin	Signal	Description
1	L+	IO-Link device power supply (+24V)
2	DI	Digital input
3	L-	IO-Link device power supply (0V)
4	C/Q	Communication signal, which supports SDCI (IO-Link) or SIO (standard input/output) digital I/O
5	FE	Functional Earth (electronics wiring)



The standard SDCI (IO-Link) transmission rates are supported:

- COM1 at 4.8 Kbps
- COM2 at 38.4 Kbps
- COM3 at 230.4 Kbps

There are active over-current limiter electronics for each port in the CBX-IOL-8-PNIO that detects the overload/short-circuit condition within a few milliseconds and shuts off the output power to protect the

port and the devices connected to it. The port’s power output self-recovers and restores to normal immediately after the overload or short-circuit condition is removed.

The over-current limiter circuit for L+/L- pins is separate circuits than the over-current limiter circuit for the C/Q output pin. When a port is affected by overload/short-circuit condition, it does not affect the operation of the other ports. All other ports will continue to operate normally without any glitch or interruption. The current output capacity, cutoff current, and power sharing/budgeting for L+/L- and C/Q signal for the ports on the CBX-IOL-8-PNIO are as follows.

CBX-IOL-8-PNIO Port	L+/L-			C/Q		
	Output Current Capacity (max.)	Overload Cutoff Current	Short-Circuit Protection	Output Current Capacity (max.)	Overload Cutoff Current	Short-Circuit Protection
Port 1: Independent over-current limiter circuits/IC for L+/L- and C/Q pins	1.6A	1.65A	Yes	200mA	400mA	Yes
Port 3: Independent over-current limiter circuits/IC for L+/L- and C/Q pins	1A	1.05A	Yes	200mA	400mA	Yes
Ports 2 and 4 (Pair) Ports 5 and 7 (Pair) Ports 6 and 8 (Pair) There’s one independent over-current limiter that protects L+/L- pins on each pair of ports, for example: Port 2 and 4. This allows you to do power budgeting on pair of ports that allows flexibility in the application. The combined overload cutoff current on a pair of ports is 1.05A for the L+/L- pins. As long as the cutoff current of 1.05A is not exceeded, the current output could be budgeted between a pair of ports such as, Port 2 and 4 any way you want. For example, Port 2 output can be at 900mA and Port 4 output can be at 100mA. Or, Port 2 could be left open and Port 4 output can be at 1A.	500mA/ port pair (1A output power budget per port pair)	1.05A/port pair	Yes	200mA*/ port	400mA*/ port	Yes
* Each port’s C/Q pin has its own independent over-current limiter circuit and are not combined. The current output of C/Q pin for each port is also independently controlled and cannot be budgeted with other ports.						

Use the following procedure to attach IO-Link or digital input/output devices to the ports.

1. Securely attach the IO-link cable between the IO-Link or digital input/output device and the IO-Link port.



Note: Make sure that you tighten the cables properly to maintain IP67 integrity.

2. If necessary, securely attach a connector cap to prevent dust or liquids from getting into any unused ports. Connector caps were shipped with the IOLM.



Note: IO-Link ports must have an approved cable or protective cover attached to the port to guarantee IP67 compliance.

3. If necessary, configure IO-Link port parameters using the Configuration | IO-Link Settings page to configure the port mode.
 - If an IO-Link device is attached to the port, the IO-Link LED should now be lit green and the device is receiving power.
 - If a digital input or output device is attached to the IO-Link port, after the port is configured for digital input or output on the **IO-Link Settings** page, the IO-Link LED does not light but when an event occurs:
 - Digital input causes the DI LED to flash.
 - Digital output causes the IO-Link LED to flash.

5 LOADING AND MANAGING IODD FILES

There are several **Attached Devices** pages that support IO-Link Device Description (IODD) file management.

5.1 IO-LINK DEVICE DESCRIPTION FILES PAGE

Use the IO-Link Device Description Files page to update (upload) and delete IO-Link Device Description (IODD) files associated with this IOLM. In addition, you can review the IODD xml file by clicking the IODD FILENAME in the table after loading the IODD file.



Note: You will need to download the appropriate IODD files from your IO-Link device manufacturer.

The IOLM provides 15790K of space to store IODD files. The IOLM includes the following default IODD files, which cannot be deleted.

- IODD-StandardDefinitions1.0.1.xml
- IODD-StandardUnitDefinitions1.0.1.xml
- IODD-StandardDefinitions1.1.xml
- IODD-StandardUnitDefinitions1.1.xml



Note: You can use the **Configuration | Save/Load** feature to backup your IODD files. You can save the configuration file from an IOLM that has IODD files installed and then load that configuration file to another IOLM to quickly load the IODD files.

5.1.1 Preparing IODD Files to Upload

After downloading the IODD files for the IO-Link device from the IO-Link sensor or actuator manufacturer, you may need to unzip the file and locate the appropriate **xml** file for the device.

- Some IODD zip files contain the **xml** files and supporting image files for a single product. This type of zip file can be immediately loaded onto the IOLM.
- Some IODD zip files contain the files for multiple products. If you upload this type of IODD zip file, the IOLM loads the first **xml** file and the associated image files, which may or may not correspond to the IO-Link device connected to the port. If you need to zip the appropriate files, the following information may be useful:
 - Unzip the package and locate the **xml** file needed for your IO-Link device.

- Open the **xml** file and search for the **productID**, which identifies the IO-Link device.
- Zip the **xml** file along with the supporting images. There are several ways to locate the supporting images:
 - Locate the appropriate images using the **xml** file.
 - Load only the **xml** file and the IOLM notifies you what files are missing. Use the **UPDATE** feature to upload the missing images.
 - Zip the **xml** with all the images and the IOLM ignores (and not upload) any unused files and notifies which files did not upload.



Note: Image files are not required for IO-Link device configuration.

5.1.2 Uploading IODD Zip Files

You can use the following procedure to upload IODD zip files.

1. Click **Attached Devices** and **IODD FILES**.
2. Click the **UPLOAD FILE** button.
3. Click the **CHOOSE FILE** button and browse to the file location.
4. Highlight the **zip** file, click **Open** and then the **UPLOAD** button.

The screenshot shows the 'IO-Link Device Description Files' interface. At the top, there is a navigation bar with 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. Below this, there are tabs for 'IODD FILES', 'SUMMARY', and 'PORT 1' through 'PORT 8'. The main content area is titled 'IO-Link Device Description Files' and contains a section for 'User IODD files (click filename to view)'. A table lists three files:

VENDOR	DEVICE	IODD FILENAME	DEVICE IMAGE	VENDOR IMAGE	SIZE
334	196609	DATALOGIC-570-20120708-1000L1.xml	dataLogic-570-pfc.png	dataLogic-logo.png	91K
412	1	dataLogic-565TOF-20151015-1000L1.xml	dataLogic-565tof-pfc.png	dataLogic-logo.png	45K
412	2	dataLogic-550C-20180717-1000L1.xml	dataLogic-dataLogic-550C-pfc.png	dataLogic-logo.png	71K

Below the table, there are buttons for 'CHOOSE FILE' (with 'No file chosen' text), 'UPLOAD' (highlighted with a red box), 'CANCEL', and 'DELETE SELECTED'. A checkbox for 'Standard IO-Link Definitions' is also visible.

5. If necessary, click **OK**



Note: Only images referenced in the xml file load to the IOLM and the remaining files are ignored.

- If desired, you can view the **xml** file by clicking the **IODD FILENAME** in the table.

The screenshot shows the Datalogic IO-Link Master web interface. The top navigation bar includes 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. The user is logged in as 'CBX-810L-PN10'. The main content area is titled 'IO-Link Device Description Files' and contains a table of 'User IODD files'. The table has columns for Vendor, Device, IODD Filename, Device Image, Vendor Image, and Size. The first row is highlighted, and the 'IODD FILENAME' cell is red-bordered. Below the table are buttons for 'CHOOSE FILE', 'UPLOAD', 'CANCEL', and 'DELETE SELECTED'. A note indicates 'Missing files listed in red'.

VENDOR	DEVICE	IODD FILENAME	DEVICE IMAGE	VENDOR IMAGE	SIZE	
334	196809	DATALOGIC-S70-20120706-1000L1.xml	dataLogic-s70-pic.png	dataLogic-Logo.png	96K	
412	1	dataLogic-565TOP-20151015-1000L1.xml	dataLogic-565top-pic.png	dataLogic-Logo.png	45K	
412	2	DataLogic-510C-20180717-1000L1.xml	dataLogic-dataLogic-s100-pic.png	dataLogic-Logo.png	71K	

- Click the hyperlink at the top of the page if you want to view the **xml** file in your browser.
- Optionally, verify that the correct **xml** file was loaded using the **Summary** page.

5.1.3 Uploading xml Files or Supporting Files

You can use the following procedure to upload **xml** or supporting image files.

1. Click **Attached Devices** and **IODD FILES**.
2. Click the **UPLOAD FILE** button.
3. Click the **CHOOSE FILE** button and browse to the file location.
4. Highlight the **xml** or image file and click **Open**.



Note: The **xml** file must be loaded before the IOLM will load the associated image files.

5. Click the **UPLOAD** button.

The screenshot shows the 'IODD FILES' section of the software. At the top, there is a navigation bar with 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. The 'Advanced' tab is selected. Below the navigation bar, there are tabs for 'IODD FILES', 'SUMMARY', and 'PORT 1' through 'PORT 8'. The main content area is titled 'IO-Link Device Description Files' and contains a table of 'User IODD files'. The table has columns for 'VENDOR', 'DEVICE', 'IODD FILENAME', 'DEVICE IMAGE', 'VENDOR IMAGE', and 'SIZE'. Three rows are visible, with the third row's 'DEVICE IMAGE' cell containing a red error message: 'dataLogic-dataLogic-s500-pic.png'. Below the table, there is a 'CHOOSE FILE' button, a file name 'dataLogic-S6-DD1.1.xml', and an 'UPLOAD' button highlighted with a red box. There is also a 'DELETE SELECTED' button.



Note: The IOLM notifies you what files are missing. The missing files do not affect the operation of the IODD Port page but the product image and logo for the IO-Link device company do not display.

This screenshot is similar to the previous one, showing the 'IODD FILES' section. The 'Advanced' tab is selected. The table of 'User IODD files' is shown, with the third row's 'DEVICE IMAGE' cell containing a red error message: 'dataLogic-dataLogic-s500-pic.png'. A red box highlights this error message. Above the table, there is a label 'Missing files listed in red' also highlighted with a red box. Below the table, the 'CHOOSE FILE' button is disabled and shows 'No file chosen'. The 'UPLOAD' and 'CANCEL' buttons are visible.

6. Optionally, use the following steps to load image files:
 - a. Select the row in the table that contains the **xml** file by clicking the check box.
 - b. Click the **UPLOAD FILE** button.
 - c. Click the **Choose File** button and browse to the file location.



- d. Highlight the file and click **Open**.
- e. Click the **UPLOAD** button.
- f. Optionally, verify that the correct xml file was loaded using the Summary page.

5.1.4 Viewing and Saving IODD Files

Use the following procedure to view the contents of an IODD file.

1. If necessary, click **Attached Devices** and **IODD Files**.
2. Click the **IODD FILENAME** in the table that you want to review. A pop-up window displays the contents of the IODD file.
3. Optionally, click the file name hyperlink at the top of the window to view the formatted file or if you want to save a copy of the file to another location.




5.1.5 Deleting IODD Files

Use the following procedure to delete an IODD file set from the IOLM.

1. If necessary, click **Attached Devices** and **IODD Files**.
2. Check the corresponding row of the IODD file that you want to delete.
3. Click the **DELETE SELECTED** button.



4. Click **CONTINUE** to the Delete files? message.



5.2 IO-LINK DEVICE CONFIGURATION SUMMARY PAGE

The **IO-Link Device Configuration Summary** page provides basic device configuration (device profile) information for ports with valid IO-Link devices attached. The **Configuration Summary** page retrieves information that resides on the IO-Link device from the manufacturer.

A file name displayed in the **IODD Name** field for a port indicates that a valid IODD file is associated with that device. If the field is empty, that indicates that a valid IODD file has not been loaded.

You can review complete IODD file information on a port by port basis by clicking the **MORE** button next to the port in question or by clicking the **PORT** menu selection in the navigational bar.

Use the following steps to access the **IO-Link Device Configuration Summary** page.

1. Click **Attached Devices**.
2. Click **SUMMARY**.



Note: The **Configuration Summary** page takes several minutes to completely load as each device is queried

3. Click the **MORE** button or the corresponding **Port** (in the navigational bar) to configure the IO-Link device parameters for a specific device. See chap. 6 more information.

The screenshot shows the 'IO-Link Device Configuration Summary' page. At the top, there is a navigation bar with 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. The user is logged in as 'CBX-SIOL-PNIO'. Below the navigation bar, there is a breadcrumb trail: 'IODD FILES > SUMMARY > PORT 1 > PORT 2 > PORT 3 > PORT 4 > PORT 5 > PORT 6 > PORT 7 > PORT 8'. The main content area is titled 'IO-Link Device Configuration Summary' and contains a table with the following data:

DEVICE SETTINGS	PORT 1	MORE	PORT 2	MORE	PORT 3	MORE	PORT 4	MORE	PORT 5	MORE	PORT 6	MORE	PORT 7	MORE	PORT 8	MORE
Vendor Name	DATALOGIC		DATALOGIC		DATALOGIC AUTOMATION S.R.L.											
VENDOR	334		412		412											
DEVICE	196609		2		1											
Description	S70 Dual Display Fiber Amplifier		Diffuse proximity Sensor		TOF Background Suppressor Sensor											
IO-Link Version	1.1		1.1		1.1											
Hardware Version	unsupported by device		RevAC		1.0.0											
Firmware Version	1.1.94		3.0.2		1.0.2											
Baud Rate	38400		38400		38400											
SIO Mode	Yes		Yes		Yes											
Min Cycle Time	2.6 ms		14.8 ms		2.3 ms											
IODD Name	DATALOGIC-S70-20120706-IODD01.1.xml		Datalogic-S90C-20180717-IO-DDI.1.xml		datalogic-S65TOF-20151015-IODD01.1.xml											
Serial Number	20160408095813		0000000000000001		B18A00498											

6 CONFIGURING IO-LINK DEVICES

This chapter discusses using the **Attached Devices | Port** pages to change IO-Link device parameters.



Note: Optionally, you can use traditional methods such as: PLC interfaces or HMI/SCADAs, depending on your protocol to configure the IO-Link devices.

6.1 PORT PAGES OVERVIEW

You can use the **Attached Devices | Port** page for a port to review and easily edit the IO-Link device configuration or view Process Data.

IO-Link Device - Port 1 User role menu

Parameter Name	Index	Subindex	Value	Description	R/W	Unit	Min	Max	Comments	Gradient	Offset	Data Type	SimpleDatatype	BitLength	FixedLength
Identification															
Vendor Name	16		DATALOGIC		RO							StringT			64
Vendor Text	17		Value in detection		RO							StringT			64
Product Name	18		S70-S-E1-PZ		RO							StringT			64
Product ID	19		S70-S-E1-PZ		RO							StringT			64
Product Text	20		S70 Dual Display Fiber Amplifier		RO							StringT			64
Serial Number	21		20160408095813		RO							StringT			16
Firmware Version	23		1.1.94		RO							StringT			64
Application Specific Tag	24		Value in detection		RW							StringT			32

Expand or collapse parameter groups to customize your view

IO-Link Device ISDU Interface - Port 1 Port Status: Operational, PDI Valid

The **Port** page provides two IO-Link device configuration methods:

- **IO-Link Device Port** table (GUI), which depends on the appropriate IODD file loaded from the IO-Link device manufacturer onto the IOLM.
- **IO-Link Device ISDU Interface - Port**, which can be used with or without IODD files loaded.


The **IO-Link Device Port** table provides detailed information about the indexes and sub-indexes. Not all indexes have sub-indexes.

Parameter Name	Index	SubIndex	Value	Description	R/W	Unit	Min	Max	Comments	Gradient	Offset	DataType	SimpleDataType	BitLength	Fixed
- Identification															
- Parameter															
- Device Settings															
Standard Command	2		<input type="button" value="Restore Factor"/>	130:Restore Factory Settings	WO		130	130	value range:130			UIntegerT		8	
Standard Command	2		<input type="button" value="Pointer ON/OFF"/>	160:Pointer ON/OFF	WO		160	160	value range:160			UIntegerT		8	
Standard Command	2		<input type="button" value="Key Lock Set"/>	161:Key Lock Set	WO		161	161	value range:161			UIntegerT		8	
EmitterStatus	64	1		1:ON 0:OFF	RW*		0	1	value range:1;0			BooleanT		1	
KeyLock Status	65	0		Same as previous description	RO		0	1	value range:1;0			BooleanT		1	
External Teach	76	1		1:Active 0:Deactivated	RW		0	1	value range:1;0			BooleanT		1	
Output Mode	79	1		0:NPN 1:PNP	RO		0	1	value range:0;1			BooleanT		1	
Light/Dark Mode	80	1		0:DARK 1:LIGHT	RW		0	1	value range:0;1			BooleanT		1	
Hysteresis	81	0		2:20 1:10 0:10	RW	mm	0	2	value range:2;1;0			UIntegerT		8	
Device Access Locks															
Parameter (write) Access Lock	12	1*	0	0 1	RW*		0	1	value range:0;1			RecordT	BooleanT	1	

- If the IODD file follows IO-Link specifications, an asterisk next to RW means that parameter is not included in Data Storage.
- If a Sub-index has an asterisk next to it in the GUI, that means that sub-index is not sub-indexable. This may be useful information when using the IO-Link Device ISDU Interface or programming your PLC.

This example shows that Index 109 contains 10 sub-indexes.

When you perform a **GET** on Index 109 using the ISDU Interface, these are the results:



109	1*
109	2*
109	3*
109	4*
109	5*
109	6*
109	7*
109	8*
109	9*
109	10*


The GUI displays this information about Index 109.

Index	Subindex	Value	Description	R/W	Unit	Min	Max	Comments	Gradient	Offset	Data Type	Simple Datatype	Bit Length	F
109	1*	2246		RO				dynamic parameter			RecordT	UIntegerT	16	
109	2*	2515		RO				dynamic parameter			RecordT	UIntegerT	16	
109	3*	3		RO				dynamic parameter			RecordT	UIntegerT	8	
109	4*	1		RO				dynamic parameter			RecordT	UIntegerT	8	
109	5*	1		RO				dynamic parameter			RecordT	UIntegerT	8	
109	6*	0		RO				dynamic parameter			RecordT	UIntegerT	8	
109	7*	0		RO				dynamic parameter			RecordT	UIntegerT	8	
109	8*	0		RO				dynamic parameter			RecordT	UIntegerT	16	
109	9*	0		RO				dynamic parameter			RecordT	UIntegerT	8	
109	10*	0		RO				dynamic parameter			RecordT	UIntegerT	8	


Which can be illustrated as:

```
00 00 | 00 80 | 00 | 00 | 00 | 00 | 01 | 00 00 | 00 | 00
  1   |   2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10
```


Access the **Process Data** page by selecting **Process Data** from the drop box next to the port number.



This shows a typical **Process Data** page.



If the correct IODD file has not been loaded or the IO-Link device does not support PDO, then you will receive this message.



6.2 EDITING PARAMETERS – IO-LINK DEVICE – PORT TABLE

Use the following procedure to edit IO-Link device parameters using the **IO-Link Device Port** table.



Note: You may want to verify that the **Automatic Download Enable for Data Storage** option on the **Configuration | IO-Link Settings** page is NOT set to **On** as this can cause unreliable results on the corresponding port.

1. If you have not done so, load the IODD file from the IO-Link device manufacturer (see Loading and Managing IODD Files).
2. Access the appropriate **Port** page by clicking **Attached Devices** and then the **Port** number that you want to configure.
3. Click the **EDIT** button after all of the device information is populated in the table.
4. Scroll down the table and make appropriate parameter changes for your environment.



Note: An IODD file may not contain all IO-Link device settings depending on the IO-Link device manufacturer. If you need to change a parameter that is not displayed in the **IO-Link Device - Port** table, you can refer to the IO-Link Device Operators Manual and use the **IO-Link Device ISDU Interface** to change the settings.

You may need to scroll to the right in the table to view applicable parameter values if the parameter is not selectable in a drop list.

The screenshot shows the 'IO-Link Device - Port 3' configuration page. The table contains the following parameters:

Parameter (write)	Access Lock	Value	Units	Range
Device Access Locks				
Parameter (write) Access Lock	12	1*		0 1
Data Storage Lock	12	2*		Same as previous description
Local Parameterization Lock	12	3*		Same as previous description
Local User Interface Lock	12	4*		Same as previous description
Teach Settings				
Standard Command	2	Teach Q1		162:Teach Q1
Standard Command	2	Teach Q2		163:Teach Q2
Teach Status_Q1	66	0		1:Error 0:OK
Teach Status_Q2	67	0		Same as previous description
Switching Point 1 Value	72	2000		
Switching Point 2 Value	73	635		
Switching Point Configuration	74	3		0:Deactivated 1:Window 2:Single Point 3:Two Points

5. Click the **SAVE** button after editing the parameters.

6.3 RESETTING IO-LINK DEVICE PARAMETERS TO FACTORY DEFAULT

In the event you want to reset the IO-Link device to factory default, typically the IODD file provides the ability from the IO-Link device manufacturer. Use the following example to reset an IO-Link device.

1. Click the **COMMAND** button and locate the **Restore Factory** button.
2. Click the **Restore Factory** or **Load Factory Settings** button.



Note: The name of the button is determined by the IO-Link device manufacturer.

The screenshot shows the 'IO-Link Device ISDU Interface - Port 3' window. The 'Device Settings' section is expanded, showing a list of parameters. The 'Restore Factory' button is highlighted with a red box. The table below shows the parameters and their settings.

Parameter Name	Index	Subindex	Value	Description	R/W	Unit	Min	Max	Comments	Gradient	Offset	Data Type	Simple Datatype	Bit Length	Fixed
Standard Command	2		Restore Factor...	130:Restore Factory Settings	WO		130	130	value range:130			UIntegerT		8	
Standard Command	2		Pointer ON/OFF	160:Pointer ON/OFF	WO		160	160	value range:160			UIntegerT		8	
Standard Command	2		Key Lock Set	161:Key Lock Set	WO		161	161	value range:161			UIntegerT		8	
EmitterStatus	64	1		1:ON 0:OFF	RW*		0	1	value range:1:0			BooleanT		1	
KeyLock Status	65	0		Same as previous description	RO		0	1	value range:1:0			BooleanT		1	
External Teach	76	1		1:Active 0:Deactivated	RW		0	1	value range:1:0			BooleanT		1	
Output Mode	79	1		0:NPN 1:PNP	RO		0	1	value range:0:1			BooleanT		1	
Light/Dark Mode	80	1		0:DARK 1:LIGHT	RW		0	1	value range:0:1			BooleanT		1	
Hysteresis	81	0		2:20 1:50 0:80	RW	mm	0	2	value range:2:1:0			UIntegerT		8	
Device Access Locks															
Parameter (write) Access Lock	12	1*	0	0 1	RW*		0	1	value range:0:1			RecordT	BooleanT	1	

3. Click **OK** when the *Refresh* message appears.

The screenshot shows the 'IO-Link Device ISDU Interface - Port 3' window. A 'Refresh?' dialog box is displayed over the 'Restore Factory' button. The dialog box contains the following text:

Refresh?
Your attached device's settings might have been affected by the recent commands you sent.
Click OK to refresh.

The dialog box has 'OK' and 'CANCEL' buttons.

6.4 EDITING PARAMETERS – IO-LINK DEVICE ISDU INTERFACE – PORT

The **IO-Link Device ISDU Interface** follows these guidelines:

- If necessary, convert hexadecimal ISDU index numbers to decimal, you must enter the decimal value for the ISDU Block Index and ISDU Sub-index numbers.
- You must enter the hexadecimal value for the IO-Link device parameters.

If the appropriate IODD files has been loaded, you can use the **IO-Link Device - Port** table to determine the index numbers and acceptable values for each parameter.



Note: An IODD file may not contain every IO-Link device setting depending on the IO-Link device manufacturer. If you need to change a parameter that is not displayed in the **IO-Link Device - Port** table, you can refer to the IO-Link Device Operators Manual.

If an IODD file has not been loaded for an IO-Link device, refer to the IO-Link Device Instruction Manual to determine the ISDU indexes.


6.4.1 Overview

The following provides some basic information about the command usage and responses when using the ISDU Interface.


- You must enter the decimal value for the ISDU Block Index and ISDU Sub-index.
- The **GET** button retrieves the parameter value in hex from the IO-Link device. You may want to retrieve values to determine the data length.




- The **SET** button sends the value to the IO-Link device.




- After successfully changing a parameter, the IO-Link Master responds with a command executed notification.



- This message means that the IO-Link device defines the entry as an invalid setting.



- This message indicates that the IO-Link device cannot read the specified ISDU Block Index and Sub-index.




6.4.2 How to Use the Interface

Use the following procedure to edit parameters using the **IO-Link Device ISDU Interface - Port**.



Note: You may want to verify that the **Automatic Download Enable for Data Storage** option on the **Configuration | IO-Link Settings** page is **NOT** set to **On** as this can cause unreliable results on the corresponding port.

- Click the **+** next to the **IO-Link Device ISDU Interface** to open the interface.



- Enter the ISDU Block Index number (decimal) that you want to edit.
- If applicable, enter the ISDU Sub-index (decimal).
- Edit the parameter (hex) and click the **SET** button.



- Verify that a *command executed* message returns.
- If the IODD file is loaded, optionally click **REFRESH** to verify your changes.

7 UTILIZING IOLM FEATURES


7.1 SETTING USER ACCOUNTS AND PASSWORDS

The IOLM is shipped from the factory without passwords. See the following table if you want to see how permissions are granted.


Page	Admin	Operator	User
Log-in	Yes	Yes	Yes
Home	Yes	Yes	Yes
Diagnostics - All	Yes	Yes	Yes
Configuration - IO-Link Settings	Yes	Yes	View-only
Configuration - Digital I/O Settings (Applicable models)	Yes	Yes	View-only
Configuration - EtherNet/IP Settings	Yes	Yes	View-only
Configuration - Modbus/TCP	Yes	Yes	View-only
Configuration - OPC UA	Yes	Yes	View-only
Configuration - Network	Yes	View-only	No
Configuration - Misc	Yes	Yes	Yes
Configuration - Load/Save	Yes	Yes	View-only
Configuration - Clear Settings	Yes	No	No
Advanced - Software	Yes	No	No
Advanced - Accounts	Yes	No	No
Advanced - Log Files	Yes	Yes	Yes
Advanced - Licenses	Yes	Yes	Yes
Attached Devices - IO-Link Device Description Files	Yes	Yes	View-only
Attached Devices - IO-Link Device Configuration Summary	Yes	Yes	View-only
Attached Devices - IO-Link Device - Port	Yes	Yes	View-only

You can use this procedure to set up passwords for the IOLM.

1. Open your browser and enter the IOLM IP address.
2. Click **Advanced | ACCOUNTS**.



3. Click the **ADMIN** check box.
4. If applicable, enter the old password in the **Old Password** text box.
5. Enter the new password in the **New Password** text box.
6. Re-enter the password in the **Confirm Password** text box.
7. Optionally, click the **Operator** check box, enter a new password, and re-enter the password in the **Confirm Password** text box.
8. Optionally, click the **User** check box, enter the new password, and re-enter the password in the **Confirm Password** text box.
9. Click **Apply**.
10. Close the new window that displays a *Password saved* banner.




Accounts

Passwords saved : AdminPassword, OperatorPassword, UserPassword

ADMIN	(PASSWORD IS CONFIGURED)	<input type="checkbox"/>
Old Password	<input type="text"/>	
New Password	<input type="text"/>	
Confirm Password	<input type="text"/>	
OPERATOR	(PASSWORD IS CONFIGURED)	<input type="checkbox"/>
New Password	<input type="text"/>	
Confirm Password	<input type="text"/>	
USER	(PASSWORD IS CONFIGURED)	<input type="checkbox"/>
New Password	<input type="text"/>	
Confirm Password	<input type="text"/>	

Apply

11. Click the **Log out** button on the top navigation bar.
12. Re-open the web interface by selecting the appropriate user type in the drop list and entering the password.



Home

User:

Password:

Login

7.2 DATA STORAGE

Data storage is typically supported by IO-Link v1.1 devices. *Data storage* means that you can upload parameters from an IO-Link device to the IOLM and/or download parameters from the IOLM to the IO-Link device. This feature can be used to:

- Quickly and easily replace a defective IO-Link device
- Configure multiple IO-Link devices with the same parameters as fast as it takes to connect and disconnect the IO-Link device

To determine whether an IO-Link (v1.1) device supports data storage, you can check one of the following:

- **IO-Link Diagnostics** page - check the **Data Storage Capable** field to see if it displays **Yes**.
- **IO-Link Configuration** page - check to see if **UPLOAD** and **DOWNLOAD** buttons display under the **Data Storage Manual Ops** group. If only a **Clear** button displays, the device on the port does not support data storage.

7.2.1 Uploading Data Storage to the IOLM

The IO-Link device manufacturer determines which parameters are saved for data storage. Remember, the IO-Link device should be configured before enabling data storage unless you are using data storage to back up the default device configuration.

There are two methods to upload Data Storage using the **Configuration | IO-Link** page:

- **Automatic Enable Upload** - If a port is set to **On** for this option, the IOLM saves the data storage parameters (if the data storage is empty) from the IO-Link device to the IOLM.

When this option is enabled and another IO-Link device (different Vendor ID and Device ID), the **IO-Link Diagnostics** page displays a *DS: Wrong Sensor* in the **IOLink State** field and the IO-Link port LED flashes red, indicating a hardware fault.

Automatic upload occurs when the **Automatic Upload Enable** option is set to **On** and one of these conditions exists:

- There is no upload data stored on the gateway and the IO-Link device is connected to the port.
- The IO-Link device has the **DS upload** bit on (generally, because you have changed the configuration through Teach buttons or the web interface).



Note: Not all device parameters are sent to data storage. The IO-Link device manufacturer determines what parameters are sent to data storage.

- **Data Storage Manual Ops: UPLOAD** - Selecting the **UPLOAD** button saves the data storage from the IO-Link device to the IOLM. The contents of the data storage do not change unless it is uploaded again or cleared. Another IO-Link device with a different Vendor ID and Device ID can be attached to the port without causing a hardware fault.

7.2.2 Downloading Data Storage to the IO-Link Device

There are two methods to download Data Storage using the **Configuration | IO-Link Device** page:

- **Automatic Download Enable** - An automatic download occurs when the **Automatic Download Enable** option is set to **On** and one of these conditions exists:
 - The original IO-Link device is disconnected and an IO-Link device whose configuration data differs from the stored configuration data.
 - The IO-Link device requests an upload and the **Automatic Upload Enable** option is set to **Off**.



Note: Do not enable both Automatic Upload and Download at the same time, the results are not reliable among IO-Link device manufacturers.

- **Data Storage Manual Ops: DOWNLOAD** - Selecting the **DOWNLOAD** button downloads the data storage from the that port to the IO-Link device.

If an IO-Link device with a different Vendor ID and Device ID is attached to the port and a manual download is attempted, the IOLM issues a hardware fault.

7.2.3 Automatic Device Configuration

Use the following steps to use an IOLM port to configure multiple IO-Link devices with the same configuration parameters.

1. If necessary, configure the IO-Link device as required for the environment.
2. Click **Configuration| IO-Link**.
3. Click the **EDIT** button for the port for which you want to store the data on the IOLM.
4. Click the **UPLOAD** button.
5. Click the **CONTINUE** button to the *Continue to upload the data storage on IO-Link Master port [number]* message.

6. Click the **OK** button to the *Data storage upload successful on Port [number]* message.

7. Set the **Automatic Download Enable** option to **On**.

The screenshot shows the 'IO-Link Settings' page with a table for configuring four ports. The 'Automatic Download Enable' option for Port 3 is highlighted with a red box and labeled '1.'. The 'SAVE' button for Port 3 is also highlighted with a red box and labeled '2.'.

IO-LINK PORT CONFIG	PORT 1	PORT 2	PORT 3	PORT 4
Port Name	IO-Link Port 1	IO-Link Port 2	IO-Link Port 3	IO-Link Port 4
Port Mode	IOLink	IOLink	IOLink	IOLink
Invert SIO	false	false	<input type="checkbox"/>	false
Invert Auxiliary Input	false	false	<input type="checkbox"/>	false
Default Digital Output	Off	Off	Off	Off
Minimum Cycle Time (4 - 538)	4 ms	4 ms	4 ms	4 ms
Auxiliary Input Settling Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms
Auxiliary Input Hold Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms
SIO Input Settling Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms
SIO Input Hold Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms
Data Storage Config				
Storage Contents	empty	empty	338:2096	empty
Automatic Upload Enable	Off	Off	Off	Off
Automatic Download Enable	Off	Off	On	Off
Data Storage Manual Ops				
	CLEAR	CLEAR	CLEAR	CLEAR
			UPLOAD	
			DOWNLOAD	
Validation Config				
Device Validation Mode	None	None	None	None
Vendor Id (0 - 65535)	0	0	0	0
Device Id (0 - 16777215)	0	0	0	0

8. Click **SAVE**.

9. Click **Diagnostics | IO-Link**.

10. Replace the IO-Link device on that port with the IO-Link device for which you want configured automatically.

11. Verify that the IO-Link device displays operational **Port Status** and the appropriate IO-Link State.

12. Repeat Steps 10 and 11 for as many devices as you want to configure.

7.2.4 Automatic Device Configuration Backup

The following procedure shows how to utilize data storage to automatically backup an IO-Link device configuration.



Note: You must configure data storage in PROFINET IO using Step 7. You can use data storage on the web page for temporary data storage related tasks.

Remember, if you adjust parameters using **Teach** buttons those values may or may not be updated in the data storage, which depends on the IO-Link device manufacturer. If you are unsure, you can always use the manual **UPLOAD** feature to capture the latest settings.

1. Click **Configuration | IO-Link**.
2. Click the **EDIT** button for the port for which you want to store the data on the IOLM.
3. Select **On** in the drop list for **Automatic Data Storage Upload Enable**.

4. Click **SAVE**.

When the **Configuration | IO-Link** page is refreshed, the **Storage Contents** field displays the **Vendor ID** and **Device ID**. In addition, the **IO-Link Diagnostics** page displays **Upload-Only** in the **Automatic Data Storage Configuration** field.

7.3 DEVICE VALIDATION

Device validation is supported by many IO-Link devices. **Device Validation Mode** provides these options:

- **None** - this disables **Device Validation Mode**.
- **Compatible** - permits a compatible IO-Link device (same Vendor ID and Device ID) to function on the corresponding port.
- **Identical** - only permits an IO-Link device (same Vendor ID, Device ID, and serial number) to function on the corresponding port.



Note: You must configure device validation in PROFINET IO using Step 7.

Use this procedure to configure device validation.

1. Click **Configuration | IO-Link Settings**.
2. Click the **EDIT** button.
3. Select **Compatible** or **Identical** for the **Device Validation** mode.




Note: Identical Device Validation requires a device serial number to operate.

4. Click the **GET ATTACHED** button or manually complete the Vendor ID, Device, ID, and serial number.

If the device does not have a serial number, you should not select **Identical** because the IOLM requires a serial number to identify a specific device.

The screenshot shows the 'IO-Link Settings' configuration page. At the top, there is a navigation bar with 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. Below this is a sub-navigation bar with 'IO-LINK', 'ETHERNET/IP', 'MODBUS/TCP', 'OPC UA', 'IOTHUB', 'NETWORK', 'MISC', 'LOAD/SAVE', and 'CLEAR SETTINGS'. The main content area is titled 'IO-Link Settings' and contains a table with columns for 'PORT 1', 'PORT 2', 'PORT 3', and 'PORT 4'. The table has several rows for configuration options like 'Port Name', 'Port Mode', 'Invert SIO', etc. The 'Device Validation Mode' row is highlighted with a red box and a '1.' annotation, showing 'Compatible' selected for Port 1. The 'GET ATTACHED' button in the bottom row for Port 1 is highlighted with a red box and a '2.' annotation. The 'SAVE' button in the top row for Port 1 is highlighted with a red box and a '3.' annotation.

- 5. Click the **SAVE** button. If the wrong or incompatible device is connected to the port, the IO-Link port LED flashes red and no IO-Link activity occurs on the port until the issue is resolved. In addition, the **IO-Link Diagnostics** page displays the following information.



7.4 DATA VALIDATION

You can use this procedure to configure data validation.



Note: You must configure device validation in PROFINET IO using Step 7.

1. Click **Configuration | IO-Link Settings**.
2. Click the **EDIT** button on the port you want to configure for data validation.
3. Select **Loose** or **Strict** to enable data validation.
 - **Loose** - the slave device's PDI/PDO lengths must be less than or equal to the user-configured values.
 - **Strict** - the slave device's PDI/PDO lengths must be the same as the user-configured values.
4. Click the **GET ATTACHED** button or manually enter the PDI and PDO length.

IO-Link Settings

IO-LINK PORT CONFIG	PORT 1	PORT 2	PORT 3	PORT 4	PORT 5	PORT 6	PORT 7	PORT 8
Port Name	Pressure#55	Flow Meter#50	Flow Meter#50	Proximity#76	Proximity#80	DI Proximity#28	Proximity#5	IOLink Port 8
Port Mode	IOLink	IOLink	IOLink	IOLink	IOLink	DigitalIn	IOLink	IOLink
Invert IO	false	false	<input type="checkbox"/>	false	false	false	false	false
Default Digital Output	Off	Off	Off	Off	Off	Off	Off	Off
Minimum Cycle Time (4 - 538)	4 ms	4 ms	4 ms	4 ms	4 ms	4 ms	4 ms	4 ms
Data Storage Config								
Storage Contents	empty	empty	empty	empty	empty	empty	empty	empty
Automatic Upload Enable	Off	Off	Off	Off	Off	Off	Off	Off
Automatic Download Enable	Off	Off	Off	Off	Off	Off	Off	Off
Data Storage Manual Ops								
	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR
		UPLOAD	UPLOAD		UPLOAD			
		DOWNLOAD	DOWNLOAD		DOWNLOAD			
Validation Config								
Device Validation Mode	None	Identical	None	None	None	None	None	None
Vendor Id (0 - 65535)	0	310	310	0	0	0	0	0
Device Id (0 - 16777215)	0	392	392	0	0	0	0	0
Serial Num		e0051171013	e0046171013					
Data Validation Mode	None	None	Strict	None	None	None	None	None
PDI Length (0 - 32)	0 byte	8 byte	8 byte	0 byte	0 byte	0 byte	0 byte	0 byte
PDO Length (0 - 32)	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte
	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED

5. Click the **SAVE** button.

If data validation fails, the IO-Link port LED flashes red and the **IO-Link Diagnostics** page displays an error.


7.5 IOLM CONFIGURATION FILES

You can use the web interface to save or load IOLM configuration files.

7.5.1 Saving Configuration Files

Use this procedure to save configuration files for the IOLM. The configuration files include all port settings, network settings, and encrypted passwords.

1. Click **Configuration | Load/Save**.
2. Click the **SAVE** button.



3. Click the **Save as** option and browse to the location that you want to store the configuration file.

7.5.2 Loading Configuration Files

Use this procedure to load a configuration file onto the IOLM.

1. Click **Configuration | Load/Save**.
2. Click the **Browse** button and locate the configuration file (.dcz extension).
3. Click the **LOAD** button.

Load or Save Configuration

Save Configuration

Select data to save:

- IOLM gateway configuration
- Datastorage contents
- IODD files

above data to file

Load Configuration

Select data to load:

- IOLM gateway configuration
- IOLM_network_configuration
- Datastorage contents
- IODD files


2. Select file to load: C:\1_Work_Files\IO-Link 1.

selected data from file

4. Click the **OK** button to close the *Configuration Uploaded* message that notifies you of what configuration parameters loaded.

7.6 CONFIGURING MISCELLANEOUS SETTINGS

The **Miscellaneous Settings** page includes the following options:



- **Menu Bar Hover Shows Submenu**

This option displays sub-menus for a category when you hover over the category name.

For example, if you hover over **Advanced**, the **SOFTWARE**, **ACCOUNTS**, **LOG FILES**, and **LICENSES** sub- menus display. You can click any sub-menu and avoid opening the default menu for a category.

- **Enable PDO Write From Attached Devices Port Page**

When enabled, it allows you to write PDO data to IO-Link slaves from the **Attached Devices | Port** page in the web user interface. See par. 7.6.2 or more information.



Note: The PDO write will not allow writes if the IOLM has a PLC connection. **This should never be enabled in a production environment.**

- **LED Flash**

You can force the IO-Link port LEDs on the IOLM into a flashing tracker pattern that allows you to easily identify a particular unit.


- Click the **ON** button to enable the LED tracker feature on the IOLM. The LEDs remain flashing until you disable the LED tracker feature
- Click the **OFF** button to disable the LED tracker.

7.6.1 Using the Menu Bar Hover Shows Submenu Option

Use this procedure to enable the **Menu Bar Hover Shows Submenu** option. If you enable this feature it displays the sub-menus for a category when you hover over the category name.

For example, if you hover over **Advanced**, the **SOFTWARE**, **ACCOUNTS**, **LOG FILES**, and **LICENSES** sub- menus display. You can click any sub-menu and avoid opening the default menu for a category.

1. Click **Configuration | MISC**.
2. Click the **EDIT** button.
3. Click **Enable** next to the **Menu Bar Hover Shows Submenu** option.
4. Click **SAVE**.



7.6.2 Enable PDO Write From Attached Devices Port Page

The purpose of this feature is for a **non-production** type of demonstration of the IOLM. You can enable this feature to get familiar with IO-Link or if you are commissioning a system and want to be able to test / get familiar with devices. It allows you to interact with a PDO device that does not have a PLC connection.

You must have set and signed into the IO-Link Master using an **admin** password.



Note: The PDO write will not allow writes if the IOLM has a PLC connection. **This should never be enabled in a production environment.**


Use this procedure to enable PDO write from the **Attached Devices | Port** page.

1. If necessary, log into the IOLM using the Administrator account.
2. Click **Configuration | MISC**.
3. Click the **EDIT** button.
4. Click **Enable** next to the **Enable PDO Write From Attached Devices Port Page** option.
5. Click the **SAVE** button.
6. If this will not cause an unstable environment, click the **CONTINUE** button.

7.6.3 IO-Link Test Event Generator

You can use the **IO-Link Test Event Generator** to send messages to an IOLM port. The generated events are displayed in the **Diagnostics | IO-Link Settings** page under the **Last Events** field and the syslog. This can test a port to verify that it is functioning correctly through

1. Click **Configuration | Misc.**
2. Expand the **IO-Link Test Event Generator**.



3. Select the port and type of event that you want to test.
Use the following table to determine what type of event you want to generate.

IO-Link Test Event Generator Descriptions	
Port	The port number to which you want to send an event.
Mode	This is the first item in the event generated. <ul style="list-style-type: none"> • Single: generates Single in the event. • Coming: generates Active in the event • Going: generates Cleared in the event
Type	This is the second item in the event generated. <ul style="list-style-type: none"> • Message: generates Message in the event. • Warning: generates Warning in the event. • Error: generates Error in the event.
Instance	This is the level in which the event is generated. This is not displayed in the generated event. <ul style="list-style-type: none"> • unknown • physical • datalink • applayer • application

Source	<p>This is the source in which the event is generated. This is the third item in the generated event.</p> <ul style="list-style-type: none"> local: simulation generated from the IOLM, which displays as Local in the event. remote: simulation of an IO-Link device event, which displays as Device in the generated event.
PDI	<p>This indicates whether to send valid or invalid PDI, which is not displayed in the generated event.</p> <ul style="list-style-type: none"> valid invalid
Code	<p>This is the fourth and fifth items in the generated event.</p> <ul style="list-style-type: none"> 0x0000: generates a s_pdu_check event 0x0001: generates a s_pdu_flow event 0x0002: generates a m_pdu_check event 0x0003: generates a s_pdu_illegal event 0x0004: generates a m_pdu_illegal event 0x0005: generates a s_pdu_buffer event 0x0006: generates a s_pdu_inkr event 0x0007: generates an s_pd_len event 0x0008: generates an s_no_pdin event 0x0009: generates an s_no_pdout event 0x000a: generates an s_channel event 0x000b: generates an m_event event 0x000c: generates an a_message event 0x000d: generates an a_warning event 0x000e: generates an a_device event 0x000f: generates an a_parameter event 0x0010: generates a devicelost event 0x0011, 13 - 17: generates an unknown event 0x0012: generates a s_desina event


4. Click **Diagnostics** and scroll down to **Last Events**.

7.7 CLEARING SETTINGS

You can return the IOLM to factory default values and can choose whether you want to restore these default values:

- Uploaded IODD files
- IO-Link data storage
- Hostname, network settings (DHCP/Static, static IP address, static network mask, and static IP gateway) Use the following procedure to restore factory default values on the IOLM.

1. Click **Configuration | Clear Settings**.



2. Click the **OK** button to the *Done Configuration Cleared* message.

8 USING THE DIAGNOSTIC PAGES

8.1 IO-LINK PORT DIAGNOSTICS

Use the **IO-Link Diagnostics** page to determine the status of the IO-Link configuration.

The screenshot shows the 'IO-Link Device Configuration Summary' page. The navigation bar includes 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. The user is logged in as 'CBX-STOL-PNTO'. Below the navigation, there are tabs for 'IODD FILES', 'SUMMARY', and 'PORT 1' through 'PORT 8'. The main content area displays a table with the following data:

DEVICE SETTINGS	PORT 1	MORE	PORT 2	MORE	PORT 3	MORE	PORT 4	MORE	PORT 5	MORE	PORT 6	MORE	PORT 7	MORE	PORT 8	MORE
Vendor Name	DATALOGIC		DATALOGIC		DATALOGIC AUTOMATION S.											
VENDOR	334		412		412											
DEVICE	196609		2		1											
Description	S70 Dual Display Fiber Amplifier		Diffuse proximity Sensor		TDF Background Suppressor Sensor											
IO-Link Version	1.1		1.1		1.1											
Hardware Version	unsupported by device		RevAC		1.0.0											
Firmware Version	1.1.94		3.0.2		1.0.2											
Baud Rate	38400		38400		38400											
SIO Mode	Yes		Yes		Yes											
Min Cycle Time	2.6 ms		14.8 ms		2.3 ms											
IODD Name	DATALOGIC-S70-20120706-IODD1.1.xml		Datalogic-S50C-20180717-IODD1.1.xml		datalogic-S6STOF-20151015-IODD1.1.xml											
Serial Number	20160408095813		0000000000000001		818A00498											


The following table provides information about the **IO-Link Diagnostics** page.

IO-Link Diagnostics	
Port Name	This is an optional friendly port name, which can be configured in the Configuration IO-Link page.
Port Mode	Displays the active device mode: <ul style="list-style-type: none"> • Reset = The port is configured to disable all functionality. • IO-Link = The port is configured to IO-Link mode. • Digital In = The port is configured to operate as a digital input. • Digital Out = The port is configured to operate as a digital output.
Port Status	Displays the port status: <ul style="list-style-type: none"> • Inactive = The port is in active state. Typically, this indicates that the device is either not attached or not detected. • Initializing = The port is in the process of initializing. • Operational = The port is operational and, if in IO-Link mode, communications to the IO-Link device has been established. • PDI Valid = The PDI data is now valid. • Fault = The port has detected a fault and is unable to re-establish communications.
IO-Link State	<ul style="list-style-type: none"> • Operate - Port is functioning correctly in IO-Link mode but has not received valid PDI data. This may also display during a data storage upload or download. • Init - The port is attempting initialization. • Reset - One of the following conditions exists: <ul style="list-style-type: none"> - The Port Mode configuration is set to Reset. - The Port Mode configuration is set to DigitalIn or DigitalOut. • DS - Wrong Sensor - Hardware failure (IO-Link LED also flashes red) because there is Data Storage on this port, which does not reflect the attached device. • DV - Wrong Sensor - Hardware failure (IO-Link LED also flashes red) because Device Validation is configured for this port and the wrong device is attached. • DS - Wrong Size - Hardware failure (IO-Link LED also flashes red) because the size of the configuration on the device does not match the size of the configuration stored on the port. • Comm Lost - Temporary state after a device is disconnected and before the port is re-initialized. • Pre-operate - Temporary status displayed when the device: <ul style="list-style-type: none"> - Is starting up after connection or power-up. - Uploading or downloading automatic data storage.
Device Vendor Name	Displays the Device Vendor Name as stored in ISDU Index 16.
Device Product Name	Displays the device product name as stored in ISDU Index 18.
Device Serial Number	Displays the device serial number as stored in ISDU Index 21.
Device Hardware Version	Displays the device hardware version as stored in ISDU Index 22.
Device Firmware Version	Displays the device firmware version as stored in ISDU Index 23.
Device IO-Link Version	The supported device IO-Link version as stored in ISDU Index 0.
Actual Cycle Time	This is the actual, or current, cycle time of the IO-Link connection to the device.
Device Minimum Cycle Time	This is the minimum, or fastest, cycle time supported by the connected IO-Link device.
	Configured in the Configuration IO-Link page, this is the minimum cycle time

Configured Minimum Cycle Time	the IO-Link Master will allow the port to operate at. The Actual Cycle Time , which is negotiated between the IO-Link Master and the device, will be at least as long as the greater of the Configured Minimum Cycle Time and the Device Minimum Cycle Time .
Data Storage Capable	Displays whether the IO-Link device on a port supports the data storage feature. Not all IO-Link devices support the data storage feature.
Automatic Data Storage Configuration	Displays whether a port is configured to automatically upload data from the IO-Link device or download data from the IOLM to the IO-Link device. Disabled displays if automatic upload or download are not enabled.
Auxiliary Input (AI) Bit Status	The current status of the auxiliary bit as received on DI of the IO-Link port.
Device PDI Data Length	The supported Device PDI Data Length, in bytes, as stored in ISDU Index 0.
PDI Data Valid	Current status of PDI data as received from the IO-Link device.
Last Rx PDI Data (MS Byte First)	The last Rx PDI data as received from the IO-Link device.
PDO Lock Enable	If enabled on the Configuration IO-Link Settings page, an industrial protocol application (PROFINET IO, EtherNet/IP, or Modbus TCP) can lock the write access to the PDO value so that the PDO value cannot be changed by other protocols (including OPC UA or the Web interface). Such a lock is released when the PLC to IO-Link Master network link disconnects.
PDO Locked	Indicates whether or not one of the industrial protocol applications has locked the write access to the PDO value.
Device PDO Data Length	The supported Device PDO Data Length, in bytes, as stored in ISDU Index 0.
PDO Data Valid	Status of PDO data being received from controller(s).
Last Tx PDO Data (MS Byte First)	The last Tx PDO data.
Time Since Initialization	The time since the last port initialization.
Process Data Errors	The number of process data errors the port received.
Process Data Retries	The number of process data retries the port performed.
Total Events	The total number of events that were received on this port.
First Events	Up to the first, or oldest, three events that were received on this port.
Last Events	Up to the last, or most recent, three events that were received on this port.
ISDU Statistics	
ISDU Read Cmd Attempts	The number of read ISDU command attempts.
ISDU Read Cmd Errors	The number of read ISDU command errors.
ISDU Write Cmd Attempts	The number of write ISDU command attempts.
ISDU Write Cmd Errors	The number of write ISDU command errors.

8.2 MODBUS/TCP DIAGNOSTICS

The **Modbus/TCP Diagnostics** page may be useful when trying to troubleshoot Modbus/TCP communications or port issues related to Modbus/TCP configuration.




The following table provides information about the **Modbus/TCP Diagnostics** page.

Modbus/TCP Diagnostics	
Active Connections	Displays the current number of active Modbus/TCP connections.
Messages Received from Masters	Displays the number of Modbus messages received from Modbus/TCP Masters.
Responses Sent to Masters	Displays the number of Modbus responses sent to Modbus/TCP Masters.
Broadcasts Received	Displays the number of broadcast Modbus/TCP messages received.
Invalid Message Length Errors	Displays the number of Modbus messages received with incorrect length fields.
Invalid Message Data Errors	Displays the number of invalid message data errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to invalid data.
Invalid Message Address Errors	Displays the number of invalid message address errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to an invalid address.
Unknown Device ID Errors	Displays the number of unknown device ID errors. These errors occur when the IO-Link Master receives a message that is addressed to a device ID other than the configured Slave Mode Device ID .
Invalid Protocol Type Errors	Displays the number of invalid message protocol type errors. These errors occur when the IO-Link Master receives a Modbus/TCP message that specifies a non-Modbus protocol.

Unsupported Function Code Errors	Displays the number of invalid Modbus function code errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to an unsupported Modbus function code.
Configuration Errors	Displays the number of improper configuration errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to an invalid configuration.
No Available Connection Errors	Displays the number of Modbus/TCP connection attempts that were rejected due to no available connections. This occurs when the number of Modbus/TCP connections has reached the limit.
System Resource Errors	Displays the number of system resource errors. These errors indicate a system error on the IO-Link such as operating system errors or full message queues. These errors typically occur when the PLC(s) are sending messages to the IO-Link Master faster than the IO-Link Master can process them.
First Error String	Text description of the first error that occurred.
Last Error String	Text description of the last error that occurred.
<i>Modbus/TCP Port Specific Diagnostics</i>	
Active PDO Controller(s)	Lists IP addresses that are controlling the PDO data.
PDO Writes to Offline or Read-Only Ports	Displays the number of PDO write messages that were dropped due to any of the following: <ul style="list-style-type: none"> • The port is configured in IO-Link mode: <ul style="list-style-type: none"> - There is no device connected to the port. - The IO-Link device is off-line. - The IO-Link device does not support PDO data. • The PDO Transmit Mode (To PLC) is disabled. • The port is configured in Digital Input mode.
ISDU Request Msgs From PLC(s)	Displays the number of ISDU request messages received from the PLC(s) or other controllers. These request messages may contain one or multiple ISDU commands.
ISDU Invalid Requests	Displays the number of ISDU requests received over Modbus/TCP with one or more invalid commands.
ISDU Requests When Port Offline	Displays the number of ISDU requests received over Modbus/TCP when the IO-Link port was offline. This can occur when: <ul style="list-style-type: none"> • The IO-Link port is initializing, such as after start-up. • There is no IO-Link device attached to the port. • The IO-Link device is not responding. Communication to the IO-Link device has been lost.
Valid ISDU Responses From Port	Displays the number of valid ISDU response messages returned from the IO-Link port interface and available to the PLC(s). The response messages contain results to the ISDU command(s) received in the request message.
ISDU Response Timeouts	Displays the number of ISDU requests that did not receive a response within the configured ISDU Response Timeout .
Unexpected ISDU Responses	Displays the number of unexpected ISDU responses. Unexpected responses may occur when an ISDU response is received after the ISDU request has timed out. This typically requires setting the ISDU Response Timeout to a longer value.
Maximum ISDU Request Msg Response Time	Displays the maximum time period required to process all commands within an ISDU request message. The response is not available until all ISDU command(s) contained in the request have been processed.
Average ISDU Request Msg Response Time	Displays the average time period required to process the ISDU request message(s). The response is not available until all ISDU command(s) contained in the request have been processed.
Minimum ISDU Request Msg Response Time	Displays the minimum time period required to process all commands within an ISDU request message. The response is not available until all ISDU command(s) contained in the request have been processed.
ISDU Read Commands	Displays the number of ISDU read commands received over Modbus/TCP.
ISDU Write Commands	Displays the number of ISDU write commands received over Modbus/TCP.
ISDU NOP Commands	Displays the number of ISDU NOP (no operation) commands received over Modbus/TCP.

8.3 PROFINET IO DIAGNOSTIC PAGE

The **PROFINET IO Diagnostics** page may be useful when trying to troubleshoot communications or port issues related to PROFINET IO configuration.



The following table provides information about the **PROFINET IO Diagnostics** page.

PROFINET IO Diagnostics	
Active Application Relationships	Displays the current number of active PROFINET IO connections.
Application Relationship 1 Uptime	The uptime of the first application relationship.
Application Relationship 2 Uptime	The uptime of the second application relationship.
Total Application Relationships Established	The total number of application relationships that have been established since power up.
IOL_CALL Function Block Requests	The total number of IOL_CALL function block requests received.
IOL_CALL Function Block Errors	The number of errors when handling IOC_CALL function block requests.
Configuration Errors	The number of system configuration related errors.
System Errors	Displays the number of system resource errors. These errors indicate a


	system error on the IO-Link such as operating system errors or full message queues. These errors typically occur when the PLC(s) are sending messages to the IO-Link Master faster than the IO-Link Master can process them.
PROFINET IO Frames Transmitted	The total number of transmitted PROFINET IO frames.
PROFINET IO Transmit Errors	The number of errors when transmitting PROFINET IO frames.
PROFINET IO Frames Received	The total number of received PROFINET IO frames.
PROFINET IO Receive Errors	The number of errors when receiving PROFINET IO frames.
Record Reads	The total number of record read requests received.
Record Read Errors	The number of errors when handling record read requests.
Digital IO Input Status Changes	The number of times that the status of the digital I/O pins have changed.
Digital IO Writes	The number of times that the status of the digital output pins has changed.
Digital IO Write Errors	The number of errors when writing to digital output pins.
IP Assignment	The current IP assignment method.
Ethernet Port 1 Link Status	Current link status of Ethernet Port 1.
Ethernet Port 2 Link Status	Current link status of Ethernet Port 2.
First Error String	Text description of the first error that occurred.
Last Error String	Text description of the last error that occurred.
PROFINET IO Port Status	
Application Relationship	The application relationship (1 or 2) that the IO-Link port belongs to.
PDI Reads	The number of PDI reads.
PDI Reads Truncated	The number of PDI reads that are truncated due to size.
PDI Read Errors	The number of errors when reading PDI.
PDO Writes	The number of PDI writes.
PDO Write Errors	The number of errors when reading PDO.
SIO Input Status Changes	The number of time the status of C/Q pin has changed when a port is in SIO input mode.
SIO Output Writes	The number of time the status of C/Q pin has changed when a port is in SIO output mode.
SIO Output Write Errors	The number of errors when writing to C/Q pin when a port is in SIO output mode.
Auxiliary Input Status Changes	The number of time the status of auxiliary pin has changed.
Event Reads	The number of IO-Link events.
Event Read Errors	The number of errors when reading IO-Link events.
Get Port Mode Errors	The number of errors when getting IO-Link port mode.
Set Port Mode Errors	The number of errors when setting IO-Link port mode.
ISDU Request Msgs From PLC(s)	Displays the number of ISDU request messages received from the PLC(s) or other controllers. These request messages may contain one or multiple ISDU commands.
ISDU Invalid Requests	Displays the number of ISDU requests received over PROFINET IO with one or more invalid commands.
Valid ISDU Responses From Port	Displays the number of valid ISDU response messages returned from the IO-Link port interface and available to the PLC(s). The response messages contain results to the ISDU command(s) received in the request message.
ISDU Response Timeouts	Displays the number of ISDU requests that did not receive a response within the configured ISDU Response Timeout .
Maximum ISDU Request Msg Response Time	Displays the maximum time period required to process all commands within an ISDU request message. The response is not available until all ISDU command(s) contained in the request have been processed.
Average ISDU Request Msg Response Time	Displays the average time period required to process the ISDU request message(s). The response is not available until all ISDU command(s) contained in the request have been processed.
Minimum ISDU Request Msg Response Time	Displays the minimum time period required to process all commands within an ISDU request message. The response is not available until all ISDU command(s) contained in the request have been processed.

ISDU Read Commands	Displays the number of ISDU read commands received over PROFINET IO.
ISDU Read Failures	The number of errors when processing ISDU read commands.
ISDU Write Commands	Displays the number of ISDU write commands received over PROFINET IO.
ISDU Write Failures	The number of errors when processing ISDU write commands.
Process Alarms	The number of process alarms sent to PLC.
Return of Submodule Alarms	The number of Return of Submodule alarms sent to PLC.
Channel Diagnostics Alarms Added	The number of channel diagnostics alarms sent to PLC.
Channel Diagnostics Alarms Removed	The number of channel diagnostics alarms removed from PLC.
Alarm Errors	The number errors when handling PROFINET IO alarms.

8.4 OPC UA DIAGNOSTICS PAGE

The **OPC UA Diagnostics** page displays status for OPC UA:

- Whether the OPC UA feature is enabled or disabled
- Number of TCP connections



The screenshot shows the OPC UA Diagnostics page. At the top, there is a navigation bar with the Datalogic logo and menu items: Home, Diagnostics, Configuration, Advanced, Attached Devices, and Help. On the right side of the navigation bar, it displays 'CBX-810L-PN10' and 'Logout'. Below the navigation bar, there are tabs for IO-LINK, ETHERNET/IP, MODBUS/TCP, and OPC UA. The main content area is titled 'OPC UA Diagnostics' and includes three buttons: 'UPDATE', 'STOP LIVE UPDATES', and 'RESET STATISTICS'. Below these buttons is a table showing the general status of OPC UA.

OPC UA GENERAL STATUS	
OPC UA Server Enable	disable
Number of TCP connections	0



Note: Not all models support OPC UA.

9 PROFINET IO REFERENCE INFORMATION

9.1 SAMPLE IO-LINK MASTER GATEWAY CONFIGURATION

This section demonstrates how to configure and use an IO-Link gateway.

Device overview								
Module	...	Rack	Slot	I address	Q address	Type	Article number	
▼ CBX8IOLPNIO		0	0			CBX-8IOL-PNIO	CBX-8IOL-PNIO	
▶ Interface		0	0 X1			CBX8IOLPNIO		
IO-Link In 2 bytes_1		0	1	6...7		IO-Link In 2 bytes		
IO-Link In/Out 2 bytes_1		0	2	8...9	2...3	IO-Link In/Out 2 by...		
SIO Digital In_1		0	3	10		SIO Digital In		
SIO Digital Out_1		0	4		4	SIO Digital Out		
		0	5					
		0	6					
		0	7					
		0	8					
IO-Link Status_1		0	9	1...4		IO-Link Status		

Figure 6 - TIA Porta V13 - Datalogic IOLM Gateway Configuration Example

- The first IO-Link device, which supported 2 bytes of PDI data, was connected to IO-Link Port 1. The PDI data were mapped into the process image at address IW 6 of the IO controller, as shown in the figure above. The IO controller could read the current PDI data from the IO-Link device at IW 6.
- The second IO-Link device, which supported 2 bytes of PDI data and 2 bytes of PDO data, was connected to IO-Link Port 2. The PDI data were mapped into the process image at address IW 8. The PDO data were mapped into process image at address QW 2. The IO controller could access PDI and PDO via the two memory locations.
- IO-Link Port 3 and Port 4 were configured as SIO Digital In and SIO Digital Out. The IO controller could read the input status of the C/Q pin of Port 3 at IB 10 and set the output C/Q pin value of Port 4 by writing to QB 4. IO-Link port status was reported through the module in Slot 10. The 4-byte port status was available at IB 1 to IB 4.

Using a variable table, as shown in the following, we monitored and modified the IO data directly.

	Address	Symbol	Display format	Status value	Modify value
1	IB 1	"Status_Active"	BIN	2#0000_1111	
2	IB 2	"Status_PDValid"	BIN	2#0000_1111	
3	IB 3	"Status_AuxiliaryInput"	BIN	2#0011_1101	
4	IB 4	"Status_Error"	BIN	2#0000_0000	
5	IW 6	"P1_IOLinkIn2bytes"	HEX	W#16#07B9	
6	IW 8	"P2_IOLinkIn2bytes"	HEX	W#16#0000	
7	IB 10	"P3_SIOInput"	HEX	B#16#01	
8	QB 4	"P4_SIOOutput"	HEX	B#16#01	B#16#01

Figure 7 - STEP 7 V5.5 - Monitoring and Modifying IO Data

i	Name	Address	Display form..	Monitor value	Modify value
1	"Status_Active"	%IB1	Bin	2#0000_1111	
2	"Status_PDValid"	%IB2	Bin	2#0000_1111	
3	"Status_AuxiliaryInput"	%IB3	Bin	2#0000_1101	
4	"Status_Error"	%IB4	Bin	2#0000_0000	
5	"P1_IOLinkIn2bytes"	%IW6	Hex	16#07B0	
6	"P2_IOLinkIn2bytes"	%IW8	Hex	16#0000	
7	"P2_IOLinkOut2bytes"	%QW2	Hex	16#0000	
8	"P3_SIOInput"	%IB10	Hex	16#01	
9	"P4_SIOOutput"	%QB4	Hex	16#01	16#01

Figure 8 - TIA Portal V13 - Monitoring and Modifying IO Data

IB 1-4 were input data from IO-Link Status module (Slot 10). IB 1 was IO-Link Active, IB 2 was PDI Valid, IB 3 was Auxiliary Input, and IB 4 was IO-Link Error. According to the current value of IB 1, Ports 1-4 were active. IB 2 showed the PDI data of Ports 1-4 were valid. IB 3 showed that the auxiliary input pins of Ports 1, 3, and 4 were high. No errors were detected so IB 4 was zero.

The PDI data of Port 1 was shown in IW 6. The PDI data of Port 2 was shown in IW 8.

In this example, we connected the C/Q pin, auxiliary input pin of Port 3 and Port 4 together, creating a testing loopback. Then we modified QB 4 to 0x01, which turned the C/Q Pin of Port 4 to high. IB 10 showed the status of the C/Q pin of Port 3 was high (0x01) as a result. The high status of auxiliary input pins of Ports 3 and 4 was reflected in IB 3.

Slot 5-8 (Port 5-8) and Slot 11 were open. They could be used by another IO controller via a second application relationship.

9.2 READ PDI DATA AS RECORD DATA

For IO modules that have input data, the Port Qualifier and PDI data can also be read by using the SFB52 **RDREC** (read record). The following table shows the available record read indexes for the IO-Link Master.

Using the same example in par. 9.1, a record read request of 2-bytes at index 100 would return the current PDI data of the IO-Link device attached to Port 1. A record read request of 1-byte at Index 900 would return the current IO-Link port active status.

Reading partial PDI data via record read request is supported. For an instance, an IO-Link device that supports 32-bytes PDI data is connected to IO-Link Port 5. A record read request of 32-bytes at Index 500 returns the whole 32-bytes of PDI data. Another record read request of 4-bytes at Index 529 returns the last 4-bytes of the PDI data. This provides flexibility in being able to get only the interested data from a large PDI data block.

If a record read requests more data than the IO module or IO-Link device supports, IO-Link Master returns the available PDI data and fills the remaining data with zeros. Again, using the same example in par. 9.1, a record read request of 4-bytes at Index 100 returned 0x09 0x0E 0x00 0x00, where 0x09 and 0x0E were the actual PDI data.

IO-Link Master returns an error if a record read request contains an invalid index.

Writing PDO Data to an IO-Link device via data record write service is not supported. This is because that the new PDO data written by a record write will only last for one update cycle. The next cycle the IO controller overwrites the new PDO data with the old cyclic data from the process image.

9.3 USING THE SFB52 RDREC

To use the SFB52 **RDREC**, specify the index of the requested module in **INDEX**. Specify the maximum number of bytes you want to read in **MLEN**. The selected length of the target area **RECORD** should have at least the length of **MLEN** bytes.

TRUE on output parameter **VALID** verifies that the data record has been successfully transferred into the target area **RECORD**. In this case, the output parameter **LEN** contains the length of the fetched data in bytes.

The output parameter **ERROR** indicates if a data record transmission error has occurred. In this case, the output parameter **STATUS** contains the error information.




Figure 9 - SFB52 Read a Process Data Record

9.4 READ AND WRITE ISDU WITH THE FB IOL_CALL

The function block **IOL_CALL** represents the conversion of the communication standardized for the IO-Link technology to and from IO-Link devices. The supports the **IOL_CALL** function block. It can be used to access an ISDU of an IO-Link device.

The **IOL_CALL** function block and the library description are available at: <http://support.automation.siemens.com/WW/view/en/82981502>


To use **IOL_CALL** function block, do the following:

1. Set **CAP** to 255.
2. Specify **PORT** to be the IO-Link port number (1 to 8) at which the IO-Link device is connected.
3. Set **IOL_INDEX** and **IOL_SUBINDEX** to be the index and subindex of the requested ISDU. **RECORD_IOL_DATA** requires the full specification of the DB parameters, i.e. **P#DB1.DBX0.0** byte 232.

The target area **RECORD_IOL_DATA** must have enough available bytes to hold the requested ISDU block up to 232 bytes.

4. Set **RD_WR** to 0 for read and 1 for write. For write, also specify the length of the data to be written in **LEN**. A positive edge on **REQ** starts the **IOL_CALL** request.

BUSY is set to 1 when the **IOL_CALL** request is in progress. Once completed, **DONE_VALID** is set to 1 if there was no error. Otherwise, **ERROR** is set and **STATUS** and **IOL_STATUS** contain the error information. For the remainder of the **IOL_CALL** function block parameters and complete error information, refer to the **IOL_CALL** library description.




Parameter	Description
CAP	Access point of the IOL_CALL function. Use 255.
PORT	IO-Link port number at which the IO-Link device is operated, port number 1 through 8. All other values: not supported.
IOL_INDEX	Address parameter INDEX (IO-Link device). 0 - 32767: index of ISDU
IOL_SUBINDEX	Address parameter SUBINDEX (IO-Link device). <ul style="list-style-type: none"> • 0: not support • 1 - 255: subindex of ISDU

The **IOL_CALL** function block has a 20 seconds timeout value. If the request takes longer than 20 seconds, the process is aborted and a timeout error is returned. The IOLM also has a timeout value for **IOL_CALL** request. The default timeout value is 20 seconds. It can be changed through the web page (Configuration | PROFINET IO).


9.4.1 Using the IO-Link Library in the TIA Portal

Use the following procedure to use the IO-Link library in the TIA Portal.

1. Download the IO-Link library from Siemens: <http://support.automation.siemens.com/WW/view/en/82981502>.
For TIA Portal V13, download the **Archive_IO_LINK_CALL.zip** archive. For STEP 7 V5.5 and V14, download **82981502_IO_LINK_Library_V3.1**.
2. Unzip the library to a working directory.
3. Configure the TIA Portal project.
 - a. Create a new or open an existing TIA Portal project.
 - b. Configure the PLC, Datalogic IOLM gateway and all the IO-Link ports.
 - c. Compile and download the project.
 - d. Make sure that everything is working as expected.
4. Take a note of the hardware identifier of the IO-Link module, which will be used to access IO-Link device ISDU.



5. Open the IO-Link library.
 - a. In TIA Portal, click the **Open global library** button on the **Libraries** tab.
 - b. Navigate to the above working directory, where the IO-Link library was unzipped.
 - c. Select the **IO_LINK_V13.a13** and click **Open**. Depending on the version of TIA Portal, the library may need to be upgraded.
 - d. After opened, there should be an **82981502_IO_LINK_XXX** library. **IO_LINK_CALL_1200 V 2.2.0** is the one that will be used.




6. Create tags and data block by going to **PLC tags**, create some tags that will be used as the parameters of IO_LINK_CALL.

IO_Link_Library_Demo > PLC_1 [CPU 1212C AC/DC/Rly] > PLC tags > Default tag table [38]


Default tag table							
	Name	Data type	Address	Retain	Visibl...	Acces...	Comment
1	Req	Bool	%M0.0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
2	ID	Hw_Io	%MW2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
3	RdWr	Bool	%M0.1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
4	IOLPort	UInt	%MW4	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
5	IOLIndex	UInt	%MW6	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
6	IOLSubindex	UInt	%MW8	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
7	Len	UInt	%MW10	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
8	DoneValid	Bool	%M0.2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
9	Busy	Bool	%M0.3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10	Error	Bool	%M0.4	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
11	Status	DWord	%MD12	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
12	IOLStatus	DWord	%MD16	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
13	RdLen	UInt	%MW20	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

7. Add a new data block and create a 232-byte array, which will be used to store the ISDU data.



8. Insert **IO_LINK_CALL**.

- a. Open the **Main** block.
- b. From the Global libraries, select **82981502 IO_LINK_xxx | Types | S7-1200V2.2 | IO_LINK_CALL_1200 | V2.2.0** and insert it into a new network.
- c. Enter the parameters using the above tags. Enter **255** for the parameter CAP.
- d. Compile and download the project.



9. Test **IO_LINK_CALL**.

- a. Create a new watch table and enter the parameters of **IO_LINK_CALL**.
- b. Click the **Monitor all** button to start monitoring all tags.
- c. Enter the hardware identifier of the IO-Link module as the modify value of tag ID.
- d. Enter the IO-Link port number (1 based), index, subindex, and length of the requested ISDU as the modify value of the corresponding tags.
- e. Finally set the **Req tag** to be true and click the **Modify once** button.

	Name	Address	Display format	Monitor value	Modify value
1	*Req*	%MO.0	Bool	TRUE	TRUE
2	*ID*	%MW2	DEC	278	278
3	*RdWr*	%MO.1	Bool	FALSE	
4	*IOLPort*	%MW4	DEC	1	1
5	*IOLIndex*	%MW6	DEC	16	16
6	*IOLSubindex*	%MW8	DEC	0	
7	*Len*	%MW10	DEC	32	32
8	*DoneValid*	%MO.2	Bool	TRUE	
9	*Busy*	%MO.3	Bool	FALSE	
10	*Error*	%MO.4	Bool	FALSE	
11	*Status*	%MD12	Hex	16#0000_0000	
12	*IOLStatus*	%MD16	Hex	16#0000_0000	
13	*RdLen*	%MW20	DEC	8	
14		<Add new>			

10. The **IO_LINK_CALL** is triggered on the positive edge of parameter REQ.

Once completed, check the value of tag **DoneValid**, **Busy**, **Error**, **Status**, **IOLStatus**, and **RdLen**. If the ISDU request was completed successfully, the **DoneValid** should be true. The **RdLen** contains the number of bytes returned. The actual data is stored in **Data_block_1.IOLData**.

	Name	Data type	Start value	Monitor value	Retain	Accessible f...
1	Static					
2	IOLData	Array[0..231] of Byte				
3	IOLData[0]	Byte	16#0	16#53		
4	IOLData[1]	Byte	16#0	16#49		
5	IOLData[2]	Byte	16#0	16#43		
6	IOLData[3]	Byte	16#0	16#48		
7	IOLData[4]	Byte	16#0	16#20		
8	IOLData[5]	Byte	16#0	16#41		
9	IOLData[6]	Byte	16#0	16#47		
10	IOLData[7]	Byte	16#0	16#00		
11	IOLData[8]	Byte	16#0	16#00		
12	IOLData[9]	Byte	16#0	16#00		

9.5 DIAGNOSTIC ALARM

Events from IO-Link Master and IO-Link devices are mapped to PROFINET alarms and channel diagnostics according to the IO-Link on *PROFINET Working Document Version 13.4.2015* with some modifications.

9.5.1 IO-Link Event Mapping Overview

IO-Link events are mapped into **PROFINET Alarms and Channel Diagnostics** using the following table. Each appearing IO-Link event (mode Coming) results in adding channel diagnostics. Each disappearing IO-Link event (mode Going) results in removing channel diagnostics. IO-Link events that have mode Single will be mapped to PROFINET process alarm.

IO-Link Event Mapping	
IO-Link Event Mode	PROFINET
Single	Process alarm
Coming	Add channel diagnostics
Going	Remove channel diagnostics

In addition, only IO-Link events that have the type of Error or Warning are mapped to PROFINET channel diagnostics. Type Message IO-Link events are not mapped.

9.5.2 IO-Link EventCode Mapping

IO-Link events that are generated by IO-Link devices (remote events) are mapped to PROFINET diagnostics using ChannelErrorType 0x500 and 0x501.

- For an **EventCode** that is between 0x0000 and 0x7FFF, **ChannelErrorType** 0x500 is used. The **EventCode** is directly mapped to **ExtChannelErrorType**.
- For an **EventCode** that is between 0x8000-0xFFFF, **ChannelErrorType** 0x501 is used. The **EventCode** is mapped to **ExtChannelErrorType** with the MSB set to 0.
- For IO-Link events that are generated by IO-Link Master (local events), **ChannelErrorType** 0x502 is used.
- **EventCode** is directly mapped to **ExtChannelErrorType**.

The following table summarizes how IO-Link EventCode is mapped to PROFINET diagnostics.

IO-Link EventCode Mapping				
Source	EventCode	ChannelError Type	ExtChannel ErrorType	Comment
IO-Link Device (remote)	0x0000-0x7FFFF	0x500	0x0000-0x7FFFF	Direct mapping of EventCode to ExtChannelErrorType (e.g. EventCode 0x6321 will be mapped to ExtChannelErrorType 0x6321)
IO-Link Device (remote)	0x8000-0xFFFF	0x501	0x0000-0x7FFFF	Mapping of EventCode to ExtChannelErrorType . Set MSB (EventCode) to "0" (e.g. EventCode 0x8005 ExtChannelErrorType 0x0005)
IO-Link Master (local)	0x0000-0x7FFFF	0x502	0x0000-0x7FFFF	Direct mapping of local EventCode to ExtChannelErrorType

The following table lists some of the **EventCode** that the Datalogic IO-Link Master generates.

IO-Link EventCode	ExtChannelErrorType	Description
0x0001	0x0001	Slave PDU Flow
0x0002	0x0002	Master PDU checksum error
0x0003	0x0003	Slave illegal PDU
0x0004	0x0004	Master illegal PDU
0x0005	0x0005	Slave PDU buffer
0x0006	0x0006	Slave PD INKR
0x0007	0x0007	Slave PD length
0x0008	0x0008	Slave no PDI
0x0009	0x0009	Slave no PDO
0x000A	0x000A	Slave channel
0x000B	0x000B	Master event
0x000C	0x000C	Application message
0x000D	0x000D	Application warning
0x000E	0x000E	Application device
0x000F	0x000F	Application parameter
0x0010	0x0010	Slave device lost
0x0012	0x0012	Slave DESINA
0x001A	0x001A	Slave wrong sensor
0x001B	0x001B	Slave retry
0x001E	0x001E	Power short circuit
0x001F	0x001F	Power sensor
0x0020	0x0020	Power actuator
0x0021	0x0021	Power fault
0x0022	0x0022	Power reset
0x0023	0x0023	Slave fallback
0x0024	0x0024	Master preoperate
0x0028	0x0028	Data storage ready
0x0029	0x0029	Data storage identity fault
0x002A	0x002A	Data storage size fault
0x002B	0x002B	Data storage upload fault
0x002C	0x002C	Data storage download fault
0x002F	0x002F	Data storage device locked fault

The following images show a *Slave device lost* event that was available in the diagnostics when an IO-Link device was disconnected from an IO-Link port. In the figure, Slot 2 means that the device was connected to IO-Link Port 2. The event will be removed from the diagnostics when the device is reconnected to the same IO-Link port.




Figure 10 - TIA Portal V13: IO-Link Events Through PROFINET Channel Diagnostics

10 MODBUS/TCP INTERFACE

The IOLM provides a slave-mode Modbus/TCP interface that provides:

- Read access to the Process Data Input (PDI) and Process Data Output (PDO) data blocks for each IO-Link port
- Write access to the PDO data block for each IO-Link port
- Write access to send ISDU requests to each IO-Link port
- Read access to ISDU responses from each IO-Link port
- Read access to the Port Information Block for each IO-Link port.

The Modbus interface is disabled by default. To enable Modbus/TCP:

1. Click **Configuration | Modbus/TCP**.
2. Click the **EDIT** button in the **Modbus/TCP Configuration** table.
3. Select **enable** in the **Modbus Enable** drop box.
4. Click the **SAVE** button.

10.1 MODBUS FUNCTION CODES

This table shows the supported Modbus function codes.

Message Type	Function Code	Maximum Message Size
Read Holding Registers	3	250 Bytes (125 Words)
Write Single Register	6	2 bytes (1 Word)
Write Multiple Registers	16 (10 hex)	246 Bytes (123 Words)
Read/Write Holding Registers	23 (17 hex)	Write: 242 bytes (121 Words) Read: 246 bytes (123 Words)

10.2 MODBUS ADDRESS DEFINITIONS

The address definitions for the Modbus/TCP interface are shown in the following tables.

	IO-Link Port 1	IO-Link Port 2	IO-Link Port 3	IO-Link Port 4	Access	Length
Multiple Port PDI Data Block(s)	999 (Base 0)	1999 (Base 0)	2999 (Base 0)	3999 (Base 0)	Read-Only	Configurable per port (s)
	1000 (Base 1)	2000 (Base 1)	3000 (Base 1)	4000 (Base 1)		
Port Specific PDI Data Block	1000 (Base 0)	2000 (Base 0)	3000 (Base 0)	4000 (Base 0)	Read-Only	Configurable per port
	1001 (Base 1)	2001 (Base 1)	3001 (Base 1)	4001 (Base 1)		
Multiple Port PDO Data Block(s)	1049 (Base 0)	2049 (Base 0)	3049 (Base 0)	4049 (Base 0)	Read/Write	Configurable per port(s)
	1050 (Base 1)	2050 (Base 1)	3050 (Base 1)	4050 (Base 1)		
Port Specific PDO Data Block	1050 (Base 0)	2050 (Base 0)	3050 (Base 0)	4050 (Base 0)	Read/Write	Configurable per port
	1051 (Base 1)	2051 (Base 1)	3051 (Base 1)	4051 (Base 1)		
Receive ISDU Response	1100 (Base 0)	2100 (Base 0)	3100 (Base 0)	4100 (Base 0)	Read-Only	4 to 125 Words
	1101 (Base 1)	2101 (Base 1)	3101 (Base 1)	4101 (Base 1)		
Transmit ISDU Request	1300 (Base 0)	2300 (Base 0)	3300 (Base 0)	4300 (Base 0)	Write-Only	4 to 123 Words
	1301 (Base 1)	2301 (Base 1)	3301 (Base 1)	4301 (Base 1)		
<i>Port Information Block (Continuous Block)</i>						232 Words
Vendor Name	1500 (Base 0)	2500 (Base 0)	3500 (Base 0)	4500 (Base 0)	Read-Only	64 Chars
	1501 (Base 1)	2501 (Base 1)	3501 (Base 1)	4501 (Base 1)		32 Words
Vendor Text	1532 (Base 0)	2532 (Base 0)	3532 (Base 0)	4532 (Base 0)	Read-Only	64 Chars
	1533 (Base 1)	2533 (Base 1)	3533 (Base 1)	4533 (Base 1)		32 Words
Product Name	1564 (Base 0)	2564 (Base 0)	3564 (Base 0)	4564 (Base 0)	Read-Only	64 Chars
	1565 (Base 1)	2565 (Base 1)	3565 (Base 1)	4565 (Base 1)		32 Words
Product Id	1596 (Base 0)	2596 (Base 0)	3596 (Base 0)	4596 (Base 0)	Read-Only	64 Chars
	1597 (Base 1)	2597 (Base 1)	3597 (Base 1)	4597 (Base 1)		32 Words
Product Text	1628 (Base 0)	2628 (Base 0)	3628 (Base 0)	4628 (Base 0)	Read-Only	64 Chars
	1629 (Base 1)	2629 (Base 1)	3629 (Base 1)	4629 (Base 1)		32 Words
Serial Number	1660 (Base 0)	2660 (Base 0)	3660 (Base 0)	4660 (Base 0)	Read-Only	16 Chars
	1661 (Base 1)	2661 (Base 1)	3661 (Base 1)	4661 (Base 1)		8 Words
Hardware Revision	1668 (Base 0)	2668 (Base 0)	3668 (Base 0)	4668 (Base 0)	Read-Only	64 Chars
	1669 (Base 1)	2669 (Base 1)	3669 (Base 1)	4669 (Base 1)		32 Words
Firmware Revision	1700 (Base 0)	2700 (Base 0)	3700 (Base 0)	4700 (Base 0)	Read-Only	64 Chars
	1701 (Base 1)	2701 (Base 1)	3701 (Base 1)	4701 (Base 1)		32 Words
Device PDI Length	1732 (Base 0)	2732 (Base 0)	3732 (Base 0)	4732 (Base 0)	Read-Only	1 Word
	1733 (Base 1)	2733 (Base 1)	3733 (Base 1)	4733 (Base 1)		
Device PDO Length	1733 (Base 0)	2733 (Base 0)	3733 (Base 0)	4733 (Base 0)	Read-Only	1 Word
	1734 (Base 1)	2734 (Base 1)	3734 (Base 1)	4734 (Base 1)		

10.2.1 Port Models

	IO-Link Port 5	IO-Link Port 6	IO-Link Port 7	IO-Link Port 8	Access	Length
Multiple Port PDI Data Block(s)	4999 (Base 0)	5999 (Base 0)	6999 (Base 0)	7999 (Base 0)	Read-Only	Configurable per port (s)
	5000 (Base 1)	6000 (Base 1)	7000 (Base 1)	8000 (Base 1)		
Port Specific PDI Data Block	5000 (Base 0)	6000 (Base 0)	7000 (Base 0)	8000 (Base 0)	Read-Only	Configurable per port
	5001 (Base 1)	6001 (Base 1)	7001 (Base 1)	8001 (Base 1)		
Multiple Port PDO Data Block(s)	5049 (Base 0)	6049 (Base 0)	7049 (Base 0)	8049 (Base 0)	Read/Write	Configurable per port(s)
	5050 (Base 1)	6050 (Base 1)	7050 (Base 1)	8050 (Base 1)		
Port Specific PDO Data Block	5050 (Base 0)	6050 (Base 0)	7050 (Base 0)	8050 (Base 0)	Read/Write	Configurable per port
	5051 (Base 1)	6051 (Base 1)	7051 (Base 1)	8051 (Base 1)		
Receive ISDU Response	5100 (Base 0)	6100 (Base 0)	7100 (Base 0)	8100 (Base 0)	Read-Only	4 to 125 Words
	5101 (Base 1)	6101 (Base 1)	7101 (Base 1)	8101 (Base 1)		
Transmit ISDU Request	5300 (Base 0)	6300 (Base 0)	7300 (Base 0)	8300 (Base 0)	Write-Only	4 to 123 Words
	5301 (Base 1)	6301 (Base 1)	7301 (Base 1)	8301 (Base 1)		
<i>Port Information Block (Continuous Block)</i>						232 Words
Vendor Name	5500 (Base 0)	6500 (Base 0)	7500 (Base 0)	8500 (Base 0)	Read-Only	64 Chars
	5501 (Base 1)	6501 (Base 1)	7501 (Base 1)	8501 (Base 1)		32 Words
Vendor Text	5532 (Base 0)	6532 (Base 0)	7532 (Base 0)	8532 (Base 0)	Read-Only	64 Chars
	5533 (Base 1)	6533 (Base 1)	7533 (Base 1)	8533 (Base 1)		32 Words
Product Name	5564 (Base 0)	6564 (Base 0)	7564 (Base 0)	8564 (Base 0)	Read-Only	64 Chars
	5565 (Base 1)	6565 (Base 1)	7565 (Base 1)	8565 (Base 1)		32 Words
Product Id	5596 (Base 0)	6596 (Base 0)	7596 (Base 0)	8596 (Base 0)	Read-Only	64 Chars
	5597 (Base 1)	6597 (Base 1)	7597 (Base 1)	8597 (Base 1)		32 Words
Product Text	5628 (Base 0)	6628 (Base 0)	7628 (Base 0)	8628 (Base 0)	Read-Only	64 Chars
	5629 (Base 1)	6629 (Base 1)	7629 (Base 1)	8629 (Base 1)		32 Words
Serial Number	5660 (Base 0)	6660 (Base 0)	7660 (Base 0)	8660 (Base 0)	Read-Only	16 Chars
	5661 (Base 1)	6661 (Base 1)	7661 (Base 1)	8661 (Base 1)		8 Words
Hardware Revision	5668 (Base 0)	6668 (Base 0)	7668 (Base 0)	8668 (Base 0)	Read-Only	64 Chars
	5669 (Base 1)	6669 (Base 1)	7669 (Base 1)	8669 (Base 1)		32 Words
Firmware Revision	5700 (Base 0)	6700 (Base 0)	7700 (Base 0)	8700 (Base 0)	Read-Only	64 Chars
	5701 (Base 1)	6701 (Base 1)	7701 (Base 1)	8701 (Base 1)		32 Words
Device PDI Length	5732 (Base 0)	6732 (Base 0)	7732 (Base 0)	8732 (Base 0)	Read-Only	1 Word
	5733 (Base 1)	6733 (Base 1)	7733 (Base 1)	8733 (Base 1)		
Device PDO Length	5733 (Base 0)	6733 (Base 0)	7733 (Base 0)	8733 (Base 0)	Read-Only	1 Word
	5734 (Base 1)	6734 (Base 1)	7734 (Base 1)	8734 (Base 1)		

10.3 MULTIPLE PORT PROCESS DATA (PDI/PDO) ACCESS VIA MODBUS/TCP

The process data has been grouped together in order to minimize the number of Modbus messages required to interface to the IO-Link master. The PDI and PDO data for multiple ports can be received or transmitted by one message.

	Modbus Holding Register Address (Base 1)	Controller Port 1 Access		Controller Port 2 Access		Controller Port 3 Access		Controller Port 4 Access	
		Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)
Read (Input) Process Data Input	1000 (Port 1)								
	2000 (Port 2)								
	3000 (Port 3)								
	4000 (Port 4)								
Read (Input) Process Data Output	1050 (Port 1)								
	2050 (Port 2)								
	3050 (Port 3)								
	4050 (Port 4)								
Write (Output) Process Data Output	1050 (Port 1)								
	2050 (Port 2)								
	3050 (Port 3)								
	4050 (Port 4)								

	Modbus Holding Register Address (Base 1)	Controller Port 5 Access		Controller Port 6 Access		Controller Port 7 Access		Controller Port 8 Access	
		Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)
Read (Input) Process Data Input	5000 (Port 5)								
	6000 (Port 6)								
	7000 (Port 7)								
	8000 (Port 8)								
Read (Input) Process Data Output	5050 (Port 5)								
	6050 (Port 6)								
	7050 (Port 7)								
	8050 (Port 8)								
Write (Output) Process Data Output	5050 (Port 5)								
	6050 (Port 6)								
	7050 (Port 7)								
	8050 (Port 8)								

To receive and transmit process data for eight ports, it may be necessary to adjust the size of the PDI/PDO data blocks.

Modbus Read/Write Access *where*:

- All PDI data can be read with one Modbus Read Holding Registers message.
- All PDO data can be read with one Modbus Read Holding Registers read message.
- All PDO data can be written with one Modbus Write Holding Registers message.
- Controller Read access:
 - The PDI data from one or more ports may be read with one message. (i.e.: If addressing port 1, at address 1000, ports one to four may be read in one message.)
 - The PDO data from one or more ports may be read with one message. (i.e.: If addressing port 1, at address 1050, ports one to four may be read in one message.)
 - Partial PDI and PDO data reads are allowed.
 - The length of the Read message can range from 1 to the total, configured PDI or PDO length for all ports starting at the addressed port.
- Controller Write (Output) access:


- Only PDO data may be written.
- The PDO data for one or more ports may be written with one Write Holding Registers message.
- Partial PDO data writes are not allowed.
- The length of the Write message must be equal to the total of the configured PDO lengths for all ports to be written. The one exception is that the data length of the last port to be written must be equal to or greater than the device PDO length for that port.

11 FUNCTIONALITY DESCRIPTIONS

11.1 PROCESS DATA BLOCK DESCRIPTIONS

11.1.1 Input Process Data Block Description

The Input Process Data Block format is dependent on the configured PDI Data Format. The following tables describe the Input Process Data Block in the possible formats.

Parameter Name	Data Type	Description
Port Status	BYTE	<p>The status of the IO-Link device.</p> <p>Bit 0 (0x01): 0 = IO-Link port communication initialization process is inactive 1 = IO-Link port communication initialization process is active</p> <p>Bit 1 (0x02): 0 = IO-Link port communication is not operational 1 = IO-Link port communication is operational</p> <p>Bit 2 (0x04): 0 = IO-Link input process data is not valid. 1 = IO-Link input process data is valid.</p> <p>Bit 3 (0x08): 0 = No fault detected 1 = Fault detected</p> <ul style="list-style-type: none"> • A minor communication fault is indicated by the Operational status bit being set to 1. A minor communication fault results from: <ul style="list-style-type: none"> - A temporary loss of communication to the IO-Link device. - A recoverable IOLM software or hardware fault. • A major communication fault is indicated by the Operational bit being set to 0. <ul style="list-style-type: none"> - An unrecoverable loss of communication to the IO-Link device. - An unrecoverable IOLM software or hardware fault. <p>Bits 4-7: Reserved (0)</p>
Auxiliary I/O	BYTE	<p>The auxiliary bit on the IO-Link port is:</p> <div style="text-align: center;">  </div> <p>Bit 0 (0x01): The status of the auxiliary bit. 0 = off 1 = on</p> <p>Bits 1-3: Reserved (0)</p> <p>If Include Digital I/O in PDI Data Block is disabled: Bits 4-7: Reserved (0)</p>
		<p><i>IOLM DR-8-PNIO - Dedicated DIO Ports Only</i> If Include Digital I/O in PDI Data Block is enabled: Bits 4-7: Bit 4 (0x10) – D1 = DI status Bit 5 (0x20) – D2 = DIO status Bit 6</p>

		(0x40) – D3 = D2 status Bit 7 (0x80) – D4 = DIO status
Event Code	INT	16-bit event code received from the IO-Link device.
PDI Data <i>Default Length = 32 bytes</i>	Array of up to 32 BYTEs	The PDI data as received from the IO-Link device. May contain from 0 to 32 bytes of PDI data. The definition of the PDI data is device dependent. Note: <i>Length is configurable using the web page interface.</i>

11.1.1.1 Input Process Data Block-8 Bit Data Format

The following table provides detailed information about the Input Process Data Block-8 Bit data format.

Byte	Bit 7	Bit 0
0	Port Status	
1	Auxiliary I/O	
2	Event Code LSB	
3	Event Code MSB	
4	PDI Data Byte 0	
5	PDI Data Byte 1	
..	..	
..	..	
N+3	PDI Data Byte (N-1)	

11.1.1.2 Input Process Data Block-16 Bit Data Format

The following table provides detailed information about the Input Process Data Block-16 data format.

Word	Bit 15	Bit 8	Bit 7	Bit 0
0	Port Status		Auxiliary I/O	
1	Event Code			
2	PDI Data Word 0			
3	PDI Data Word 1			
..	..			
..	..			
N+1	PDI Data Word (N-1)			

11.1.1.3 Input Process Data Block-32 Bit Data Format

The following table provides detailed information about the Input Process Data Block-32 Bit data format.

Long Word	Bit 31	Bit 24	Bit 23	Bit 16	Bit 15	Bit 0
0	Port Status		Auxiliary I/O		Event Code	
2	PDI Data Long Word 0					
3	PDI Data Long Word 1					
..	..					
N	PDI Data Long Word (N-1)					

11.1.2 Output Process Data Block Description

The contents of the Output Process Data Block are configurable.

Parameter Name	Data	Description
Clear Event Code in PDO Block (Configurable option) <i>Default:</i> Not included	INT	If included, allows clearing of 16-bit event code received in the PDI data block via the PDU data block.
Include Digital Output(s) in PDO Data Block <i>Default:</i> Not included	INT	If included, allows setting the Digital Output Pins D2 and D4.
PDO Data <i>Default Length</i> = 32 bytes	Array of up to 32 BYTES	The PDO data written to the IO-Link device. May contain from 0 to 32 bytes of PDO data. The definition and length of the PDO data is device dependent. Note: Length is configurable via web page interface.

11.1.2.1 Output Process Data Block-8 Bit (SINT) Data Format

Without either the **Clear Event Code in PDO Block** or **Include Digital Output(s) in PDO Data Block** options selected:

Byte	Bit 7	Bit 0
0	PDO Data Byte 0	
1	PDO Data Byte 1	
..	..	
..	..	
N-1	PDO Data Byte (N-1)	

With the **Clear Event Code in PDO Block** option selected and without the **Include Digital Output(s) in PDO Data Block** option selected:

Byte	Bit 7	Bit 0
0	Event Code LSB	
1	Event Code MSB	
2	PDO Data Byte 0	
3	PDO Data Byte 1	
..	..	
..	..	
N+1	PDO Data Byte (N-1)	

With both the **Clear Event Code in PDO Block** and **Include Digital Output(s) in PDO Data Block** options selected:

Byte	Bit 7	Bit 0
0	Event code LSB	
1	Event code MSB	
2	Digital Output Settings: Bit 1 (0x02) - DI setting Bit 3 (0x08) - C/Q setting	
3	0 (Unused)	
4	PDO Data Byte 0	
5	PDO Data Byte 1	
..	..	
..	..	
N + 3	PDO Data Byte (N-1)	

11.1.2.2 Output Process Data Block-16 Bit (INT) Data Format

Without either the **Clear Event Code in PDO Block** or **Include Digital Output(s) in PDO Data Block** options selected:

Word	Bit 15	Bit 0
0	PDO Data Word 0	
1	PDO Data Word 1	
..	..	
..	..	
N-1	PDO Data Word (N-1)	

With the **Clear Event Code in PDO Block** option selected and without the **Include Digital Output(s) in PDO Data Block** option selected:

Word	Bit 15	Bit 0
0	Event Code	
1	PDO Data Word 0	
2	PDO Data Word 1	
..	..	
..	..	
N	PDO Data Word (N-1)	

With both the **Clear Event Code in PDO Block** and **Include Digital Output(s) in PCO Data Block** options selected:

Word	Bit 15	Bit 0
0	Event Code	
1	Digital Output Settings: Bit 1 (0x02) - DI setting Bit 3 (0x08) - C/Q setting	
2	PDO Data Word 0	
3	PDO Data Word 1	
..	..	
..	..	
N+1	PDO Data Word (N-1)	

11.1.2.3 Output Process Data Block-32 Bit (DINT) Data Format

Without either the **Clear Event Code in PDO Block** or **Include Digital Output(s) in PDO Data Block** options selected:

Long Word	Bit 31	Bit 0
0	PDO Data Long Word 0	
1	PDO Data Long Word 1	
..	..	
..	..	
N-1	PDO Data Long Word (N-1)	

With the **Clear Event Code in PDO Block** option selected and without the **Include Digital Output(s) in PDO Data Block** option selected:

Long Word	Bit 31	Bit 16	Bit 15	Bit 0
0	0		Event Code	
1	PDO Data Long Word 0			
2	PDO Data Long Word 1			
..	..			
..	..			
N - 1	PDO Data Long Word (N-1)			

With both the **Clear Event Code in PDO Block** and **Include Digital Output(s) in PDO Data Block** options selected:

Long Word	Bit 31	Bit 16	Bit 15	Bit 0
0	Digital Output Settings: Bit 17 (0x2000) – DI setting Bit 19 (0x8000) – C/Q setting		Event Code	
1	PDO Data Long Word 0			
2	PDO Data Long Word 1			
..	..			
..	..			
N - 1	PDO Data Long Word (N-1)			

11.2 EVENT HANDLING


The IOLM event handling is designed to provide real-time updates of event codes received directly from the IO-Link device. The IO-Link event code:

- Is included in the second 16-bit word of the Input Process Data (PDI) block.
 - An active event is indicated by a non-zero value.
 - Inactive or no event is indicated by a zero value.
- Two methods are provided to clear an event:
 - Enable the *Clear Event After Hold Time* option.
 - The IOLM keeps, or holds, the active event code in the PDI block until the configured *Active Event Hold Time* has passed.
 - The IOLM then clears the event code in the PDI block and waits until the *Clear Event Hold Time* has passed before including another event code in the PDI block.
 - Enable the *Clear Event In PDO Block* option.
 - The IOLM monitors the PDO block received from the PLC.
 - The IOLM expects the first entry of the PDO block to indicate an event code to be cleared.
 - If there is an active event code in the PDI block and the PDO block both contain the same event code, the event code is cleared in the PDI block.
 - The IOLM then clears event code in the PDI block and waits until the *Clear Event Hold Time* has passed before including another event code in the PDI block.
- The two methods can be used separately or together to control clearing of events.

The next subsections illustrate the event clearing process for the various event configurations.


11.2.1 Clear Event After Hold Time Process

This illustrates clearing the event after the hold time process.




11.2.2 Clear Event in PDO Block Process

This illustrates clearing the event in the PDO block process.



11.2.3 Clear Event Code in PDO Block and Clear Event After Hold Time Process- PDO Block First

This illustrates clearing the event code in the PDO block and clearing the event after the hold time process with the PDO block first.



11.3 ISDU HANDLING

The IOLM provides a very flexible ISDU interface that is used by all supported industrial protocols. The ISDU interface contains the following:


- An ISDU *request* may contain one or multiple individual ISDU read and/or write *commands*.
- Individual ISDU command-based byte swapping capabilities.
- Variable sized command structures to allow access to a wide range of ISDU block sizes.
- A single ISDU request may contain as many ISDU read and/or write commands as allowed by the industrial protocol payload. For example, if an industrial protocol provides up to 500 byte read/write payloads, then an ISDU request may contain multiple commands of various lengths that can total up to 500 bytes in length.
- For the ControlLogix family of EtherNet/IP PLCs, both blocking and non-blocking ISDU request methods are provided.
 - The IOLM implements blocking ISDU requests by not responding to an ISDU request message until all commands have been processed.
 - The IOLM implements non-blocking ISDU requests by:
 - Responding to an ISDU request message immediately after receiving and verifying the ISDU request.
 - Requiring the PLC to monitor the ISDU request status with read messages. The IOLM will not return a completed status until all the ISDU commands have been processed.

11.3.1 ISDU Request/Response Structure

ISDU requests may contain a single command or multiple, nested commands.

11.3.1.1 Single ISDU Command Requests

This illustrates a single ISDU command request.




Single Command ISDU Request/Response

11.3.1.2 Multiple ISDU Command Structure


ISDU requests with multiple commands may consist of commands of the same data size or commands with different data sizes. The following are two examples of multiple ISDU commands.

- **Multiple Command ISDU Request/Response of Same Data Area Length**



Example - Multiple Command ISDU Request/Response of Same Data Area Length

- Multiple Command ISDU Request/Response of Different Data Lengths



Example - Multiple Command ISDU Request/Response of Different Data Area Lengths

11.3.2 ISDU Request Message Format From PLC to IOLM

Write and read ISDU commands have the same message data format. Each ISDU request message is comprised of one or more commands. The command(s) can consist of either a series of nested commands or a single read command.



Note: A list of nested ISDU commands is terminated with either a control field of 0, (single/last operation), or the end of the message data.

11.3.2.1 Standard ISDU Request Command Format

This table displays a standard ISDU request command format with ControlLogix PLCs.

Name	Data Type	Parameter Descriptions
Byte Swapping	USINT	Bits 0-3: 0= No byte swapping. 1= 16-bit (INT) byte swapping of ISDU data. 2= 32-bit (DINT) byte swapping of ISDU data. Bits 4-7: Set to zero. Unused.
RdWrControlType	USINT	Provides the control and type of ISDU command. Bits 0-3, Type Field: 0 = NOP (No operation) 1 = Read operation 2 = Write operation 3 = Read/Write "OR" 4 = Read/Write "AND" Bits 4-7, Control Field: 0 = Single/Last Operation (length can vary from to 1 to 232) 1 = Nested batch command – fixed 4 byte data area 2 = Nested batch command – fixed 8 byte data area 3 = Nested batch command – fixed 16 byte data area 4 = Nested batch command – fixed 32 byte data area 5 = Nested batch command – fixed 64 byte data area 6 = Nested batch command – fixed 128 byte data area 7 = Nested batch command – fixed 232 byte data area
Index	UINT	The parameter address of the data object in the IO-Link device.
Subindex	UINT	The data element address of a structured parameter of the data object in the IO-Link device.
Datalength	UINT	Length of data to read or write. For nested batch commands, the data length can vary from 1 to the fixed data area size.
Data	Array of USINTs, UINTs, or UDINTs.	Size of array is determined by the Control field in RdWrControlType. Note: Data is valid only for write commands.

11.3.2.2 Integer (16-Bit Word) ISDU Request Command Format

This table shows an integer (16 bit word) ISDU request command format with a SLC, MicroLogix, PLC-5, or Modbus/TCP.

Name	Data Type	Parameter Description
Byte Swapping / RdWrControlType	UINT	<p>Provides the control, type and byte swapping of ISDU command</p> <p>Bits 0-3, Type Field:</p> <p>0 = NOP (No operation) 1 = Read operation 2 = Write operation 3 = Read/Write "OR" 4 = Read/Write "AND"</p> <p>Bits 4-7, Control Field:</p> <p>0 = Single/Last Operation (length can vary from 1 to 232) 1 = Nested batch command – fixed 4 byte data area 2 = Nested batch command – fixed 8 byte data area 3 = Nested batch command – fixed 16 byte data area 4 = Nested batch command – fixed 32 byte data area 5 = Nested batch command – fixed 64 byte data area 6 = Nested batch command – fixed 128 byte data area 7 = Nested batch command – fixed 232 byte data area</p> <p>Bits 8-11:</p> <p>0 = No byte swapping. 1 = 16-bit (INT) byte swapping of ISDU data. 2 = 32-bit (DINT) byte swapping of ISDU data.</p> <p>Bits 12-15:</p> <p>Set to zero. Unused.</p>
Index	UINT	The parameter address of the data object in the IO-Link device.
Subindex	UINT	The data element address of a structured parameter of the data object in the IO-Link device.
Datalength	UINT	<p>Length of data to read or write.</p> <p>For nested batch commands, the data length can vary from 1 to the fixed data area size.</p>
Data	Array of USINTs, UINTs, or UDINTs.	<p>Size of array is determined by the Control field in RdWrControlType.</p> <p>Note: Data is valid only for write commands.</p>

11.3.3 ISDU Response Message Format

The ISDU responses have the same data format as requests with the only exception being the returned command status. Each ISDU response message is comprised of one or more responses to the single and/or nested command(s) received in the request.

11.3.3.1 Standard ISDU Response Command Format

The following table show the standard ISDU response command format with ControlLogix PLCs.

Name	Data Type	Parameter Description
Status	USINT	<p>Indicates the byte alignment and status of the command response.</p> <p>Byte swapping, bits 0-3:</p> <p>0= No byte swapping. 1= 16-bit (INT) byte swapping of TX/RX ISDU data. 2= 32-bit (DINT) byte swapping of TX/RX ISDU data.</p> <p>Status, bits 4-7:</p> <p>0 = NOP (No operation) 1 = In process (Only valid for non-blocking requests) 2 = Success 3 = Failure: IO-Link device rejected the request. 4 = Timed out: IO-Link device did not respond</p>
RdWrControlType	USINT	<p>Provides the control and type of ISDU request</p> <p>Bits 0-3, Type Field:</p> <p>0 = NOP (No operation) 1 = Read operation 2 = Write operation 3 = Read/Write "OR" 4 = Read/Write "AND"</p> <p>Bits 4-7, Control Field:</p> <p>0 = Single/Last Operation (length can vary from to 1 to 232) 1 = Nested batch command – fixed 4 byte data area 2 = Nested batch command – fixed 8 byte data area 3 = Nested batch command – fixed 16 byte data area 4 = Nested batch command – fixed 32 byte data area 5 = Nested batch command – fixed 64 byte data area 6 = Nested batch command – fixed 128 byte data area 7 = Nested batch command – fixed 232 byte data area</p>
Index	UINT	The parameter address of the data object in the IO-Link device.
Subindex	UINT	The data element address of a structured parameter of the data object in the IO-Link device.
Datalength	UINT	<p>Length of data that was read or written.</p> <p>For nested batch commands, the data length can vary from 1 to fixed data area size.</p>
Data	Array of USINTs, UINTs, or UDINTs.	<p>Data required for read commands. Optionally can return the data of a write command.</p> <p>The size of the array is determined by the Control field in the RdWrControlType.</p> <p>Note: Data field not required for single NOP commands.</p>

11.3.3.2 Integer (16-Bit Word) ISDU Response Command Format

The following table shows an integer (16-bit word) ISDU response command format with SLC, MicroLogix, PLC-5, or Modbus/TCP.


Name	Data Type	Parameter Descriptions
Status, Byte-Swapping, RdWrControlType	UINT	<p>Indicates the control, type, byte swapping and status of the ISDU command.</p> <p>Bits 0-3, Type Field:</p> <ul style="list-style-type: none"> 0 = NOP (No operation) 1 = Read operation 2 = Write operation 3 = Read/Write "OR" 4 = Read/Write "AND" <p>Bits 4-7, Control Field:</p> <ul style="list-style-type: none"> 0 = Single/Last Operation (length can vary from 1 to 232) 1 = Nested batch command – fixed 4 byte data area 2 = Nested batch command – fixed 8 byte data area 3 = Nested batch command – fixed 16 byte data area 4 = Nested batch command – fixed 32 byte data area 5 = Nested batch command – fixed 64 byte data area 6 = Nested batch command – fixed 128 byte data area 7 = Nested batch command – fixed 232 byte data area <p>Byte swapping, bits 8-11:</p> <ul style="list-style-type: none"> 0 = No byte swapping. 1 = 16-bit (INT) byte swapping of TX/RX ISDU data. 2 = 32-bit (DINT) byte swapping of TX/RX ISDU data. <p>Status, bits 12-15:</p> <ul style="list-style-type: none"> 0 = NOP (No operation) 1 = In process (Only valid for non-blocking requests) 2 = Success 3 = Failure: IO-Link device rejected the request. 4 = Timed out: IO-Link device did not respond
Index	UINT	The parameter address of the data object in the IO-Link device
Subindex	UINT	The data element address of a structured parameter of the data object in the IO-Link device.
Datalength	UINT	Length of data that was read or written. For nested batch commands, the data length can vary from 1 to fixed data area size.
Data	Array of USINTs, UINTs, or UDINTs	<p>Data returned for read commands. Contains the data of a write command.</p> <p>The size of the array is determined by the Control field in RdWrControlType.</p> <p>Note: Data field not required for single NOP commands.</p>

11.3.4 ISDU Blocking and Non-Blocking Methods

The IOLM supports both blocking and non-blocking ISDU requests. The following diagrams demonstrate how each mode works.


11.3.4.1 Single Command Blocking

The following illustrates the single command blocking method.



11.3.4.2 Multiple Command Blocking


This illustrates the multiple command blocking method.



Multiple Command ISDU Blocking Process

11.3.4.3 Single Command Non-Blocking


This illustrates the single command non-blocking method.



Single Command ISDU Non-Blocking Process

11.3.4.4 Multiple Command Non-Blocking

This illustrates the multiple command non-blocking method.



Multiple Command ISDU Non-Blocking Process

12 TROUBLESHOOTING AND TECHNICAL SUPPORT

12.1 TROUBLESHOOTING

Before contacting Technical Support, you may want to try the following:


- Check to make sure LEDs are not reporting an issue. Refer to par. 12.2.
- Verify that the network IP address, subnet mask, and gateway are correct and appropriate for the network. Make sure that the IP address programmed into the IO-Link Master matches the unique reserved IP configured address assigned by the system administrator.
 - If using DHCP, the host system needs to provide the subnet mask. The gateway is optional and is not required for a purely local network.
 - Remember that if the rotary switches on the CBX-IOL-8-PNIO are set to a non-default position, the rotary switches override the lower 3 digits (8 bits) of the static IP address configured in the **Network** page.
 - Verify that the Ethernet hub and any other network devices between the system and the IO-Link Master are powered up and operating.
- Verify that you are using the correct types of cables on the correct connectors and that all cables are connected securely.
- Disconnect and re-connect the IO-Link device, or optionally, use the **Configuration | IO-Link** page to **Reset**
- the port, and then set the **Port Mode** back to **IOLink**.
- Reboot or power cycle the IOLM. Use the **Advanced | Software** page to reboot the IOLM.
- Verify that the **Port Mode** matches the device, for example: IO-Link, Digital In, Digital Out, or Reset (port is disabled).
- If you are receiving an error that indicates a hardware fault, check the **Configuration | IO-Link** page for the port experiencing the fault.
 - Check the settings for the **Automatic Upload Enable** and **Automatic Download Enable** options. If the Vendor ID or Device ID of the attached device does not match, a hardware fault is generated.
 - Make sure if the port contains data storage that the Vendor ID and Device ID match the device attached to the port. If it does not, **CLEAR** the data storage or move the device to another port.
 - Check the Device Validation and Data Validation settings. If the attached device does not meet these settings, a hardware fault is issued.
- Open the IO-Link Master web interface and review the following pages to see if you can locate a problem:
 - **IO-Link Diagnostics**
 - **EtherNet/IP Diagnostics**
 - **Modbus/TCP Diagnostics**
 - **OPC UA Diagnostics**
- If you have a spare IO-Link Master, try replacing the IO-Link Master.

12.2 IOLM LEDs

12.2.1 CBX-IOL-8-PNIO-LEDs

The CBX-IOL-8-PNIO (8-port IP67 model with an L-coded power connector) provides these LEDs.

LED Activity During Power On Sequence - CBX-IOL-8-PNIO
<ol style="list-style-type: none"> 1. The US LED lights. 2. The ETH1/ETH2 LED lights on the connected port. 3. The MOD and NET LEDs are lit. 4. The IO-Link LEDs flash (if no IO-Link device attached) or are lit if an IO-Link device is attached. <p>The MOD LED is solid green, the IO-Link Master is ready for operation.</p>

CBX-IOL-8-PNIO LEDs	
US	<p>The US LED provides the following information:</p> <ul style="list-style-type: none"> • Green solid = The IO-Link Master is powered. • Red solid = Power input voltage below 18VDC.
UA	<p>The UA LED provides the following information:</p> <ul style="list-style-type: none"> • Green solid = The IO-Link Master is powered. • Red solid = Power input voltage below 18VDC.
MOD (Module Status)	<p>The MOD LED provides the following information:</p> <ul style="list-style-type: none"> • Off = No module status • Green and red flashing = Self-test • Green flashing = Standby – not configured • Green solid = Operational • Red flashing = Minor recoverable fault - check the EtherNet/IP Diagnostics page to locate the issue • Red solid = Major unrecoverable fault
NET (Network)	<p>The NET LED provides the following information:</p> <ul style="list-style-type: none"> • Off = No IP address • Green and red flashing = Self-test • Green flashing = An IP address is configured, but no CIP connections are established, and an Exclusive Owner connection has not timed out • Green solid = Active EtherNet/IP or Modbus connection and no EtherNet/IP connection time-outs • Red flashing = One or more EtherNet/IP connection time-outs • Red solid = Duplicate IP address on network
1-8 	<p>This LED provides the following information about the IO-Link port.</p> <ul style="list-style-type: none"> • Off = SIO mode - signal is low or disabled • Yellow = SIO mode - signal is high • Red flashing = Hardware fault - make sure that configured IO-Link settings on the port do not conflict with the device that is attached: <ul style="list-style-type: none"> - Automatic Upload and/or Download is enabled and it is not the same device. - Device Validation Mode is enabled and it is not the correct device. - Data Validation Mode is enabled but there is an error. • Red solid = PDI of the attached IO-Link device is invalid • Green solid = An IO-Link device is connected and communicating • Green flashing = Searching for IO-Link devices
Port 1-4 DI	<p>The DI LED indicates digital input on DI (Pin 2).</p> <ul style="list-style-type: none"> • Off = DI signal is low or disconnected • Yellow = DI signal is high
ETH1/ETH2	<p>The ETH1/ETH2 LEDs provide the following information:</p> <ul style="list-style-type: none"> • Green solid = Link • Green flashing = Activity

12.3 CONTACTING TECHNICAL SUPPORT

You may want to access the **Help/SUPPORT** page when you call Technical Support, as they may request the information displayed on the **SUPPORT** page.



The screenshot shows the 'Support' page in the IO-Link Master web interface. The page has a blue navigation bar with 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help' tabs. The 'Help' tab is active. The main content area is titled 'Support' and contains a table with system and application base information. A 'Download' button is visible in the top right corner of the table area.

SYSTEM INFO	
Host Name	?
Serial Number	9608-085461
Model Name	IOLM 8-Port IP67 Ethernet/IP
Hardware Version	99600-8 rev A
Switch Position	000
MAC Address	00:c0:4e:7a:ff:b7
IP Address	192.168.1.250
Subnet Mask	255.255.255.0
Gateway Address	0.0.0.0
IP Type	static
APPLICATION BASE	
application-manager	1.5.0.3
configuration-manager	1.5.0.4
discovery-protocol	1.5.0.1
ethernetp	1.5.0.023
event-log	1.5.0.2
iolink-driver	1.5.2.13
liblinkutils	1.5.0.046
modbus	1.5.0.020
opcu-server	1.5.1.13
web-browser-interface	1.5.0.38
IMAGES	
U-Boot	1.29
FPGA	1.02
ulmage-Primary	1.33
ulmage-Backup	1.33
Applications	1.5.28

12.4 USING LOG FILES

The IO-Link Master provides four different log files that you can view, export, or clear:

- **Syslog** (system log) displays line-by-line activity records.
- **dmesg** displays Linux kernel messages.
- **top** displays which programs are using most of the memory and CPU.
- **ps** displays the running programs
- **pnio** displays PROFINET IO activity
- All log files start up automatically during the startup cycle. Each log file has a size limit of 100KB.



Note: Typically, log files are intended to be used by Technical Support in the event there is a problem.

12.4.1 View a Log File

Use this procedure to view a log file:


1. Open your browser and enter the IP address of the IO-Link Master.
2. Click **Advanced** and then **LOG FILES**.
3. Select the log file type from the drop-list.
4. Optionally, click the **REFRESH** button to get the latest information.
5. Optionally, export the log file.



12.4.2 Export a Log File

Use the following procedure to export a log file.

1. Open your browser and enter the IP address of the IO-Link Master.
2. Click **Advanced** and then **LOG FILES**.
3. Select the log file type from the drop-list.
4. Click the **EXPORT** button.
5. Click the **Save** button drop-list and click **Save** to save it to your user folder or **Save as** to browse to or create a new folder in which to place the log file.




6. Depending on your browser, you may need to close the pop-up window.

12.4.3 Clear a Log File

Use this procedure to clear a log file.

1. Open your browser and enter the IP address of the IO-Link Master.
2. Click **Advanced** and then **LOG FILES**.
3. Optionally, export the log file.
4. Select the log file type from the drop-list.
5. Click the **CLEAR** button.



The log file automatically starts logging the latest information.



 **DATALOGIC**

www.datalogic.com